

AutoCAD® 2002

autodesk®

DXF Reference Guide

Copyright © 2001 Autodesk, Inc.

All Rights Reserved

AUTODESK, INC. MAKES NO WARRANTY, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, REGARDING THESE MATERIALS AND MAKES SUCH MATERIALS AVAILABLE SOLELY ON AN "AS-IS" BASIS.

IN NO EVENT SHALL AUTODESK, INC. BE LIABLE TO ANYONE FOR SPECIAL, COLLATERAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING OUT OF PURCHASE OR USE OF THESE MATERIALS. THE SOLE AND EXCLUSIVE LIABILITY TO AUTODESK, INC., REGARDLESS OF THE FORM OF ACTION, SHALL NOT EXCEED THE PURCHASE PRICE OF THE MATERIALS DESCRIBED HEREIN.

Autodesk, Inc. reserves the right to revise and improve its products as it sees fit. This publication describes the state of this product at the time of its publication, and may not reflect the product at all times in the future.

Autodesk Trademarks

The following are registered trademarks of Autodesk, Inc., in the USA and/or other countries: 3D Plan, 3D Props, 3D Studio, 3D Studio MAX, 3D Studio VIZ, 3DSurfer, ActiveShapes, ActiveShapes (logo), Actrix, ADE, ADI, Advanced Modeling Extension, AEC Authority (logo), AEC-X, AME, Animator Pro, Animator Studio, ATC, AUGI, AutoCAD, AutoCAD Data Extension, AutoCAD Development System, AutoCAD LT, AutoCAD Map, Autodesk, Autodesk Animator, Autodesk (logo), Autodesk MapGuide, Autodesk University, Autodesk View, Autodesk WalkThrough, Autodesk World, AutoLISP, AutoShade, AutoSketch, AutoSurf, AutoVision, Biped, bringing information down to earth, CAD Overlay, Character Studio, Design Companion, Design Your World, Design Your World (logo), Drafrix, Education by Design, Generic, Generic 3D Drafting, Generic CADD, Generic Software, Geodyssey, Heidi, HOOPS, Hyperwire, Inside Track, Kinetix, MaterialSpec, Mechanical Desktop, Multimedia Explorer, NAAUG, ObjectARX, Office Series, Opus, PeopleTracker, Physique, Planix, Powered with Autodesk Technology, Powered with Autodesk Technology (logo), RadioRay, Rastation, Softdesk, Softdesk (logo), Solution 3000, Tech Talk, Texture Universe, The AEC Authority, The Auto Architect, TinkerTech, VISION, *WHIP!*, *WHIP!* (logo), Woodbourne, WorkCenter, and World-Creating Toolkit.

The following are trademarks of Autodesk, Inc., in the USA and/or other countries: 3D on the PC, 3ds max, ACAD, Advanced User Interface, AEC Office, AME Link, Animation Partner, Animation Player, Animation Pro Player, A Studio in Every Computer, ATLAST, Auto-Architect, AutoCAD Architectural Desktop, AutoCAD Architectural Desktop Learning Assistance, AutoCAD Learning Assistance, AutoCAD LT Learning Assistance, AutoCAD Simulator, AutoCAD SQL Extension, AutoCAD SQL Interface, Autodesk Animator Clips, Autodesk Animator Theatre, Autodesk Device Interface, Autodesk Inventor, Autodesk PhotoEDIT, Autodesk Point A (logo), Autodesk Software Developer's Kit, Autodesk Streamline, Autodesk View DwgX, AutoFlix, AutoPAD, AutoSnap, AutoTrack, Built with ObjectARX (logo), ClearScale, Colour Warper, Combustion, Concept Studio, Content Explorer, cornerStone Toolkit, Dancing Baby (image), Design 2000 (logo), DesignCenter, Design Doctor, Designer's Toolkit, DesignProf, DesignServer, DWG Linking, DWG Unplugged, DXF, Extending the Design Team, FLI, FLIC, GDX Driver, Generic 3D, gmax, Heads-up Design, Home Series, i-drop, Kinetix (logo), Lightscape, ObjectDBX, onscreen onair online, Ooga-Chaka, Photo Landscape, Photoscape, Plugs and Sockets, PolarSnap, Pro Landscape, QuickCAD, Real-Time Roto, Render Queue, SchoolBox, Simply Smarter Diagramming, SketchTools, Sparks, Suddenly Everything Clicks, Supportdesk, The Dancing Baby, Transform Ideas Into Reality, Visual LISP, Visual Syllabus, VIZable, Volo, and Where Design Connects.

Third Party Trademarks

All other brand names, product names or trademarks belong to their respective holders.

Third Party Software Program Credits

ACIS Copyright © 1989-2001 Spatial Corp.

Copyright © 1997 Microsoft Corporation. All rights reserved.

International CorrectSpell™ Spelling Correction System © 1995 by Lernout & Hauspie Speech Products, N.V. All rights reserved.

InstallShield™ 3.0. Copyright © 1997 InstallShield Software Corporation. All rights reserved.

Portions Copyright © 1991-1996 Arthur D. Applegate. All rights reserved.

Portions of this software are based on the work of the Independent JPEG Group.

Typefaces from the Bitstream ® typeface library copyright 1992.

Typefaces from Payne Loving Trust © 1996. All rights reserved.

GOVERNMENT USE

Use, duplication, or disclosure by the U. S. Government is subject to restrictions as set forth in FAR 12.212 (Commercial Computer Software-Restricted Rights) and DFAR 227.7202 (Rights in Technical Data and Computer Software), as applicable.

Contents

| | | |
|-----------|---|----|
| | Revisions to the DXF Reference | 1 |
| | Objects Section | 2 |
| Chapter 1 | DXF Format | 5 |
| | Organization of This Reference | 6 |
| | Formatting Conventions in This Reference. | 6 |
| | Object and Entity Codes | 6 |
| | Group Code Value Types | 7 |
| | Group Codes in Numerical Order | 9 |
| Chapter 2 | HEADER Section | 15 |
| | HEADER Section Group Codes | 16 |
| | Revised VPORT Header Variables | 27 |
| | Special Handling of Date/Time Variables | 28 |
| Chapter 3 | CLASSES Section | 31 |
| | CLASSES Section Group Codes | 32 |
| | Default Class Values | 33 |
| Chapter 4 | TABLES Section | 35 |
| | Symbol Table Group Codes | 36 |
| | Common Symbol Table Group Codes | 36 |

| | | |
|------------------|---|-----------|
| | Common Group Codes for Symbol Table Entries | 37 |
| | APPID | 38 |
| | BLOCK_RECORD | 39 |
| | DIMSTYLE | 40 |
| | LAYER | 44 |
| | LTYPE | 45 |
| | STYLE | 46 |
| | UCS | 47 |
| | VIEW | 49 |
| | VPORT | 51 |
| Chapter 5 | BLOCKS Section | 55 |
| | BLOCKS Section Group Codes | 56 |
| | BLOCK | 56 |
| | ENDBLK | 58 |
| Chapter 6 | ENTITIES Section. | 59 |
| | Common Group Codes for Entities | 60 |
| | 3DFACE | 62 |
| | 3DSOLID | 63 |
| | ACAD_PROXY_ENTITY. | 63 |
| | ARC | 64 |
| | ATTDEF | 65 |
| | ATTRIB | 66 |
| | BODY | 68 |
| | CIRCLE | 69 |
| | DIMENSION | 69 |
| | Common Dimension Group Codes | 69 |
| | Aligned Dimension Group Codes. | 71 |
| | Linear and Rotated Dimension Group Codes | 72 |
| | Radial and Diameter Dimension Group Codes | 73 |
| | Angular Dimension Group Codes. | 74 |
| | Ordinate Dimension Group Codes | 75 |
| | Dimension Style Overrides | 76 |
| | ELLIPSE | 76 |
| | ELLIPSE Command's Parameter Option. | 77 |
| | HATCH | 78 |
| | Boundary Path Data | 80 |
| | Pattern Data | 83 |
| | IMAGE | 83 |
| | INSERT | 85 |
| | LEADER. | 86 |
| | LINE. | 88 |

| | |
|--------------------------|-------|
| LWPOLYLINE | . 88 |
| MLINE. | . 89 |
| MTEXT | . 92 |
| OLEFRAME | . 93 |
| OLE2FRAME. | . 94 |
| POINT. | . 96 |
| POLYLINE | . 97 |
| Polyface Meshes. | . 98 |
| RAY | . 99 |
| REGION | . 99 |
| SEQEND | . 100 |
| SHAPE. | . 100 |
| SOLID | . 101 |
| SPLINE | . 102 |
| TEXT | . 103 |
| TOLERANCE. | . 105 |
| TRACE. | . 106 |
| VERTEX | . 107 |
| VIEWPORT | . 109 |
| XLINE. | . 113 |

| | | |
|------------------|--|--------------|
| Chapter 7 | OBJECTS Section | . 115 |
| | OBJECT Section Group Codes | . 116 |
| | Object Ownership | . 116 |
| | Common Group Codes for Objects | . 116 |
| | ACAD_PROXY_OBJECT | . 117 |
| | ACBBDICTIONARYWDFLT | . 118 |
| | ACDBPLACEHOLDER. | . 119 |
| | DICTIONARY | . 120 |
| | DICTIONARYVAR | . 121 |
| | DIMASSOC | . 122 |
| | GROUP | . 124 |
| | IDBUFFER | . 125 |
| | IMAGEDEF | . 125 |
| | IMAGEDEF_REACTOR. | . 126 |
| | LAYER_INDEX | . 127 |
| | LAYER_FILTER | . 128 |
| | LAYOUT | . 128 |
| | MLINESTYLE. | . 131 |
| | OBJECT_PTR. | . 132 |
| | PLOTSETTINGS | . 133 |
| | RASTERVARIABLES. | . 135 |
| | SPATIAL_INDEX | . 136 |
| | SPATIAL_FILTER | . 137 |

| | | |
|-------------------|--|------------|
| | SORTENTSTABLE. | 138 |
| | VBA_PROJECT | 139 |
| | XRECORD | 140 |
| Chapter 8 | THUMBNAILIMAGE Section | 143 |
| | THUMBNAILIMAGE Section Group Codes. | 144 |
| Appendix A | Drawing Interchange File Formats | 145 |
| | ASCII DXF Files | 146 |
| | General DXF File Structure | 146 |
| | Group Codes in DXF Files | 147 |
| | ASCII Control Characters in DXF Files | 147 |
| | Header Group Codes in DXF Files | 148 |
| | Class Group Codes in DXF Files | 148 |
| | Symbol Table Group Codes in DXF Files | 149 |
| | Symbol Table Example | 149 |
| | Blocks Group Codes in DXF Files | 152 |
| | Entity Group Codes in DXF Files | 153 |
| | Object Group Codes in DXF Files. | 153 |
| | Writing a DXF Interface Program. | 154 |
| | Reading a DXF File | 154 |
| | Writing a DXF File | 156 |
| | Binary DXF Files | 158 |
| | Slide Files | 159 |
| | Old Slide Header | 162 |
| | Slide Library Files. | 163 |
| Appendix B | Advanced DXF Issues | 165 |
| | Database Objects | 166 |
| | Persistent Inter-Object Reference Handles | 166 |
| | Pointer and Ownership References | 167 |
| | Hard and Soft References | 167 |
| | Arbitrary Handles. | 167 |
| | 1005 Group Codes | 168 |
| | Subclass Markers | 168 |
| | Extension Dictionary and Persistent Reactors | 170 |
| | Extended Data | 170 |
| | Object Coordinate Systems (OCS) | 173 |
| | Arbitrary Axis Algorithm | 175 |
| | Index | 177 |

Revisions to the DXF Reference

This topic lists the revisions to the DXF Reference from the last update to the DXF Reference. The version number of this DXF Reference is u16.1.01. Any updates to this reference will be available at *<http://www.autodesk.com/techpubs/autocad/dxf/>*.

In this chapter

- Objects Section

Objects Section

- New objects: [DIMASSOC](#).

DXF Format

1

The DXF™ format is a tagged data representation of all the information contained in an AutoCAD® drawing file. *Tagged data* means that each data element in the file is preceded by an integer number that is called a *group code*. A group code's value indicates what type of data element follows. This value also indicates the meaning of a data element for a given object (or record) type. Virtually all user-specified information in a drawing file can be represented in DXF format.

In this chapter

- Organization of This Reference
- Object and Entity Codes
- Group Code Value Types
- Group Codes in Numerical Order

Organization of This Reference

The *DXF Reference* presents the DXF™ group codes found in DXF files and encountered by AutoLISP® and ObjectARX™ applications. This chapter describes the general DXF conventions. The remaining chapters list the group codes organized by object type. The group codes are presented in the order they are found in a DXF file, and each chapter is named according to the associated section of a DXF file. Although the DXF file format is used as the organizing mechanism for this reference, specific information on the actual formatting of DXF files is found in appendix A, “[Drawing Interchange File Formats](#).” Advanced concepts relating to DXF group codes as they pertain to both applications and DXF files is found in appendix B, “[Advanced DXF Issues](#).”

For descriptions of the AutoLISP functions that use group codes, see chapter 10, “Using AutoLISP to Manipulate AutoCAD Objects,” in the *Visual LISP Developer's Guide*.

Formatting Conventions in This Reference

Each group code listed in this reference is presented by a numeric group code value and a description. All group codes can apply to DXF™ files, applications (AutoLISP or ObjectARX), or both. When the description of a code is different for applications and DXF files (or only applies to one or the other), the description is preceded by the following indicators:

APP Application-specific description

DXF DXF file-specific description

If the description is common to both DXF files and applications, no indicator is provided.

Optional codes are indicated as “optional” in the description.

Object and Entity Codes

In the DXF™ format, the definition of objects differs from entities: objects have no graphical representation and entities do. For example, dictionaries are objects not entities. Entities are also referred to as *graphical objects* while objects are referred to as *nongraphical objects*.

Entities appear in both the BLOCK and ENTITIES sections of the DXF file. The use of group codes in the two sections is identical.

Some group codes that define an entity always appear; others are optional and appear only if their values differ from the defaults.

Do not write programs that rely on the order given here. The end of an entity is indicated by the next 0 group, which begins the next entity or indicates the end of the section.

NOTE Accommodating DXF files from future releases of AutoCAD® will be easier if you write your DXF processing program in a table-driven way, ignore undefined group codes, and make no assumptions about the order of group codes in an entity. With each new AutoCAD release, new group codes will be added to entities to accommodate additional features.

Group Code Value Types

Group codes define the type of the associated value as an integer, a floating-point number, or a string, according to the following table of group code ranges. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Group code value types | |
|------------------------|---|
| Code range | Group value type |
| 0–9 | String (with the introduction of extended symbol names in AutoCAD 2000, the 255 character limit has been lifted. There is no explicit limit to the number of bytes per line, although most lines should fall within 2049 bytes) |
| 10–39 | Double precision 3D point |
| 40–59 | Double precision floating point value |
| 60–79 | 16-bit integer value |
| 90–99 | 32-bit integer value |
| 100 | String (255-character maximum; less for Unicode strings) |
| 102 | String (255-character maximum; less for Unicode strings) |

Group code value types (continued)

| Code range | Group value type |
|------------|---|
| 105 | String representing hexadecimal (hex) handle value |
| 110–119 | Double precision floating point value |
| 120–129 | Double precision floating point value |
| 130–139 | Double precision floating point value |
| 140–149 | Double precision scalar floating-point value |
| 170–179 | 16-bit integer value |
| 210–239 | Double precision floating point value |
| 270–279 | 16-bit integer value |
| 280–289 | 16-bit integer value |
| 290–299 | Boolean flag value |
| 300–309 | Arbitrary text string |
| 310–319 | String representing hex value of binary chunk |
| 320–329 | String representing hex handle value |
| 330–369 | String representing hex object IDs |
| 370–379 | 16-bit integer value |
| 380–389 | 16-bit integer value |
| 390–399 | String representing hex handle value |
| 400–409 | 16-bit integer value |
| 410–419 | String |
| 999 | Comment (string) |
| 1000–1009 | String (same limits as indicated with 0–9 code range) |
| 1010–1059 | Double precision floating point value |
| 1060–1070 | 16-bit integer value |

Group code value types (*continued*)

| Code range | Group value type |
|------------|----------------------|
| 1071 | 32-bit integer value |

Group Codes in Numerical Order

The following table gives the group code or group code range accompanied by an explanation of the group code value. In the table, “fixed” indicates that the group code always has the same purpose. If a group code isn’t fixed, its purpose depends on the context. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Group codes by number

| Group code | Description |
|------------|---|
| –5 | APP: persistent reactor chain |
| –4 | APP: conditional operator (used <i>only</i> with <code>ssget</code>) |
| –3 | APP: extended data (XDATA) sentinel (fixed) |
| –2 | APP: entity name reference (fixed) |
| –1 | APP: entity name. The name changes each time a drawing is opened. It is never saved (fixed) |
| 0 | Text string indicating the entity type (fixed) |
| 1 | Primary text value for an entity |
| 2 | Name (attribute tag, block name, and so on) |
| 3–4 | Other text or name values |
| 5 | Entity handle; text string of up to 16 hexadecimal digits (fixed) |
| 6 | Linetype name (fixed) |
| 7 | Text style name (fixed) |
| 8 | Layer name (fixed) |

Group codes by number (*continued*)

| Group code | Description |
|--------------|--|
| 9 | DXF: variable name identifier (used only in HEADER section of the DXF file) |
| 10 | Primary point; this is the start point of a line or text entity, center of a circle, and so on DXF: X value of the primary point (followed by Y and Z value codes 20 and 30) APP: 3D point (list of three reals) |
| 11–18 | Other points DXF: X value of other points (followed by Y value codes 21–28 and Z value codes 31–38) APP: 3D point (list of three reals) |
| 20, 30 | DXF TM : Y and Z values of the primary point |
| 21–28, 31–37 | DXF: Y and Z values of other points |
| 38 | DXF: entity's elevation if nonzero |
| 39 | Entity's thickness if nonzero (fixed) |
| 40–48 | Double precision floating point values (text height, scale factors, and so on) |
| 48 | Linetype scale; double precision floating point scalar value; default value is defined for all entity types |
| 49 | Repeated double precision floating point value. Multiple 49 groups may appear in one entity for variable-length tables (such as the dash lengths in the LTYPE table). A 7x group always appears <i>before</i> the first 49 group to specify the table length |
| 50–58 | Angles (output in degrees to DXF files and radians through AutoLISP and ObjectARX applications) |
| 60 | Entity visibility; integer value; absence or 0 indicates visibility; 1 indicates invisibility |
| 62 | Color number (fixed) |
| 66 | "Entities follow" flag (fixed) |
| 67 | Space—that is, model or paper space (fixed) |

Group codes by number (continued)

| Group code | Description |
|------------|--|
| 68 | APP: identifies whether viewport is on but fully off screen; is not active or is off |
| 69 | APP: viewport identification number |
| 70–78 | Integer values, such as repeat counts, flag bits, or modes |
| 90–99 | 32-bit integer values |
| 100 | Subclass data marker (with derived class name as a string). Required for all objects and entity classes that are derived from another concrete class. The subclass data marker segregates data defined by different classes in the inheritance chain for the same object. This is in addition to the requirement for DXF names for each distinct concrete class derived from ObjectARX (see “Subclass Markers” on page 168) |
| 102 | Control string, followed by “{<arbitrary name>” or “}”. Similar to the xdata 1002 group code, except that when the string begins with “{”, it can be followed by an arbitrary string whose interpretation is up to the application. The only other control string allowed is “}” as a group terminator. AutoCAD does not interpret these strings except during drawing audit operations. They are for application use |
| 105 | Object handle for DIMVAR symbol table entry |
| 110 | UCS origin (appears only if code 72 is set to 1) DXF: X value; APP: 3D point |
| 111 | UCS X-axis (appears only if code 72 is set to 1) DXF: X value; APP: 3D vector |
| 112 | UCS Y-axis (appears only if code 72 is set to 1) DXF: X value; APP: 3D vector |
| 120–122 | DXF: Y value of UCS origin, UCS X-axis, and UCS Y-axis |
| 130–132 | DXF: Z value of UCS origin, UCS X-axis, and UCS Y-axis |
| 140–149 | Double precision floating point values (points, elevation, and DIMSTYLE settings, for example) |
| 170–179 | 16-bit integer values, such as flag bits representing DIMSTYLE settings |
| 210 | Extrusion direction (fixed) DXF: X value of extrusion direction APP: 3D extrusion direction vector |

Group codes by number (*continued*)

| Group code | Description |
|------------|---|
| 220, 230 | DXF: Y and Z values of the extrusion direction |
| 270–279 | 16-bit integer values |
| 280–289 | 16-bit integer values |
| 290–299 | Boolean flag value |
| 300–309 | Arbitrary text strings |
| 310–319 | Arbitrary binary chunks with same representation and limits as 1004 group codes: hexadecimal strings of up to 254 characters represent data chunks of up to 127 bytes |
| 320–329 | Arbitrary object handles; handle values that are taken “as is.” They are not translated during INSERT and XREF operations |
| 330–339 | Soft-pointer handle; arbitrary soft pointers to other objects within same DXF file or drawing. Translated during INSERT and XREF operations |
| 340–349 | Hard-pointer handle; arbitrary hard pointers to other objects within same DXF file or drawing. Translated during INSERT and XREF operations |
| 350–359 | Soft-owner handle; arbitrary soft ownership links to other objects within same DXF file or drawing. Translated during INSERT and XREF operations |
| 360–369 | Hard-owner handle; arbitrary hard ownership links to other objects within same DXF file or drawing. Translated during INSERT and XREF operations |
| 370–379 | Lineweight enum value (AcDb::LineWeight). Stored and moved around as a 16-bit integer. Custom non-entity objects may use the full range, but entity classes only use 371–379 DXF group codes in their representation, because AutoCAD® and AutoLISP both always assume a 370 group code is the entity’s lineweight. This allows 370 to behave like other “common” entity fields |
| 380–389 | PlotStyleName type enum (AcDb::PlotStyleNameType). Stored and moved around as a 16-bit integer. Custom non-entity objects may use the full range, but entity classes only use 381–389 DXF group codes in their representation, for the same reason as the Lineweight range above |

Group codes by number (continued)

| Group code | Description |
|------------|--|
| 390–399 | String representing handle value of the PlotStyleName object, basically a hard pointer, but has a different range to make backward compatibility easier to deal with. Stored and moved around as an Object ID (a handle in DXF files) and a special type in AutoLISP. Custom non-entity objects may use the full range, but entity classes only use 391–399 DXF group codes in their representation, for the same reason as the Lineweight range above |
| 400–409 | 16-bit Integers |
| 410–419 | String |
| 999 | DXF: The 999 group code indicates that the line following it is a comment string. SAVEAS does not include such groups in a DXF output file, but OPEN honors them and ignores the comments. You can use the 999 group to include comments in a DXF file that you’ve edited |
| 1000 | ASCII string (up to 255 bytes long) in extended data |
| 1001 | Registered application name (ASCII string up to 31 bytes long) for extended data |
| 1002 | Extended data control string (“{” or “}”) |
| 1003 | Extended data layer name |
| 1004 | Chunk of bytes (up to 127 bytes long) in extended data |
| 1005 | Entity handle in extended data; text string of up to 16 hexadecimal digits |
| 1010 | A point in extended data DXF: X value (followed by 1020 and 1030 groups) APP: 3D point |
| 1020, 1030 | DXF: Y and Z values of a point |
| 1011 | A 3D world space position in extended data DXF: X value (followed by 1021 and 1031 groups) APP: 3D point |
| 1021, 1031 | DXF: Y and Z values of a world space position |
| 1012 | A 3D world space displacement in extended data DXF: X value (followed by 1022 and 1032 groups) APP: 3D vector |

Group codes by number (*continued*)

| Group code | Description |
|------------|--|
| 1022, 1032 | DXF: Y and Z values of a world space displacement |
| 1013 | A 3D world space direction in extended data DXF: X value (followed by 1022 and 1032 groups) APP: 3D vector |
| 1023, 1033 | DXF: Y and Z values of a world space direction |
| 1040 | Extended data double precision floating point value |
| 1041 | Extended data distance value |
| 1042 | Extended data scale factor |
| 1070 | Extended data 16-bit signed integer |
| 1071 | Extended data 32-bit signed long |

HEADER Section

2

The group codes described in this chapter pertain only to DXF™ files. The HEADER section of a DXF file contains the settings of variables associated with the drawing. Each variable is specified by a 9 group code giving the variable's name, followed by groups that supply the variable's value. This chapter lists only the variables that are saved in the drawing file.

In this chapter

- HEADER Section Group Codes

HEADER Section Group Codes

The following table lists the variables that are saved in a DXF™ file. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| DXF system variables | | |
|----------------------|------------|--|
| Variable | Group code | Description |
| \$ACADMAINTVER | 70 | Maintenance version number (should be ignored) |
| \$ACADVER | 1 | The AutoCAD® drawing database version number: AC1006 = R10, AC1009 = R11 and R12, AC1012 = R13, AC1014 = R14, AC1015 = AutoCAD 2000 |
| \$ANGBASE | 50 | Angle 0 direction |
| \$ANGDIR | 70 | 1 = Clockwise angles, 0 = Counterclockwise |
| \$ATTMODE | 70 | Attribute visibility: 0 = None, 1 = Normal, 2 = All |
| \$AUNITS | 70 | Units format for angles |
| \$AUPREC | 70 | Units precision for angles |
| \$CECOLOR | 62 | Current entity color number: 0 = BYBLOCK, 256 = BYLAYER |
| \$CELTSCALE | 40 | Current entity linetype scale |
| \$CELTYPE | 6 | Entity linetype name, or BYBLOCK or BYLAYER |
| \$CELWEIGHT | 370 | Lineweight of new objects |
| \$CPSNID | 390 | Plotstyle handle of new objects. If CEPSNTYPE is 3, then this value indicates the handle |
| \$CEPSNTYPE | 380 | Plotstyle type of new objects: 0 = PlotStyle by layer 1 = PlotStyle by block 2 = PlotStyle by dictionary default 3 = PlotStyle by object ID/handle |
| \$CHAMFERA | 40 | First chamfer distance |
| \$CHAMFERB | 40 | Second chamfer distance |

DXF system variables (continued)

| Variable | Group code | Description |
|-------------|------------|--|
| \$CHAMFERC | 40 | Chamfer length |
| \$CHAMFERD | 40 | Chamfer angle |
| \$CLAYER | 8 | Current layer name |
| \$CMLJUST | 70 | Current multiline justification: 0 = Top, 1 = Middle, 2 = Bottom |
| \$CMLSCALE | 40 | Current multiline scale |
| \$CMLSTYLE | 2 | Current multiline style name |
| \$DIMADEC | 70 | Number of precision places displayed in angular dimensions |
| \$DIMALT | 70 | Alternate unit dimensioning performed if nonzero |
| \$DIMALTD | 70 | Alternate unit decimal places |
| \$DIMALTF | 40 | Alternate unit scale factor |
| \$DIMALTRND | 40 | Determines rounding of alternate units |
| \$DIMALTTD | 70 | Number of decimal places for tolerance values of an alternate units dimension |
| \$DIMALTTZ | 70 | Controls suppression of zeros for alternate tolerance values: 0 = Suppresses zero feet and precisely zero inches 1 = Includes zero feet and precisely zero inches 2 = Includes zero feet and suppresses zero inches 3 = Includes zero inches and suppresses zero feet |
| \$DIMALTU | 70 | Units format for alternate units of all dimension style family members except angular: 1 = Scientific; 2 = Decimal; 3 = Engineering; 4 = Architectural (stacked); 5 = Fractional (stacked); 6 = Architectural; 7 = Fractional |
| \$DIMALTZ | 70 | Controls suppression of zeros for alternate unit dimension values: 0 = Suppresses zero feet and precisely zero inches 1 = Includes zero feet and precisely zero inches 2 = Includes zero feet and suppresses zero inches 3 = Includes zero inches and suppresses zero feet |
| \$DIMAPOST | 1 | Alternate dimensioning suffix |

DXF system variables (continued)

| Variable | Group code | Description |
|------------|------------|--|
| \$DIMASO | 70 | 1 = Create associative dimensioning 0 = Draw individual entities |
| \$DIMASZ | 40 | Dimensioning arrow size |
| \$DIMATFIT | 70 | Controls dimension text and arrow placement when space is not sufficient to place both within the extension lines: 0 = Places both text and arrows outside extension lines 1 = Moves arrows first, then text 2 = Moves text first, then arrows 3 = Moves either text or arrows, whichever fits best AutoCAD adds a leader to moved dimension text when DIMTMOVE is set to 1 |
| \$DIMAUNIT | 70 | Angle format for angular dimensions: 0 = Decimal degrees, 1 = Degrees/minutes/seconds, 2 = Gradians, 3 = Radians, 4 = Surveyor's units |
| \$DIMAZIN | 70 | Controls suppression of zeros for angular dimensions: 0 = Displays all leading and trailing zeros 1 = Suppresses leading zeros in decimal dimensions 2 = Suppresses trailing zeros in decimal dimensions 3 = Suppresses leading and trailing zeros |
| \$DIMBLK | 1 | Arrow block name |
| \$DIMBLK1 | 1 | First arrow block name |
| \$DIMBLK2 | 1 | Second arrow block name |
| \$DIMCEN | 40 | Size of center mark/lines |
| \$DIMCLRD | 70 | Dimension line color: range is 0 = BYBLOCK, 256 = BYLAYER |
| \$DIMCLRE | 70 | Dimension extension line color: range is 0 = BYBLOCK, 256 = BYLAYER |
| \$DIMCLRT | 70 | Dimension text color: range is 0 = BYBLOCK, 256 = BYLAYER |
| \$DIMDEC | 70 | Number of decimal places for the tolerance values of a primary units dimension |
| \$DIMDLE | 40 | Dimension line extension |
| \$DIMDLI | 40 | Dimension line increment |

DXF system variables (continued)

| Variable | Group code | Description |
|-------------|------------|--|
| \$DIMDSEP | 70 | Single-character decimal separator used when creating dimensions whose unit format is decimal |
| \$DIMEXE | 40 | Extension line extension |
| \$DIMEXO | 40 | Extension line offset |
| \$DIMFAC | 40 | Scale factor used to calculate the height of text for dimension fractions and tolerances. AutoCAD multiplies DIMTXT by DIMTFAC to set the fractional or tolerance text height |
| \$DIMGAP | 40 | Dimension line gap |
| \$DIMJUST | 70 | Horizontal dimension text position: 0 = Above dimension line and center-justified between extension lines 1 = Above dimension line and next to first extension line 2 = Above dimension line and next to second extension line 3 = Above and center-justified to first extension line 4 = Above and center-justified to second extension line |
| \$DIMLDRBLK | 1 | Arrow block name for leaders |
| \$DIMLFAC | 40 | Linear measurements scale factor |
| \$DIMLIM | 70 | Dimension limits generated if nonzero |
| \$DIMLUNIT | 70 | Sets units for all dimension types except Angular: 1 = Scientific; 2 = Decimal; 3 = Engineering; 4 = Architectural; 5 = Fractional; 6 = Windows desktop |
| \$DIMLWD | 70 | Dimension line lineweight: -3 = Standard -2 = ByLayer -1 = ByBlock 0-211 = an integer representing 100th of mm |
| \$DIMLWE | 70 | Extension line lineweight: -3 = Standard -2 = ByLayer -1 = ByBlock 0-211 = an integer representing 100th of mm |
| \$DIMPOST | 1 | General dimensioning suffix |
| \$DIMRND | 40 | Rounding value for dimension distances |
| \$DIMSAH | 70 | Use separate arrow blocks if nonzero |

DXF system variables (continued)

| Variable | Group code | Description |
|-------------|------------|---|
| \$DIMSCALE | 40 | Overall dimensioning scale factor |
| \$DIMSD1 | 70 | Suppression of first extension line: 0 = Not suppressed, 1 = Suppressed |
| \$DIMSD2 | 70 | Suppression of second extension line: 0 = Not suppressed, 1 = Suppressed |
| \$DIMSE1 | 70 | First extension line suppressed if nonzero |
| \$DIMSE2 | 70 | Second extension line suppressed if nonzero |
| \$DIMSHO | 70 | 1 = Recompute dimensions while dragging 0 = Drag original image |
| \$DIMSOXD | 70 | Suppress outside-extensions dimension lines if nonzero |
| \$DIMSTYLE | 2 | Dimension style name |
| \$DIMITAD | 70 | Text above dimension line if nonzero |
| \$DIMITDEC | 70 | Number of decimal places to display the tolerance values |
| \$DIMITFAC | 40 | Dimension tolerance display scale factor |
| \$DIMITIH | 70 | Text inside horizontal if nonzero |
| \$DIMITIX | 70 | Force text inside extensions if nonzero |
| \$DIMITM | 40 | Minus tolerance |
| \$DIMITMOVE | 70 | Dimension text movement rules: 0 = Moves the dimension line with dimension text 1 = Adds a leader when dimension text is moved 2 = Allows text to be moved freely without a leader |
| \$DIMITOFL | 70 | If text is outside extensions, force line extensions between extensions if nonzero |
| \$DIMITOH | 70 | Text outside horizontal if nonzero |
| \$DIMITOL | 70 | Dimension tolerances generated if nonzero |
| \$DIMITOLJ | 70 | Vertical justification for tolerance values: 0 = Top, 1 = Middle, 2 = Bottom |

DXF system variables (continued)

| Variable | Group code | Description |
|---------------|------------|--|
| \$DIMTP | 40 | Plus tolerance |
| \$DIMTSZ | 40 | Dimensioning tick size: 0 = No ticks |
| \$DIMTVP | 40 | Text vertical position |
| \$DIMTXSTY | 7 | Dimension text style |
| \$DIMTXT | 40 | Dimensioning text height |
| \$DIMTZIN | 70 | Controls suppression of zeros for tolerance values: 0 = Suppresses zero feet and precisely zero inches 1 = Includes zero feet and precisely zero inches 2 = Includes zero feet and suppresses zero inches 3 = Includes zero inches and suppresses zero feet |
| \$DIMUPT | 70 | Cursor functionality for user positioned text: 0 = Controls only the dimension line location 1 = Controls the text position as well as the dimension line location |
| \$DIMZIN | 70 | Controls suppression of zeros for primary unit values: 0 = Suppresses zero feet and precisely zero inches 1 = Includes zero feet and precisely zero inches 2 = Includes zero feet and suppresses zero inches 3 = Includes zero inches and suppresses zero feet |
| \$DISPSILH | 70 | Controls the display of silhouette curves of body objects in Wire-frame mode: 0 = Off, 1 = On |
| \$DWGCODEPAGE | 3 | Drawing code page; Set to the system code page when a new drawing is created, but not otherwise maintained by AutoCAD |
| \$ELEVATION | 40 | Current elevation set by ELEV command |
| \$ENDCAPS | 280 | Lineweight endcaps setting for new objects: 0 = none; 1 = round; 2=angle; 3=square |
| \$EXTMAX | 10, 20, 30 | X, Y, and Z drawing extents upper-right corner (in WCS) |
| \$EXTMIN | 10, 20, 30 | X, Y, and Z drawing extents lower-left corner (in WCS) |

DXF system variables (continued)

| Variable | Group code | Description |
|-------------------|------------|---|
| \$EXTNAMES | 290 | Controls symbol table naming: 0 = Release 14 compatibility. Limits names to 31 characters in length. Names can include the letters A to Z, the numerals 0 to 9, and the special characters, dollar sign (\$), underscore (_), and hyphen (-). 1 = AutoCAD 2000. Names can be up to 255 characters in length, and can include the letters A to Z, the numerals 0 to 9, spaces, and any special characters not used by Microsoft Windows and AutoCAD for other purposes |
| \$FILLETRAD | 40 | Fillet radius |
| \$FILLMODE | 70 | Fill mode on if nonzero |
| \$FINGERPRINTGUID | 2 | Set at creation time, uniquely identifies a particular drawing |
| \$HANDSEED | 5 | Next available handle |
| \$HYPERLINKBASE | 1 | Path for all relative hyperlinks in the drawing. If null, the drawing path is used |
| \$INSBASE | 10, 20, 30 | Insertion base set by BASE command (in WCS) |
| \$INSUNITS | 70 | Default drawing units for AutoCAD DesignCenter blocks: 0 = Unitless; 1 = Inches; 2 = Feet; 3 = Miles; 4 = Millimeters; 5 = Centimeters; 6 = Meters; 7 = Kilometers; 8 = Microinches; 9 = Mils; 10 = Yards; 11 = Angstroms; 12 = Nanometers; 13 = Microns; 14 = Decimeters; 15 = Decameters; 16 = Hectometers; 17 = Gigameters; 18 = Astronomical units; 19 = Light years; 20 = Parsecs |
| \$JOINSTYLE | 280 | Lineweight joint setting for new objects: 0=none; 1 = round; 2 = angle; 3 = flat |
| \$LIMCHECK | 70 | Nonzero if limits checking is on |
| \$LIMMAX | 10, 20 | XY drawing limits upper-right corner (in WCS) |
| \$LIMMIN | 10, 20 | XY drawing limits lower-left corner (in WCS) |
| \$LTSCALE | 40 | Global linetype scale |
| \$LUNITS | 70 | Units format for coordinates and distances |
| \$LUPREC | 70 | Units precision for coordinates and distances |

DXF system variables (continued)

| Variable | Group code | Description |
|-----------------|------------|--|
| \$LWDISPLAY | 290 | Controls the display of lineweights on the Model or Layout tab: 0 = Lineweight is not displayed 1 = Lineweight is displayed |
| \$MAXACTVP | 70 | Sets maximum number of viewports to be regenerated |
| \$MEASUREMENT | 70 | Sets drawing units: 0 = English; 1 = Metric |
| \$MENU | 1 | Name of menu file |
| \$MIRRTEXT | 70 | Mirror text if nonzero |
| \$ORTHOMODE | 70 | Ortho mode on if nonzero |
| \$PDMODE | 70 | Point Display mode |
| \$PDSIZE | 40 | Point display size |
| \$PELEVATION | 40 | Current paper space elevation |
| \$PEXTMAX | 10, 20, 30 | Maximum X, Y, and Z extents for paper space |
| \$PEXTMIN | 10, 20, 30 | Minimum X, Y, and Z extents for paper space |
| \$PINSBASE | 10, 20, 30 | Paper space insertion base point |
| \$PLIMCHECK | 70 | Limits checking in paper space when nonzero |
| \$PLIMMAX | 10, 20 | Maximum X and Y limits in paper space |
| \$PLIMMIN | 10, 20 | Minimum X and Y limits in paper space |
| \$PLINEGEN | 70 | Governs the generation of linetype patterns around the vertices of a 2D polyline: 1 = Linetype is generated in a continuous pattern around vertices of the polyline 0 = Each segment of the polyline starts and ends with a dash |
| \$PLINEWID | 40 | Default polyline width |
| \$PROXYGRAPHICS | 70 | Controls the saving of proxy object images |
| \$PSLTSCALE | 70 | Controls paper space linetype scaling: 1 = No special linetype scaling 0 = Viewport scaling governs linetype scaling |

DXF system variables (continued)

| Variable | Group code | Description |
|-----------------|------------|---|
| \$PSTYLEMODE | 290 | Indicates whether the current drawing is in a Color-Dependent or Named Plot Style mode: 0 = Uses color-dependent plot style tables in the current drawing 1 = Uses named plot style tables in the current drawing |
| \$PSVPSCALE | 40 | View scale factor for new viewports: 0 = Scaled to fit >0 = Scale factor (a positive real value) |
| \$PUCSBASE | 2 | Name of the UCS that defines the origin and orientation of orthographic UCS settings (paper space only) |
| \$PUCSNAME | 2 | Current paper space UCS name |
| \$PUCSORG | 10, 20, 30 | Current paper space UCS origin |
| \$PUCSORGBACK | 10, 20, 30 | Point which becomes the new UCS origin after changing paper space UCS to 'BACK' when PUCSBASE is set to WORLD |
| \$PUCSORGBOTTOM | 10, 20, 30 | Point which becomes the new UCS origin after changing paper space UCS to 'BOTTOM' when PUCSBASE is set to WORLD |
| \$PUCSORGFRONT | 10, 20, 30 | Point which becomes the new UCS origin after changing paper space UCS to 'FRONT' when PUCSBASE is set to WORLD |
| \$PUCSORGLEFT | 10, 20, 30 | Point which becomes the new UCS origin after changing paper space UCS to 'LEFT' when PUCSBASE is set to WORLD |
| \$PUCSORGRIGHT | 10, 20, 30 | Point which becomes the new UCS origin after changing paper space UCS to 'RIGHT' when PUCSBASE is set to WORLD |
| \$PUCSORGTOP | 10, 20, 30 | Point which becomes the new UCS origin after changing paper space UCS to 'TOP' when PUCSBASE is set to WORLD |
| \$PUCSORTHOREF | 2 | If paper space UCS is orthographic (PUCSORTHOVIEW not equal to 0), this is the name of the UCS that the orthographic UCS is relative to. If blank, UCS is relative to WORLD |
| \$PUCSORTHOVIEW | 70 | Orthographic view type of paper space UCS: 0 = UCS is not orthographic; 1 = Top; 2 = Bottom; 3 = Front; 4 = Back; 5 = Left; 6 = Right |
| \$PUCSXDIR | 10, 20, 30 | Current paper space UCS X axis |
| \$PUCSYDIR | 10, 20, 30 | Current paper space UCS Y axis |

DXF system variables (continued)

| Variable | Group code | Description |
|--------------|------------|---|
| \$QTEXTMODE | 70 | Quick Text mode on if nonzero |
| \$REGENMODE | 70 | REGENAUTO mode on if nonzero |
| \$SHADEGE | 70 | 0 = Faces shaded, edges not highlighted 1 = Faces shaded, edges highlighted in black 2 = Faces not filled, edges in entity color 3 = Faces in entity color, edges in black |
| \$SHADEDIF | 70 | Percent ambient/diffuse light, range 1–100, default 70 |
| \$SKETCHINC | 40 | Sketch record increment |
| \$SKPOLY | 70 | 0 = Sketch lines, 1 = Sketch polylines |
| \$SPLFRAME | 70 | Spline control polygon display: 1 = On, 0 = Off |
| \$SPLINESEGS | 70 | Number of line segments per spline patch |
| \$SPLINETYPE | 70 | Spline curve type for PEDIT Spline |
| \$SURFTAB1 | 70 | Number of mesh tabulations in first direction |
| \$SURFTAB2 | 70 | Number of mesh tabulations in second direction |
| \$SURFTYPE | 70 | Surface type for PEDIT Smooth |
| \$SURFU | 70 | Surface density (for PEDIT Smooth) in M direction |
| \$SURFV | 70 | Surface density (for PEDIT Smooth) in N direction |
| \$TDCREATE | 40 | Local date/time of drawing creation (see “Special Handling of Date/Time Variables”) |
| \$TDINDWG | 40 | Cumulative editing time for this drawing (see “Special Handling of Date/Time Variables”) |
| \$TDUCREATE | 40 | Universal date/time the drawing was created (see “Special Handling of Date/Time Variables”) |
| \$TDUPDATE | 40 | Local date/time of last drawing update (see “Special Handling of Date/Time Variables”) |
| \$TDUSRTIMER | 40 | User-elapsed timer |

DXF system variables (continued)

| Variable | Group code | Description |
|----------------|------------|---|
| \$TDUUPDATE | 40 | Universal date/time of the last update/save (see “Special Handling of Date/Time Variables”) |
| \$TEXTSIZE | 40 | Default text height |
| \$TEXTSTYLE | 7 | Current text style name |
| \$THICKNESS | 40 | Current thickness set by ELEV command |
| \$TILEMODE | 70 | 1 for previous release compatibility mode, 0 otherwise |
| \$TRACEWID | 40 | Default trace width |
| \$TREEDEPTH | 70 | Specifies the maximum depth of the spatial index |
| \$UCSBASE | 2 | Name of the UCS that defines the origin and orientation of orthographic UCS settings |
| \$UCSNAME | 2 | Name of current UCS |
| \$UCSORG | 10, 20, 30 | Origin of current UCS (in WCS) |
| \$UCSORGBACK | 10, 20, 30 | Point which becomes the new UCS origin after changing model space UCS to ‘BACK’ when UCSBASE is set to WORLD |
| \$UCSORGBOTTOM | 10, 20, 30 | Point which becomes the new UCS origin after changing model space UCS to ‘BOTTOM’ when UCSBASE is set to WORLD |
| \$UCSORGFRONT | 10, 20, 30 | Point which becomes the new UCS origin after changing model space UCS to ‘FRONT’ when UCSBASE is set to WORLD |
| \$UCSORGLEFT | 10, 20, 30 | Point which becomes the new UCS origin after changing model space UCS to ‘LEFT’ when UCSBASE is set to WORLD |
| \$UCSORGRIGHT | 10, 20, 30 | Point which becomes the new UCS origin after changing model space UCS to ‘RIGHT’ when UCSBASE is set to WORLD |
| \$UCSORGTOP | 10, 20, 30 | Point which becomes the new UCS origin after changing model space UCS to ‘TOP’ when UCSBASE is set to WORLD |
| \$UCSORTHOREF | 2 | If model space UCS is orthographic (UCSORTHORVIEW not equal to 0), this is the name of the UCS that the orthographic UCS is relative to. If blank, UCS is relative to WORLD |

DXF system variables (continued)

| Variable | Group code | Description |
|----------------|------------|---|
| \$UCSORTHOVIEW | 70 | Orthographic view type of model space UCS: 0 = UCS is not orthographic; 1 = Top; 2 = Bottom; 3 = Front; 4 = Back; 5 = Left; 6 = Right |
| \$UCSXDIR | 10, 20, 30 | Direction of the current UCS X axis (in WCS) |
| \$UCSYDIR | 10, 20, 30 | Direction of the current UCS Y axis (in WCS) |
| \$UNITMODE | 70 | Low bit set = Display fractions, feet-and-inches, and surveyor's angles in input format |
| \$USERI1 – 5 | 70 | Five integer variables intended for use by third-party developers |
| \$USERR1 – 5 | 40 | Five real variables intended for use by third-party developers |
| \$USRTIMER | 70 | 0 = Timer off, 1 = Timer on |
| \$VERSIONGUID | 2 | Uniquely identifies a particular version of a drawing. Updated when the drawing is modified |
| \$VISRETAIN | 70 | 0 = Don't retain xref-dependent visibility settings 1 = Retain xref-dependent visibility settings |
| \$WORLDVIEW | 70 | 1 = Set UCS to WCS during DVIEW/VPOINT 0 = Don't change UCS |
| \$XEDIT | 290 | Controls whether the current drawing can be edited in-place when being referenced by another drawing. 0 = Can't use in-place reference editing 1 = Can use in-place reference editing |

Revised VPORT Header Variables

The following header variables existed before AutoCAD® Release 11 but now have independent settings for each active viewport. OPEN honors these variables when read from DXF™ files. If a VPORT symbol table with *ACTIVE entries is present (as is true for any DXF file produced by Release 11 or later),

the values in the VPORT table entries override the values of these header variables.

Revised VPORT header variables

| Variable | Group code | Description |
|---------------|------------|--|
| \$FASTZOOM | 70 | Fast zoom enabled if nonzero |
| \$GRIDMODE | 70 | Grid mode on if nonzero |
| \$GRIDUNIT | 10, 20 | Grid <i>X</i> and <i>Y</i> spacing |
| \$SNAPANG | 50 | Snap grid rotation angle |
| \$SNAPBASE | 10, 20 | Snap/grid base point (in UCS) |
| \$SNAPISOPAIR | 70 | Isometric plane: 0 = Left, 1 = Top, 2 = Right |
| \$SNAPMODE | 70 | Snap mode on if nonzero |
| \$SNAPSTYLE | 70 | Snap style: 0 = Standard, 1 = Isometric |
| \$SNAPUNIT | 10, 20 | Snap grid <i>X</i> and <i>Y</i> spacing |
| \$VIEWCTR | 10, 20 | <i>XY</i> center of current view on screen |
| \$VIEWDIR | 10, 20, 30 | Viewing direction (direction from target in WCS) |
| \$VIEWSIZE | 40 | Height of view |

Special Handling of Date/Time Variables

The CDATE and DATE system variables provide access to the current date and time. The TDCREATE, TDINDWG, TDUPDATE, and TDUSRTIMER system variables (and the \$TDCREATE, \$TDUCREATE, \$TDUPDATE, and \$TDUUPDATE DXF header variables) provide access to times and dates associated with the current drawing. The values are represented as real numbers with special meanings, as described below.

DATE is the current date and time represented as a Julian date and fraction of a day in a real number.

<Julian date>.<Fraction of day>

For example, on December 31, 1999, at 9:58:35 p.m. GMT, the DATE variable contains

2451544.91568287

The date and time are taken from the computer's clock when the variable is read. The time is represented as a fraction of a day, so the times returned by DATE may be truly subtracted to compute differences in time. To extract the seconds since midnight from the value returned by DATE, use the AutoLISP expressions:

```
(setq s (getvar "DATE"))  
(setq seconds (* 86400.0 (- s (fix s))))
```

Note that DATE only returns a true Julian date if the system's clock is set to UTC/Zulu (Greenwich Mean Time). TDCREATE and TDUPDATE have the same format as DATE, but their values represent the creation time and last update time of the current drawing.

TDINDWG and TDUSRTIMER (and the \$TDINDWG and \$TDUSRTIMER DXF header variables) use a format similar to that of DATE, but their values represent elapsed times, as in:

<Number of days>.<Fraction of day>

CDATE is the current date and time in calendar and clock format. The value is returned as a real number in the form:

YYYYMMDD.HHMMSShsec

where:

YYYY = year

MM = month (01-12)

DD = day (01-31)

HH = hours (00-23)

MM = minutes (00-59)

SS = seconds (00-59)

hsec = hundredths of a second (00-99)

For example, if the current date is December 31, 1999, and the time is 9:58:35.75 p.m., CDATE would return the value:

19991231.21583575

Note that CDATE values can be compared for later and earlier values but that subtracting them yields numbers that are not meaningful.

CLASSES Section

3

The group codes described in this chapter are found only in DXF™ files. The CLASSES section holds the information for application-defined classes whose instances appear in the BLOCKS, ENTITIES, and OBJECTS sections of the database. It is assumed that a class definition is permanently fixed in the class hierarchy. All fields are required.

In this chapter

- CLASSES Section Group Codes

CLASSES Section Group Codes

Each entry in the CLASSES section contains the groups described in the following table.

| CLASSES section group codes | |
|-----------------------------|---|
| Group code | Description |
| 0 | Record type (CLASS). Identifies beginning of a CLASS record |
| 1 | Class DXF record name; always unique |
| 2 | C++ class name. Used to bind with software that defines object class behavior; always unique |
| 3 | Application name. Posted in Alert box when a class definition listed in this section is not currently loaded |
| 90 | Proxy capabilities flag. Bit-coded value that indicates the capabilities of this object as a proxy: 0 = No operations allowed (0) 1 = Erase allowed (0x1) 2 = Transform allowed (0x2) 4 = Color change allowed (0x4) 8 = Layer change allowed (0x8) 16 = Linetype change allowed (0x10) 32 = Linetype scale change allowed (0x20) 64 = Visibility change allowed (0x40) 128 = Cloning allowed (0x80) 256 = Lineweight change allowed (0x100) 512 = Plot Style Name change allowed (0x200) 895 = All operations except cloning allowed (0x37F) 1023 = All operations allowed (0x3FF) 32768 = R13 format proxy (0x8000) |
| 280 | Was-a-proxy flag. Set to 1 if class was not loaded when this DXF file was created, and 0 otherwise |
| 281 | Is-an-entity flag. Set to 1 if class was derived from the AcDbEntity class and can reside in the BLOCKS or ENTITIES section. If 0, instances may appear only in the OBJECTS section |

Default Class Values

AutoCAD registers the classes listed in the following table. (This may not be a complete list of the classes found in a DXF file. It depends on the applications currently in use by AutoCAD®.)

| Default class values | | | | |
|---------------------------|---------------------------|------------|-------------|-------------|
| DXF record name code 1 | C++ class name code 2 | Code 90 | Code 280 | Code 281 |
| ACDBDICTIONARYWDFLT | AcDbDictionaryWithDefault | 0 | 0 | 0 |
| ACDBPLACEHOLDER | AcDbPlaceholder | 0 | 0 | 0 |
| ARCALIGNEDTEXT | AcDbArcAlignedText | 0 | 0 | 1 |
| DICTIONARYVAR | AcDbDictionaryVar | 0 | 0 | 0 |
| HATCH | AcDbHatch | 0 | 0 | 1 |
| IDBUFFER | AcDbIdBuffer | 0 | 0 | 0 |
| IMAGE | AcDbRasterImage | 127 | 0 | 1 |
| IMAGEDEF | AcDbRasterImageDef | 0 | 0 | 0 |
| IMAGEDEF_REACTOR | AcDbRasterImageDefReactor | 1 | 0 | 0 |
| LAYER_INDEX | AcDbLayerIndex | 0 | 0 | 0 |
| LAYOUT | AcDbLayout | 0 | 0 | 0 |
| LWPOLYLINE | AcDbPolyline | 0 | 0 | 1 |
| OBJECT_PTR | CAsDLPNTableRecord | 1 | 0 | 0 |
| OLE2FRAME | AcDbOle2Frame | 0 | 0 | 1 |
| PLOTSETTINGS | AcDbPlotSettings | 0 | 0 | 0 |
| RASTERVARIABLES | AcDbRasterVariables | 0 | 0 | 0 |
| RTEXT | RText | 0 | 0 | 1 |

Default class values (*continued*)

| DXF record name code 1 | C++ class name code 2 | Code 90 | Code 280 | Code 281 |
|---------------------------|--------------------------|------------|-------------|-------------|
| SORTENTSTABLE | AcDbSortentsTable | 0 | 0 | 0 |
| SPATIAL_INDEX | AcDbSpatialIndex | 0 | 0 | 0 |
| SPATIAL_FILTER | AcDbSpatialFilter | 0 | 0 | 0 |
| WIPEOUT | AcDbWipeout | 127 | 0 | 1 |
| WIPEOUTVARIABLES | AcDbWipeoutVariables | 0 | 0 | 0 |

TABLES Section

4

The group codes described in this chapter are found in DXF™ files and used by applications. The TABLES section contains several tables, each of which can contain a variable number of entries. These codes are also used by AutoLISP® and ObjectARX™ applications in entity definition lists.

In this chapter

- Symbol Table Group Codes
- Common Symbol Table Group Codes
- APPID
- BLOCK_RECORD
- DIMSTYLE
- LAYER
- LTYPE
- STYLE
- UCS
- VIEW
- VPORT

Symbol Table Group Codes

The order of the tables may change, but the LTYPE table always precedes the LAYER table. Each table is introduced with a 0 group code with the label TABLE. This is followed by a 2 group code identifying the particular table (APPID, DIMSTYLE, LAYER, LTYPE, STYLE, UCS, VIEW, VPORT, or BLOCK_RECORD), a 5 group code (a handle), a 100 group code (AcDbSymbolTable subclass marker), and a 70 group code that specifies the maximum number of table entries that may follow. Table names are output in uppercase characters. The DIMSTYLE handle is a 105 group code not a 5 group code.

The tables in a drawing can contain deleted items, but these are not written to the DXF file. As a result, fewer table entries may follow the table header than are indicated by the 70 group code, so do not use the count in the 70 group code as an index to read in the table. This group code is provided so that a program that reads DXF files can allocate an array large enough to hold all the table entries that follow.

Following this header for each table are the table entries. Each table entry consists of a 0 group identifying the item type (same as table name, such as LTYPE or LAYER), a 2 group giving the name of the table entry, a 70 group specifying flags relevant to the table entry (defined for each following table), and additional groups that give the value of the table entry. The end of each table is indicated by a 0 group with the value ENDTAB.

Both symbol table records and symbol tables are database objects. At a very minimum, with all prevailing usage within AutoCAD®, this implies that a handle is present, positioned after the 2 group codes for both the symbol table record objects and the symbol table objects.

The DIMSTYLE table is the only record type in the system with a handle code of 105 because of its earlier usage of group code 5. As a rule, programmers should not be concerned about this exception unless it is in the context of the DIMSTYLE table section. This is the only context in which this exception should occur.

Common Symbol Table Group Codes

The following table shows group codes that apply to all symbol tables. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Group codes that apply to all symbol tables

| Group code | Description |
|------------|--|
| -1 | APP: entity name (changes each time a drawing is opened) |
| 0 | Object type (TABLE) |
| 2 | Table name |
| 5 | Handle |
| 102 | "{ACAD_XDICTIONARY" indicates the start of an extension dictionary group. This group exists only if persistent reactors have been attached to this object (optional) |
| 360 | Hard owner ID/handle to owner dictionary (optional) |
| 102 | End of group, "}" (optional) |
| 330 | Soft-pointer ID/handle to owner object |
| 100 | Subclass marker (AcDbSymbolTable) |
| 70 | Maximum number of entries in table |

Common Group Codes for Symbol Table Entries

The following table shows group codes that apply to all symbol table entries. When you refer to the table of group codes by entity type, which lists the codes associated with specific entities, keep in mind that the codes shown here can also be present. For information about abbreviations and formatting used in this table, see ["Formatting Conventions in This Reference" on page 6](#).

Group codes that apply to all symbol table entries

| Group code | Description |
|------------|--|
| -1 | APP: entity name (changes each time a drawing is opened) |
| 0 | Entity type (table name) |
| 5 | Handle (all except DIMSTYLE) |
| 105 | Handle (DIMSTYLE table only) |

Group codes that apply to all symbol table entries (*continued*)

| Group code | Description |
|----------------------------------|---|
| 102 | Start of application-defined group "{ <i>application_name</i> ". For example, "{ACAD_REACTORS" indicates the start of the AutoCAD persistent reactors group (optional) |
| <i>application-defined codes</i> | Codes and values within the 102 groups are application defined (optional) |
| 102 | End of group, "}" (optional) |
| 102 | "{ACAD_REACTORS" indicates the start of the AutoCAD persistent reactors group. This group exists only if persistent reactors have been attached to this object (optional) |
| 330 | Soft pointer ID/handle to owner dictionary (optional) |
| 102 | End of group, "}" (optional) |
| 102 | "{ACAD_XDICTIONARY" indicates the start of an extension dictionary group. This group exists only if persistent reactors have been attached to this object (optional) |
| 360 | Hard owner ID/handle to owner dictionary (optional) |
| 102 | End of group, "}" (optional) |
| 330 | Soft-pointer ID/handle to owner object |
| 100 | Subclass marker (AcDbSymbolTableRecord) |

APPID

The following group codes apply to APPID symbol table entries. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries” on page 37](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

APPID group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbRegAppTableRecord) |
| 2 | User-supplied (or application-supplied) application name (for extended data). These table entries maintain a set of names for all registered applications |
| 70 | Standard flag values (bit-coded values): 1 = If set, xdata associated with this APPID is not written when SAVEASR12 is performed 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD commands. It can be ignored by most programs that read DXF files and need not be set by programs that write DXF files) |

BLOCK_RECORD

The following group codes apply to BLOCK_RECORD symbol table entries. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries” on page 37](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

BLOCK_RECORD group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbBlockTableRecord) |
| 2 | Block name |
| 340 | Hard-pointer ID/handle to associated LAYOUT object |
| 310 | DXF: Binary data for bitmap preview (optional) |
| 1001 | Xdata application name “ACAD” (optional) |

BLOCK_RECORD group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 1000 | Xdata string data "DesignCenter Data" (optional) |
| 1002 | Begin xdata "{" (optional) |
| 1070 | Autodesk Design Center version number |
| 1070 | Insert units: 0 = Unitless; 1 = Inches; 2 = Feet; 3 = Miles; 4 = Millimeters; 5 = Centimeters; 6 = Meters; 7 = Kilometers; 8 = Microinches; 9 = Mils; 10 = Yards; 11 = Angstroms; 12 = Nanometers; 13 = Microns; 14 = Decimeters; 15 = Decameters; 16 = Hectometers; 17 = Gigameters; 18 = Astronomical units; 19 = Light years; 20 = Parsecs |
| 1002 | End xdata "}" |

DIMSTYLE

The following group codes apply to DIMSTYLE symbol table entries. The DIMSTYLE system variables are described in appendix B, "System Variables," in the *Command Reference*. In addition to the group codes described here, see ["Common Group Codes for Symbol Table Entries" on page 37](#). For information about abbreviations and formatting used in this table, see ["Formatting Conventions in This Reference" on page 6](#).

DIMSTYLE group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbDimStyleTableRecord) |
| 2 | Dimension style name |
| 70 | Standard flag values (bit-coded values): 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD® commands. It can be ignored by most programs that read DXF™ files and need not be set by programs that write DXF files) |

DIMSTYLE group codes (continued)

| Group codes | Description |
|-------------|-----------------------------------|
| 3 | DIMPOST |
| 4 | DIMAPOST |
| 5 | DIMBLK (obsolete, now object ID) |
| 6 | DIMBLK1 (obsolete, now object ID) |
| 7 | DIMBLK2 (obsolete, now object ID) |
| 40 | DIMSCALE |
| 41 | DIMASZ |
| 42 | DIMEXO |
| 43 | DIMDLI |
| 44 | DIMEXE |
| 45 | DIMRND |
| 46 | DIMDLE |
| 47 | DIMTP |
| 48 | DIMTM |
| 140 | DIMTXT |
| 141 | DIMCEN |
| 142 | DIMTSZ |
| 143 | DIMALTF |
| 144 | DIMLFAC |
| 145 | DIMTVP |
| 146 | DIMTFAC |
| 147 | DIMGAP |
| 148 | DIMALTRND |

DIMSTYLE group codes (continued)

| Group codes | Description |
|-------------|--|
| 71 | DIMTOL |
| 72 | DIMLIM |
| 73 | DIMTIH |
| 74 | DIMTOH |
| 75 | DIMSE1 |
| 76 | DIMSE2 |
| 77 | DIMTAD |
| 78 | DIMZIN |
| 79 | DIMAZIN |
| 170 | DIMALT |
| 171 | DIMALTD |
| 172 | DIMTOFL |
| 173 | DIMSAH |
| 174 | DIMTIX |
| 175 | DIMSOXD |
| 176 | DIMCLRD |
| 177 | DIMCLRE |
| 178 | DIMCLRT |
| 179 | DIMADEC |
| 270 | DIMUNIT (obsolete, now use DIMLUNIT AND DIMFRAC) |
| 271 | DIMDEC |
| 272 | DIMTDEC |
| 273 | DIMALTU |

DIMSTYLE group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 274 | DIMALTTD |
| 275 | DIMAUNIT |
| 276 | DIMFRAC |
| 277 | DIMLUNIT |
| 278 | DIMDSEP |
| 279 | DIMTMOVE |
| 280 | DIMJUST |
| 281 | DIMSD1 |
| 282 | DIMSD2 |
| 283 | DIMTOLJ |
| 284 | DIMTZIN |
| 285 | DIMALTZ |
| 286 | DIMALTTZ |
| 287 | DIMFIT (obsolete, now use DIMATFIT and DIMTMOVE) |
| 288 | DIMUPT |
| 289 | DIMATFIT |
| 340 | DIMTXSTY (handle of referenced STYLE) |
| 341 | DIMLDRBLK (handle of referenced BLOCK) |
| 342 | DIMBLK (handle of referenced BLOCK) |
| 343 | DIMBLK1 (handle of referenced BLOCK) |
| 344 | DIMBLK2 (handle of referenced BLOCK) |
| 371 | DIMLWD (lineweight enum value) |
| 372 | DIMLWE (lineweight enum value) |

LAYER

The following group codes apply to LAYER symbol table entries. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries” on page 37](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| LAYER group codes | |
|-------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbLayerTableRecord) |
| 2 | Layer name |
| 70 | Standard flags (bit-coded values): 1 = Layer is frozen; otherwise layer is thawed 2 = Layer is frozen by default in new viewports 4 = Layer is locked 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD commands. It can be ignored by most programs that read DXF files and need not be set by programs that write DXF files) |
| 62 | Color number (if negative, layer is off) |
| 6 | Linetype name |
| 290 | Plotting flag. If set to 0, do not plot this layer |
| 370 | Lineweight enum value |
| 390 | Hard pointer ID/handle of PlotStyleName object |

Xref-dependent layers are output during SAVEAS. For these layers, the associated linetype name in the DXF file is always CONTINUOUS.

LTYPE

The following group codes apply to LTYPE symbol table entries. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries” on page 37](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| LTYPE group codes | |
|-------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbLinetypeTableRecord) |
| 2 | Linetype name |
| 70 | Standard flag values (bit-coded values): 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD commands. It can be ignored by most programs that read DXF files and need not be set by programs that write DXF files) |
| 3 | Descriptive text for linetype |
| 72 | Alignment code; value is always 65, the ASCII code for A |
| 73 | The number of linetype elements |
| 40 | Total pattern length |
| 49 | Dash, dot or space length (one entry per element) |
| 74 | Complex linetype element type (one per element). Default is 0 (no embedded shape/text). The following codes are bit values: 1 = If set, code 50 specifies an absolute rotation; if not set, code 50 specifies a relative rotation 2 = Embedded element is a text string 4 = Embedded element is a shape |

LTYPE group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 75 | Shape number (one per element) if code 74 specifies an embedded shape. If code 74 specifies an embedded text string, this value is set to 0 If code 74 is set to 0, code 75 is omitted |
| 340 | Pointer to STYLE object (one per element if code 74 > 0) |
| 46 | S = Scale value (optional); multiple entries can exist |
| 50 | R = (relative) or A = (absolute) rotation value in radians of embedded shape or text; one per element if code 74 specifies an embedded shape or text string |
| 44 | X = X offset value (optional); multiple entries can exist |
| 45 | Y = Y offset value (optional); multiple entries can exist |
| 9 | Text string (one per element if code 74 = 2) |

The group codes 74, 75, 340, 46, 50, 44, 45, and 9 are not returned by the tbl search or tbl next functions. You must use tbl obj name to retrieve these values within an application.

STYLE

The following group codes apply to STYLE symbol table entries. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries” on page 37](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

STYLE group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbTextStyleTableRecord) |
| 2 | Style name |

STYLE group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 70 | Standard flag values (bit-coded values): 1 = If set, this entry describes a shape 4 = Vertical text 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD commands. It can be ignored by most programs that read DXF files and need not be set by programs that write DXF files) |
| 40 | Fixed text height; 0 if not fixed |
| 41 | Width factor |
| 50 | Oblique angle |
| 71 | Text generation flags: 2 = Text is backward (mirrored in X) 4 = Text is upside down (mirrored in Y) |
| 42 | Last height used |
| 3 | Primary font file name |
| 4 | Bigfont file name; blank if none |

A STYLE table item is also used to record shape file LOAD command requests. In this case the first bit (1) is set in the 70 group flags and only the 3 group (shape file name) is meaningful (all the other groups are output, however).

UCS

The following group codes apply to UCS symbol table entries. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries” on page 37](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

UCS group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbUCSTableRecord) |
| 2 | UCS name |
| 70 | Standard flag values (bit-coded values): 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD commands. It can be ignored by most programs that read DXF files and need not be set by programs that write DXF files) |
| 10 | Origin (in WCS) DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of origin (in WCS) |
| 11 | X-axis direction (in WCS) DXF: X value; APP: 3D vector |
| 21, 31 | DXF: Y and Z values of X-axis direction (in WCS) |
| 12 | Y-axis direction (in WCS) DXF: X value; APP: 3D vector |
| 22, 32 | DXF: Y and Z values of Y-axis direction (in WCS) |
| 79 | Always 0 |
| 146 | Elevation |
| 346 | ID/handle of base UCS if this is an orthographic. This code is not present if the 79 code is 0. If this code is not present and 79 code is non-zero, then base UCS is assumed to be WORLD |
| 71 | Orthographic type (optional; always appears in pairs with the 13, 23, 33 codes): 1 = Top; 2 = Bottom; 3 = Front; 4 = Back; 5 = Left; 6 = Right |
| 13 | Origin for this orthographic type relative to this UCS. DXF: X value of origin point; APP: 3D point |
| 23, 33 | DXF: Y and Z values of origin point |

Each 71/13,23,33 pair defines the UCS origin for a particular orthographic type relative to this UCS. For instance if the following pair is present, then invoking the UCS/LEFT command when UCSBASE is set to this UCS will cause the new UCS origin to become (1,2,3).

```
71: 5
13: 1. 0
23: 2. 0
33: 3. 0
```

If this pair were not present, then invoking the UCS/LEFT command would cause the new UCS origin to be set to this UCS's origin point.

VIEW

The following group codes apply to VIEW symbol table entries. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries” on page 37](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| VIEW group codes | |
|------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbViewTableRecord) |
| 2 | Name of view |
| 70 | Standard flag values (bit-coded values): 1 = If set, this is a paper space view 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD commands. It can be ignored by most programs that read DXF files and need not be set by programs that write DXF files) |
| 40 | View height (in DCS) |
| 10 | View center point (in DCS) DXF: X value; APP: 2D point |
| 20 | DXF: Y value of view center point (in DCS) |

VIEW group codes (continued)

| Group codes | Description |
|-------------|--|
| 41 | View width (in DCS) |
| 11 | View direction from target (in WCS) DXF: X value; APP: 3D vector |
| 21, 31 | DXF: Y and Z values of view direction from target (in WCS) |
| 12 | Target point (in WCS) DXF: X value; APP: 3D point |
| 22, 32 | DXF: Y and Z values of target point (in WCS) |
| 42 | Lens length |
| 43 | Front clipping plane (offset from target point) |
| 44 | Back clipping plane (offset from target point) |
| 50 | Twist angle |
| 71 | View mode (see VIEWMODE system variable) |
| 281 | Render mode: 0 = 2D Optimized (classic 2D) 1 = Wireframe 2 = Hidden line 3 = Flat shaded 4 = Gouraud shaded 5 = Flat shaded with wireframe 6 = Gouraud shaded with wireframe All rendering modes other than 2D Optimized engage the new 3D graphics pipeline. These values directly correspond to the SHADEMODE command and the AcDbAbstractViewTableRecord::RenderMode enum |
| 72 | 1 if there is a UCS associated to this view, 0 otherwise |

The following codes only appear if code 72 is set to 1. They define the UCS that is associated to this view. This UCS will become the current UCS whenever this view is restored (if code 72 is 0, the UCS is unchanged).

VIEW with UCS group codes

| Group codes | Description |
|-------------|--|
| 110 | UCS origin (appears only if code 72 is set to 1) DXF: X value; APP: 3D point |
| 120, 130 | DXF: Y and Z values of UCS origin |
| 111 | UCS X-axis (appears only if code 72 is set to 1) DXF: X value; APP: 3D vector |
| 121, 131 | DXF: Y and Z values of UCS X-axis |
| 112 | UCS Y-axis (appears only if code 72 is set to 1) DXF: X value; APP: 3D vector |
| 122, 132 | DXF: Y and Z values of UCS Y-axis |
| 79 | Orthographic type of UCS (appears only if code 72 is set to 1): 0 = UCS is not orthographic; 1 = Top; 2 = Bottom; 3 = Front; 4 = Back; 5 = Left; 6 = Right |
| 146 | UCS Elevation (appears only if code 72 is set to 1) |
| 345 | ID/handle of AcDbUCSTableRecord if UCS is a named UCS. If not present, then UCS is unnamed (appears only if code 72 is set to 1) |
| 346 | ID/handle of AcDbUCSTableRecord of base UCS if UCS is orthographic (79 code is non-zero). If not present and 79 code is non-zero, then base UCS is taken to be WORLD (appears only if code 72 is set to 1) |

VPORT

The following group codes apply to VPORT symbol table entries. The VPORT table is unique: it may contain several entries with the same name (indicating a multiple-viewport configuration). The entries corresponding to the active viewport configuration all have the name *ACTIVE. The first such entry describes the current viewport. In addition to the group codes described here, see [“Common Group Codes for Symbol Table Entries”](#) on

page 37. For information about abbreviations and formatting used in this table, see “[Formatting Conventions in This Reference](#)” on page 6.

| VPORT group codes | |
|-------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbViewportTableRecord) |
| 2 | Viewport name |
| 70 | Standard flag values (bit-coded values): 16 = If set, table entry is externally dependent on an xref 32 = If this bit and bit 16 are both set, the externally dependent xref has been successfully resolved 64 = If set, the table entry was referenced by at least one entity in the drawing the last time the drawing was edited. (This flag is for the benefit of AutoCAD commands. It can be ignored by most programs that read DXF files and need not be set by programs that write DXF files) |
| 10 | Lower-left corner of viewport DXF: <i>X</i> value; APP: 2D point |
| 20 | DXF: <i>Y</i> value of lower-left corner of viewport |
| 11 | Upper-right corner of viewport DXF: <i>X</i> value; APP: 2D point |
| 21 | DXF: <i>Y</i> value of upper-right corner of viewport |
| 12 | View center point (in DCS) DXF: <i>X</i> value; APP: 2D point |
| 22 | DXF: <i>Y</i> value of view center point (in DCS) |
| 13 | Snap base point DXF: <i>X</i> value; APP: 2D point |
| 23 | DXF: <i>Y</i> value of snap base point |
| 14 | Snap spacing <i>X</i> and <i>Y</i> DXF: <i>X</i> value; APP: 2D point |
| 24 | DXF: <i>Y</i> value of snap spacing <i>X</i> and <i>Y</i> |
| 15 | Grid spacing <i>X</i> and <i>Y</i> DXF: <i>X</i> value; APP: 2D point |
| 25 | DXF: <i>Y</i> value of grid spacing <i>X</i> and <i>Y</i> |

VPORT group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 16 | View direction from target point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 26, 36 | DXF: <i>Y</i> and <i>Z</i> values of view direction from target point (in WCS) |
| 17 | View target point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 27, 37 | DXF: <i>Y</i> and <i>Z</i> values of view target point (in WCS) |
| 40 | View height |
| 41 | Viewport aspect ratio |
| 42 | Lens length |
| 43 | Front clipping plane (offset from target point) |
| 44 | Back clipping plane (offset from target point) |
| 50 | Snap rotation angle |
| 51 | View twist angle |
| 68 | APP: Status field (never saved in DXF) |
| 69 | APP: ID (never saved in DXF) |
| 71 | View mode (see VIEWMODE system variable) |
| 72 | Circle zoom percent |
| 73 | Fast zoom setting |
| 74 | UCSICON setting |
| 75 | Snap on/off |
| 76 | Grid on/off |
| 77 | Snap style |
| 78 | Snap isopair |

VPORT group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 281 | <p>Render mode: 0 = 2D Optimized (classic 2D) 1 = Wireframe 2 = Hidden line 3 = Flat shaded 4 = Gouraud shaded 5 = Flat shaded with wireframe 6 = Gouraud shaded with wireframe</p> <p>All rendering modes other than 2D Optimized engage the new 3D graphics pipeline. These values directly correspond to the SHADEMODE command and the AcDbAbstractViewTableRecord::RenderMode enum</p> |
| 65 | Value of UCSVP for this viewport. If set to 1, then viewport stores its own UCS which will become the current UCS whenever the viewport is activated. If set to 0, UCS will not change when this viewport is activated |
| 110 | UCS origin DXF: X value; APP: 3D point |
| 120, 130 | DXF: Y and Z values of UCS origin |
| 111 | UCS X-axis DXF: X value; APP: 3D vector |
| 121, 131 | DXF: Y and Z values of UCS X-axis |
| 112 | UCS Y-axis DXF: X value; APP: 3D vector |
| 122, 132 | DXF: Y and Z values of UCS Y-axis |
| 79 | <p>Orthographic type of UCS 0 = UCS is not orthographic; 1 = Top; 2 = Bottom; 3 = Front; 4 = Back; 5 = Left; 6 = Right</p> |
| 146 | Elevation |
| 345 | ID/handle of AcDbUCSTableRecord if UCS is a named UCS. If not present, then UCS is unnamed |
| 346 | ID/handle of AcDbUCSTableRecord of base UCS if UCS is orthographic (79 code is non-zero). If not present and 79 code is non-zero, then base UCS is taken to be WORLD |

BLOCKS Section

5

The group codes described in this chapter are found in DXF™ files and used by applications. The BLOCKS section contains an entry for each block reference in the drawing.

In this chapter

- BLOCKS Section Group Codes
- BLOCK
- ENDBLK

BLOCKS Section Group Codes

The BLOCKS section of the DXF file contains all the block definitions, including anonymous blocks generated by the HATCH command and by associative dimensioning. Each block definition contains the entities that make up that block as it is used in the drawing. The format of the entities in this section is identical to those in the ENTITIES section. All entities in the BLOCKS section appear between block and endblk entities. Block and endblk entities appear only in the BLOCKS section. Block definitions are never nested (that is, no block or endblk entity ever appears within another block-endblk pair), although a block definition can contain an insert entity.

External references are written in the DXF file as block definitions, except that they also include a string (group code 1) that specifies the path and file name of the external reference.

The block table handle, along with any xdata and persistent reactors, appears in each block definition immediately following the BLOCK record, which contains all of the specific information that a block table record stores.

BLOCK

The following group codes apply to block entities. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Block group codes | |
|----------------------------------|--|
| Group codes | Description |
| 0 | Entity type (BLOCK) |
| 5 | Handle |
| 102 | Start of application-defined group “{ <i>application_name</i> ”. For example, “{ACAD_REACTORS” indicates the start of the AutoCAD persistent reactors group (optional) |
| <i>application-defined codes</i> | Codes and values within the 102 groups are application defined (optional) |
| 102 | End of group, “}” (optional) |
| 330 | Soft-pointer ID/handle to owner object |

Block group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbEntity) |
| 8 | Layer name |
| 100 | Subclass marker (AcDbBlockBegin) |
| 2 | Block name |
| 70 | Block-type flags (bit coded values, may be combined): 0 = Indicates none of the following flags apply 1 = This is an anonymous block generated by hatching, associative dimensioning, other internal operations, or an application 2 = This block has non-constant attribute definitions (this bit is not set if the block has any attribute definitions that are constant, or has no attribute definitions at all) 4 = This block is an external reference (xref) 8 = This block is an xref overlay 16 = This block is externally dependent 32 = This is a resolved external reference, or dependent of an external reference (ignored on input) 64 = This definition is a referenced external reference (ignored on input) |
| 10 | Base point DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of base point |
| 3 | Block name |
| 1 | Xref path name |
| 4 | Block description (optional) |

The UCS in effect when a block definition is created becomes the WCS for all entities in the block definition. The new origin for these entities is shifted to match the base point defined for the block definition. All entity data is translated to fit this new WCS.

Model Space and Paper Space Block Definitions

Three empty definitions always appear in the BLOCKS section. They are titled *Model_Space, *Paper_Space and *Paper_Space0. These definitions manifest the representations of model space and paper space as block definitions internally. The internal name of the first paper space layout is

*Paper_Space, the second is *Paper_Space0, the third *Paper_Space1, and so on.

Model Space and Paper Space Entity Segregation

The interleaving between model space and paper space no longer occurs. Instead, all paper space entities are output, followed by model space entities. The flag distinguishing them is the group code 67.

ENDBLK

The following group codes apply to endblk objects. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Endblk group codes | |
|----------------------------------|--|
| Group codes | Description |
| 0 | Entity type (ENDBLK) |
| 5 | Handle |
| 102 | Start of application-defined group “{ <i>application_name</i> ”. For example, “{ACAD_REACTORS” indicates the start of the AutoCAD persistent reactors group (optional) |
| <i>application-defined codes</i> | Codes and values within the 102 groups are application defined (optional) |
| 102 | End of group, “}” (optional) |
| 330 | Soft-pointer ID/handle to owner object |
| 100 | Subclass marker (AcDbEntity) |
| 8 | Layer name |
| 100 | Subclass marker (AcDbBlockEnd) |

ENTITIES Section

6

This chapter presents the group codes that apply to graphical objects. These codes are found in the ENTITIES section of a DXF™ file and are used by AutoLISP® and ObjectARX™ applications in entity definition lists.

In this chapter

- Common Group Codes for Entities
- 3DFACE
- 3DSOLID
- ACAD_PROXY_ENTITY
- ARC
- ATTDEF
- ATTRIB
- BODY
- CIRCLE
- DIMENSION
- ELLIPSE
- HATCH
- IMAGE
- INSERT
- LEADER
- LINE
- LWPOLYLINE
- MLINE
- MTEXT
- OLEFRAME
- OLE2FRAME
- POINT
- POLYLINE
- RAY
- REGION
- SEQEND
- SHAPE
- SOLID
- SPLINE
- TEXT
- TOLERANCE
- TRACE
- VERTEX
- VIEWPORT
- XLINE

Common Group Codes for Entities

The following table shows group codes that apply to virtually all graphical objects. Some of the group codes shown here are included with an entity definition only if the entity has nondefault values for the property. When you refer to the group codes by entity type, the lists of codes associated with *specific* entities, keep in mind that the codes shown here are also present.

NOTE Do not write programs that rely on the order shown in these DXF code tables. Although these tables show the order of group codes as they usually appear, the order can change under certain conditions or may be changed in a future AutoCAD® release. The code that controls an entity should be driven by a case (switch) or a table so that it can process each group correctly even if the order is unexpected.

When a group is omitted, its default value upon input (when using OPEN) is indicated in the third column. If the value of a group code is equal to the default, it is omitted upon output (when using SAVEAS). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Group codes that apply to all graphical objects | | |
|---|---|----------------------------|
| Group code | Description | If omitted, defaults to... |
| -1 | APP: entity name (changes each time a drawing is opened) | not omitted |
| 0 | Entity type | not omitted |
| 5 | Handle | not omitted |
| 102 | Start of application defined group “{ <i>application_name</i> ” (optional) | no default |
| <i>application-defined codes</i> | Codes and values within the 102 groups are application-defined (optional) | no default |
| 102 | End of group, “}” (optional) | no default |
| 102 | “{ACAD_REACTORS” indicates the start of the AutoCAD persistent reactors group. This group exists only if persistent reactors have been attached to this object (optional) | no default |

Group codes that apply to all graphical objects (*continued*)

| Group code | Description | If omitted, defaults to... |
|------------|---|----------------------------|
| 330 | Soft pointer ID/handle to owner dictionary (optional) | no default |
| 102 | End of group, “}” (optional) | no default |
| 102 | “{ACAD_XDICTIONARY” indicates the start of an extension dictionary group. This group exists only if persistent reactors have been attached to this object (optional) | no default |
| 360 | Hard owner ID/handle to owner dictionary (optional) | no default |
| 102 | End of group, “}” (optional) | no default |
| 330 | Soft-pointer ID/handle to owner BLOCK_RECORD object | not omitted |
| 100 | Subclass marker (AcDbEntity) | not omitted |
| 67 | Absent or zero indicates entity is in model space. 1 indicates entity is in paper space (optional) | 0 |
| 410 | APP: layout tab name | not omitted |
| 8 | Layer name | not omitted |
| 6 | Linetype name (present if not BYLAYER). The special name BYBLOCK indicates a floating linetype (optional) | BYLAYER |
| 62 | Color number (present if not BYLAYER); zero indicates the BYBLOCK (floating) color; 256 indicates BYLAYER; a negative value indicates that the layer is turned off (optional) | BYLAYER |
| 370 | Lineweight enum value. Stored and moved around as a 16-bit integer. | not omitted |
| 48 | Linetype scale (optional) | 1.0 |
| 60 | Object visibility (optional): 0 = Visible, 1 = Invisible | 0 |
| 92 | The number of bytes in the image (and subsequent binary chunk records) (optional) | no default |

Group codes that apply to all graphical objects (*continued*)

| Group code | Description | If omitted, defaults to... |
|------------|--|----------------------------|
| 310 | Preview image data (multiple lines; 256 characters max. per line) (optional) | no default |

3DFACE

The following group codes apply to 3dface entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

3dface group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbFace) |
| 10 | First corner (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of first corner (in WCS) |
| 11 | Second corner (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of second corner (in WCS) |
| 12 | Third corner (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 22, 32 | DXF: <i>Y</i> and <i>Z</i> values of third corner (in WCS) |
| 13 | Fourth corner (in WCS). If only three corners are entered, this is the same as the third corner DXF: <i>X</i> value; APP: 3D point |
| 23, 33 | DXF: <i>Y</i> and <i>Z</i> values of fourth corner (in WCS) |
| 70 | Invisible edge flags (optional; default = 0): 1 = First edge is invisible 2 = Second edge is invisible 4 = Third edge is invisible 8 = Fourth edge is invisible |

3DSOLID

The following group codes apply to 3dsolid entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

3dsolid group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbModelerGeometry) |
| 70 | Modeler format version number (currently = 1) |
| 1 | Proprietary data (multiple lines < 255 characters each) |
| 3 | Additional lines of proprietary data (if previous group 1 string is greater than 255 characters) (optional) |

ACAD_PROXY_ENTITY

The following group codes apply to proxy entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Acad_proxy_entity group codes

| Group codes | Description |
|-------------|--|
| 100 | DXF™: AcDbProxyEntity |
| 90 | DXF: Proxy entity class ID (always 498) |
| 91 | DXF: Application entity's class ID. Class IDs are based on the order of the class in the CLASSES section. The first class is given the ID of 500, the next is 501, and so on |
| 92 | DXF: Size of graphics data in bytes |
| 310 | DXF: Binary graphics data (multiple entries can appear) (optional) |

Acad_proxy_entity group codes (continued)

| Group codes | Description |
|-----------------------------|---|
| 93 | DXF: Size of entity data in bits |
| 310 | DXF: Binary entity data (multiple entries can appear) (optional) |
| 330 or 340 or 350 or 360 | DXF: An object ID (multiple entries can appear) (optional) |
| 94 | DXF: 0 (indicates end of object ID section) |
| 95 | DXF: Object drawing format when it becomes a proxy (a 32-bit unsigned integer): Low word is AcDbDwgVersion High word is MaintenanceReleaseVersion |
| 70 | DXF: Original custom object data format: 0 = DWG format 1 = DXF format |

ARC

The following group codes apply to arc entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Arc group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbCircle) |
| 39 | Thickness (optional; default = 0) |
| 10 | Center point (in OCS) DXF™: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of center point (in OCS) |
| 40 | Radius |
| 100 | Subclass marker (AcDbArc) |
| 50 | Start angle |

Arc group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 51 | End angle |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction (optional) |

ATTDEF

The following group codes apply to attdef (attribute definition) entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Attdef group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbText) |
| 39 | Thickness (optional; default = 0) |
| 10 | First alignment point (in OCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of text start point (in OCS) |
| 40 | Text height |
| 1 | Default value (string) |
| 100 | Subclass marker (AcDbAttributeDefinition) |
| 50 | Text rotation (optional; default = 0) |
| 41 | Relative <i>X</i> scale factor (width) (optional; default = 1). This value is also adjusted when fit-type text is used |
| 51 | Oblique angle (optional; default = 0) |
| 7 | Text style name (optional, default = STANDARD) |

Attdef group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 71 | Text generation flags (optional, default = 0); see TEXT group codes |
| 72 | Horizontal text justification type (optional, default = 0); see TEXT group codes |
| 11 | Second alignment point (in OCS) (optional) DXF: X value; APP: 3D point Meaningful only if 72 or 74 group values are nonzero |
| 21, 31 | DXF: Y and Z values of second alignment point (in OCS) (optional) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction |
| 100 | Subclass marker (AcDbAttributeDefinition) |
| 3 | Prompt string |
| 2 | Tag string |
| 70 | Attribute flags: 1 = Attribute is invisible (does not appear) 2 = This is a constant attribute 4 = Verification is required on input of this attribute 8 = Attribute is preset (no prompt during insertion) |
| 73 | Field length (optional; default = 0) (not currently used) |
| 74 | Vertical text justification type (optional, default = 0); see group code 73 in TEXT |

If group 72 and/or 74 values are nonzero then the first alignment point values are ignored and AutoCAD calculates new values based on the second alignment point and the length and height of the text string itself (after applying the text style). If the 72 and 74 values are zero or missing, then the second alignment point is meaningless.

ATTRIB

The following group codes apply to attrib (attribute) entities. In addition to the group codes described here, see [“Common Group Codes for Entities”](#) on

page 60. For information about abbreviations and formatting used in this table, see “[Formatting Conventions in This Reference](#)” on page 6.

| Attrib group codes | |
|--------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbText) |
| 39 | Thickness (optional; default = 0) |
| 10 | Text start point (in OCS) DXF™: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of text start point (in OCS) |
| 40 | Text height |
| 1 | Default value (string) |
| 100 | Subclass marker (AcDbAttribute) |
| 2 | Attribute tag (string) |
| 70 | Attribute flags: 1 = Attribute is invisible (does not appear) 2 = This is a constant attribute 4 = Verification is required on input of this attribute 8 = Attribute is preset (no prompt during insertion) |
| 73 | Field length (optional; default = 0) (not currently used) |
| 50 | Text rotation (optional; default = 0) |
| 41 | Relative X scale factor (width) (optional; default = 1). This value is also adjusted when fit-type text is used |
| 51 | Oblique angle (optional; default = 0) |
| 7 | Text style name (optional, default = STANDARD) |
| 71 | Text generation flags (optional, default = 0). See TEXT group codes |
| 72 | Horizontal text justification type (optional, default = 0). See TEXT group codes |
| 74 | Vertical text justification type (optional, default = 0). See group code 73 in TEXT |
| 11 | Alignment point (in OCS) (optional) DXF: X value; APP: 3D point Present only if 72 or 74 group is present and nonzero |

Attrib group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 21, 31 | DXF: Y and Z values of alignment point (in OCS) (optional) |
| 210 | Extrusion direction. Present only if the entity's extrusion direction is not parallel to the WCS Z axis (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

If group 72 and/or 74 values are nonzero then the text insertion point values are ignored, and AutoCAD calculates new values based on the text alignment point and the length of the text string itself (after applying the text style). If the 72 and 74 values are zero or missing, then the text alignment point is ignored and recalculated based on the text insertion point and the length of the text string itself (after applying the text style).

BODY

The following group codes apply to body entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Body group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbModelerGeometry) |
| 70 | Modeler format version number (currently = 1) |
| 1 | Proprietary data (multiple lines < 255 characters each) |
| 3 | Additional lines of proprietary data (if previous group 1 string is greater than 255 characters) (optional) |

CIRCLE

The following group codes apply to circle entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Circle group codes | |
|--------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbCircle) |
| 39 | Thickness (optional; default = 0) |
| 10 | Center point (in OCS) DXF™: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of center point (in OCS) |
| 40 | Radius |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

DIMENSION

Dimension entity definitions consist of group codes that are common to all dimension types, followed by codes specific to the type.

Common Dimension Group Codes

The following group codes apply to all dimension entity types. In addition to the group codes described here, see [“Common Group Codes for Entities”](#)

on page 60. For information about abbreviations and formatting used in this table, see “[Formatting Conventions in This Reference](#)” on page 6.

| Common dimension group codes | |
|------------------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbDimension) |
| 2 | Name of the block that contains the entities that make up the dimension picture |
| 10 | Definition point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of definition point (in WCS) |
| 11 | Middle point of dimension text (in OCS) DXF: <i>X</i> value; APP: 3D point |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of middle point of dimension text (in OCS) |
| 70 | Dimension type. Values 0–6 are integer values that represent the dimension type. Values 32, 64, and 128 are bit values, which are added to the integer values (value 32 is always set in R13 and later releases). 0 = Rotated, horizontal, or vertical; 1 = Aligned; 2 = Angular; 3 = Diameter; 4 = Radius; 5 = Angular 3 point; 6 = Ordinate; 32 = Indicates that the block reference (group code 2) is referenced by this dimension only. 64 = Ordinate type. This is a bit value (bit 7) used only with integer value 6. If set, ordinate is X-type; if not set, ordinate is Y-type. 128 = This is a bit value (bit 8) added to the other group 70 values if the dimension text has been positioned at a user-defined location rather than at the default location |
| 71 | Attachment point: 1 = Top left; 2 = Top center; 3 = Top right; 4 = Middle left; 5 = Middle center; 6 = Middle right; 7 = Bottom left; 8 = Bottom center; 9 = Bottom right |
| 72 | Dimension text line spacing style (optional): 1 (or missing) = At least (taller characters will override) 2 = Exact (taller characters will not override) |
| 41 | Dimension text line spacing factor (optional): Percentage of default (3-on-5) line spacing to be applied. Valid values range from 0.25 to 4.00 |
| 42 | Actual measurement (optional; read-only value) |

Common dimension group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 1 | Dimension text explicitly entered by the user. Optional; default is the measurement. If null or "<>", the dimension measurement is drawn as the text, if " " (one blank space), the text is suppressed. Anything else is drawn as the text |
| 53 | The optional group code 53 is the rotation angle of the dimension text away from its default orientation (the direction of the dimension line) (optional) |
| 51 | All dimension types have an optional 51 group code, which indicates the horizontal direction for the dimension entity. The dimension entity determines the orientation of dimension text and lines for horizontal, vertical, and rotated linear dimensions. This group value is the negative of the angle between the OCS X axis and the UCS X axis. It is always in the XY plane of the OCS |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |
| 3 | Dimension style name |

Xdata belonging to the application ID "ACAD" follows a dimension entity if any dimension overrides that have been applied to this entity. See ["Dimension Style Overrides" on page 76](#).

For all dimension types, the following group codes represent 3D WCS points:

- (10, 20, 30)
- (13, 23, 33)
- (14, 24, 34)
- (15, 25, 35)

For all dimension types, the following group codes represent 3D OCS points:


- (11, 21, 31)
- (12, 22, 32)
- (16, 26, 36)

Aligned Dimension Group Codes

The following group codes apply to aligned dimensions. In addition to the group codes described here, those listed in ["Common Group Codes for Enti-](#)

ties” on page 60 and “Common Dimension Group Codes” on page 69 can also be present. For information about abbreviations and formatting used in this table, see “Formatting Conventions in This Reference” on page 6.

| Aligned dimension group codes | |
|-------------------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbAlignedDimension) |
| 12 | Insertion point for clones of a dimension—Baseline and Continue (in OCS) DXF: X value; APP: 3D point |
| 22, 32 | DXF: Y and Z values of insertion point for clones of a dimension—Baseline and Continue (in OCS) |
| 13 | Definition point for linear and angular dimensions (in WCS) DXF: X value; APP: 3D point |
| 23, 33 | DXF: Y and Z values of definition point for linear and angular dimensions (in WCS) |
| 14 | Definition point for linear and angular dimensions (in WCS) DXF: X value; APP: 3D point |
| 24, 34 | DXF: Y and Z values of definition point for linear and angular dimensions (in WCS) |



The point (13,23,33) specifies the start point of the first extension line and the point (14,24,34) specifies the start point of the second extension line. Point (10,20,30) specifies the dimension line location. The point (11,21,31) specifies the midpoint of the dimension text.

Linear and Rotated Dimension Group Codes

The following group codes apply to linear and rotated dimensions (note that linear and rotated dimensions are part of the AcDbAlignedDimension subclass). In addition to the group codes described here, those listed in “Common Group Codes for Entities” on page 60 and “Common Dimension Group Codes” on page 69 can also be present. For information about abbreviations

and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).


| Linear and rotated dimension group codes | |
|--|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbAlignedDimension) |
| 12 | Insertion point for clones of a dimension—Baseline and Continue (in OCS) DXF: <i>X</i> value; APP: 3D point |
| 22, 32 | DXF: <i>Y</i> and <i>Z</i> values of insertion point for clones of a dimension—Baseline and Continue (in OCS) |
| 13 | Definition point for linear and angular dimensions (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 23, 33 | DXF: <i>Y</i> and <i>Z</i> values of definition point for linear and angular dimensions (in WCS) |
| 14 | Definition point for linear and angular dimensions (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 24, 34 | DXF: <i>Y</i> and <i>Z</i> values of definition point for linear and angular dimensions (in WCS) |
| 50 | Angle of rotated, horizontal, or vertical dimensions |
| 52 | Linear dimension types with an oblique angle have an optional group code 52. When added to the rotation angle of the linear dimension (group code 50), it gives the angle of the extension lines |
| 100 | Subclass marker (AcDbRotatedDimension) |

Radial and Diameter Dimension Group Codes

The following group codes apply to radial and diameter dimensions. In addition to the group codes described here, those listed in [“Common Group Codes for Entities” on page 60](#) and [“Common Dimension Group Codes” on page 69](#) can also be present. For information about abbreviations and format-

ting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Radial and diameter dimension group codes | |
|---|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbRadialDimension or AcDbDiametricDimension) |
| 15 | Definition point for diameter, radius, and angular dimensions (in WCS) DXF: X value; APP: 3D point |
| 25, 35 | DXF: Y and Z values of definition point for diameter, radius, and angular dimensions (in WCS) |
| 40 | Leader length for radius and diameter dimensions |




The point (15,25,35) specifies the first point of the dimension line on the circle/arc and the point (10,20,30) specifies the point opposite the first point. The point (11,21,31) specifies the midpoint of the dimension text.

The point (15,25,35) specifies the first point of the dimension line on the circle/arc and the point (10,20,30) specifies the center of the circle/arc. The point (11,21,31) specifies the midpoint of the dimension text.

Angular Dimension Group Codes


The following group codes apply to angular dimensions. In addition to the group codes described here, those listed in [“Common Group Codes for Entities” on page 60](#) and [“Common Dimension Group Codes” on page 69](#) can also be present. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Angular dimension group codes | |
|-------------------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDb3PointAngularDimension) |
| 13 | Definition point for linear and angular dimensions (in WCS) DXF: X value; APP: 3D point |
| 23, 33 | DXF: Y and Z values of definition point for linear and angular dimensions (in WCS) |
| 14 | Definition point for linear and angular dimensions (in WCS) DXF: X value; APP: 3D point |




Angular dimension group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 24, 34 | DXF: Y and Z values of definition point for linear and angular dimensions (in WCS) |
| 15 | Definition point for diameter, radius, and angular dimensions (in WCS) DXF: X value; APP: 3D point |
| 25, 35 | DXF: Y and Z values of definition point for diameter, radius, and angular dimensions (in WCS) |
| 16 | Point defining dimension arc for angular dimensions (in OCS) DXF: X value; APP: 3D point |
| 26, 36 | DXF: Y and Z values of point defining dimension arc for angular dimensions (in OCS) |



The points (13,23,33) and (14,24,34) specify the endpoints of the line used to determine the first extension line. Points (10,20,30) and (15,25,35) specify the endpoints of the line used to determine the second extension line. Point (16,26,36) specifies the location of the dimension line arc. The point (11,21,31) specifies the midpoint of the dimension text.



The point (15,25,35) specifies the vertex of the angle. The points (13,23,33) and (14,24,34) specify the endpoints of the extension lines. The point (10,20,30) specifies the location of the dimension line arc and the point (11,21,31) specifies the midpoint of the dimension text.

Ordinate Dimension Group Codes


The following group codes apply to ordinate dimensions. In addition to the group codes described here, those listed in [“Common Group Codes for Entities” on page 60](#) and [“Common Dimension Group Codes” on page 69](#) can also be present. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Ordinate dimension group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbOrdinateDimension) |
| 13 | Definition point for linear and angular dimensions (in WCS) DXF: X value; APP: 3D point |

Ordinate dimension group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 23, 33 | DXF: Y and Z values of definition point for linear and angular dimensions (in WCS) |
| 14 | Definition point for linear and angular dimensions (in WCS) DXF: X value; APP: 3D point |
| 24, 34 | DXF: Y and Z values of definition point for linear and angular dimensions (in WCS) |



The point (13,23,33) specifies the feature location and the point (14,24,34) specifies the leader end point. The point (11,21,31) specifies the midpoint of the dimension text. Point (10,20,30) is placed at the origin of the UCS that is current when the dimension is created.

Dimension Style Overrides

Dimension style overrides can be applied to dimension, leader, and tolerance entities. Any overrides applied to these entities are stored in the entity as xdata. The overridden dimension variable group codes and the related values are contained within group 1002 control strings. The following example shows the xdata of a dimension entity where the DIMTOL and DIMCLRE variables have been overridden.

```
(setq diment (car (entsel))) ; Select dimension entity
(setq elst (entget diment '("ACAD"))) ; Get entity definition list
(assoc -3 elst) ; Extract xdata only
```

This code returns the following:

```
(-3 ("ACAD"
  (1000 . "DSTYLE") (1002 . "{") Start of the ACAD APPID section of xdata
  (1070 . 177) (1070 . 3) The DIMCLRE (code 177) override + value (3)
  (1070 . 71) (1070 . 1) The DIMTOL (code 71) override + value (1)
  (1002 . "}") )) End dimstyle subsection and ACAD section
```

ELLIPSE

The following group codes apply to ellipse entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#).

For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Ellipse group codes | |
|---------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbEllipse) |
| 10 | Center point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of center point (in WCS) |
| 11 | Endpoint of major axis, relative to the center (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of endpoint of major axis, relative to the center (in WCS) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction (optional) |
| 40 | Ratio of minor axis to major axis |
| 41 | Start parameter (this value is 0.0 for a full ellipse) |
| 42 | End parameter (this value is 2pi for a full ellipse) |

The group codes 41 and 42 are the start and end values for *u* in the equation describing the Parameter option of the ELLIPSE command (see the following topic, [“ELLIPSE Command’s Parameter Option”](#)). The magnitude of the codes 11,21,31 vector is equal to 1/2 of the major axis which is the *a* value in the equation. The point 10,20,30 is the *c* value in the equation. Knowing all these, we can calculate the *b* value to complete the equation.

ELLIPSE Command’s Parameter Option

The Parameter option of the ELLIPSE command uses the following equation to define an elliptical arc.

$$p(u)=c+a*\cos(u)+b*\sin(u)$$

The variables *a*, *b*, *c* are determined when you select the endpoints for the first axis and the distance for the second axis. *a* is the negative of 1/2 of the

major axis length, b is the negative of $1/2$ the minor axis length, and c is the center point (2-D) of the ellipse.

Because this is actually a vector equation and the variable c is actually a point with X and Y values, it really should be written as:

$$p(u) = (C_x + a \cdot \cos(u)) \cdot i + (C_y + b \cdot \sin(u)) \cdot j$$

where

- C_x is the X value of the point c
- C_y is the Y value of the point c
- a is $-(1/2)$ of the major axis length
- b is $-(1/2)$ of the minor axis length
- i and j represent unit vectors in the X and Y directions

In AutoCAD, once the axis endpoints are selected, all you have left to specify is the start and end of the elliptical arc.

When you select the parameter option, you are asked for a start parameter and an end parameter. These values are plugged into the equation to determine the actual start and end points on the ellipse. The rest of the ellipse is filled in between these two points in a counterclockwise direction from the first parameter to the second. The value entered for the parameter u is taken to be degrees for the purposes of obtaining the $\cos(u)$ and $\sin(u)$.

For example:

Axis endpoint 1 = 0,1

Axis endpoint 2 = 4,1

Other axis distance = 2,0

Start parameter = 270

End parameter = 0

generates the start point at 2,2 and the end point at 0,1 and fills in the ellipse from 2,2 to 0,1 in a counterclockwise direction.

HATCH

The following group codes apply to hatch entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#).

For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Hatch group codes | |
|-------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbHatch) |
| 10 | Elevation point (in OCS) DXF: <i>X</i> value = 0; APP: 3D point (<i>X</i> and <i>Y</i> always equal 0, <i>Z</i> represents the elevation) |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of elevation point (in OCS) <i>Y</i> value = 0, <i>Z</i> represents the elevation |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction |
| 2 | Hatch pattern name |
| 70 | Solid fill flag (solid fill = 1; pattern fill = 0) |
| 71 | Associativity flag (associative = 1; non-associative = 0) |
| 91 | Number of boundary paths (loops) |
| <i>varies</i> | Boundary path data. Repeats number of times specified by code 91. See “Boundary Path Data” on page 80 |
| 75 | Hatch style: 0 = Hatch “odd parity” area (Normal style) 1 = Hatch outermost area only (Outer style) 2 = Hatch through entire area (Ignore style) |
| 76 | Hatch pattern type: 0 = User-defined; 1 = Predefined; 2 = Custom |
| 52 | Hatch pattern angle (pattern fill only) |
| 41 | Hatch pattern scale or spacing (pattern fill only) |
| 77 | Hatch pattern double flag (pattern fill only): 0 = not double; 1 = double |
| 78 | Number of pattern definition lines |

Hatch group codes (*continued*)

| Group codes | Description |
|---------------|--|
| <i>varies</i> | Pattern line data. Repeats number of times specified by code 78. See “Pattern Data” on page 83 |
| 47 | Pixel size used to determine the density to perform various intersection and ray casting operations in hatch pattern computation for associative hatches and hatches created with the Flood method of hatching |
| 98 | Number of seed points |
| 10 | Seed point (in OCS) DXF: X value; APP: 2D point (multiple entries) |
| 20 | DXF: Y value of seed point (in OCS); (multiple entries) |

Boundary Path Data

The boundary of each hatch object is defined by a path (or *loop*) that consists of one or more segments. Path segment data varies depending on the entity type (or types) that make up the path. Each path segment is defined by its own set of group codes. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Hatch boundary path data group codes

| Group codes | Description |
|---------------|--|
| 92 | Boundary path type flag (bit coded): 0 = Default; 1 = External; 2 = Polyline; 4 = Derived; 8 = Textbox; 16 = Outermost |
| <i>varies</i> | Polyline boundary type data (only if boundary = polyline). See Polyline boundary data table below |
| 93 | Number of edges in this boundary path (only if boundary is not a polyline) |
| 72 | Edge type (only if boundary is not a polyline): 1 = Line; 2 = Circular arc; 3 = Elliptic arc; 4 = Spline |
| <i>varies</i> | Edge type data (only if boundary is not a polyline). See appropriate Edge data table below |
| 97 | Number of source boundary objects |

Hatch boundary path data group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 330 | Reference to source boundary objects (multiple entries) |

Polyline boundary data group codes

| Group codes | Description |
|-------------|---|
| 72 | Has bulge flag |
| 73 | Is closed flag |
| 93 | Number of polyline vertices |
| 10 | Vertex location (in OCS) DXF: <i>X</i> value; APP: 2D point (multiple entries) |
| 20 | DXF: <i>Y</i> value of vertex location (in OCS) (multiple entries) |
| 42 | Bulge (optional, default = 0) |

Line edge data group codes

| Group codes | Description |
|-------------|--|
| 10 | Start point (in OCS) DXF: <i>X</i> value; APP: 2D point |
| 20 | DXF: <i>Y</i> value of start point (in OCS) |
| 11 | End point (in OCS) DXF: <i>X</i> value; APP: 2D point |
| 21 | DXF: <i>Y</i> value of end point (in OCS) |

Arc edge data group codes

| Group codes | Description |
|-------------|---|
| 10 | Center point (in OCS) DXF: <i>X</i> value; APP: 2D point |
| 20 | DXF: <i>Y</i> value of center point (in OCS) |
| 40 | Radius |

Arc edge data group codes (*continued*)

| Group codes | Description |
|-------------|--------------------------|
| 50 | Start angle |
| 51 | End angle |
| 73 | Is counterclockwise flag |

Ellipse edge data group codes

| Group codes | Description |
|-------------|---|
| 10 | Center point (in OCS) DXF: <i>X</i> value; APP: 2D point |
| 20 | DXF: <i>Y</i> value of center point (in OCS) |
| 11 | End point of major axis relative to center point (in OCS) DXF: <i>X</i> value; APP: 2D point |
| 21 | DXF: <i>Y</i> value of end point of major axis (in OCS) |
| 40 | Length of minor axis (percentage of major axis length) |
| 50 | Start angle |
| 51 | End angle |
| 73 | Is counterclockwise flag |

Spline edge data group codes

| Group codes | Description |
|-------------|--------------------------------|
| 94 | Degree |
| 73 | Rational |
| 74 | Periodic |
| 95 | Number of knots |
| 96 | Number of control points |
| 40 | Knot values (multiple entries) |

Spline edge data group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 10 | Control point (in OCS) DXF: <i>X</i> value; APP: 2D point |
| 20 | DXF: <i>Y</i> value of control point (in OCS) |
| 42 | Weights (optional, default = 1) |

Pattern Data

The following pattern data codes repeat for each pattern definition line. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Hatch pattern data group codes

| Group codes | Description |
|-------------|---|
| 53 | Pattern line angle |
| 43 | Pattern line base point, <i>X</i> component |
| 44 | Pattern line base point, <i>Y</i> component |
| 45 | Pattern line offset, <i>X</i> component |
| 46 | Pattern line offset, <i>Y</i> component |
| 79 | Number of dash length items |
| 49 | Dash length (multiple entries) |

IMAGE

The following group codes apply to image entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#).

For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Image group codes | |
|-------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbRasterImage) |
| 90 | Class version |
| 10 | Insertion point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of insertion point (in WCS) |
| 11 | U-vector of a single pixel (points along the visual bottom of the image, starting at the insertion point) (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values U-vector (in WCS) |
| 12 | V-vector of a single pixel (points along the visual left side of the image, starting at the insertion point) (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 22, 32 | DXF: <i>Y</i> and <i>Z</i> values of V-vector (in WCS) |
| 13 | Image size in pixels DXF: <i>U</i> value; APP: 2D point (<i>U</i> and <i>V</i> values) |
| 23 | DXF: <i>V</i> value of image size in pixels |
| 340 | Hard reference to imagedef object |
| 70 | Image display properties: 1 = Show image 2 = Show image when not aligned with screen 4 = Use clipping boundary 8 = Transparency is on |
| 280 | Clipping state: 0 = Off, 1 = On |
| 281 | Brightness value (0-100; default = 50) |
| 282 | Contrast value (0-100; default = 50) |
| 283 | Fade value (0-100; default = 0) |

Image group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 360 | Hard reference to imagedef_reactor object |
| 71 | Clipping boundary type. 1 = Rectangular, 2 = Polygonal |
| 91 | Number of clip boundary vertices that follow |
| 14 | Clip boundary vertex (in OCS) DXF: <i>X</i> value; APP: 2D point (multiple entries) Notes: 1) For rectangular clip boundary type, two opposite corners must be specified. Default is (-0.5,-0.5), (size.x-0.5, size.y-0.5). 2) For polygonal clip boundary type, three or more vertices must be specified. Polygonal vertices must be listed sequentially |
| 24 | DXF: <i>Y</i> value of clip boundary vertex (in OCS) (multiple entries) |

INSERT

The following group codes apply to insert (block reference) entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Insert group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbBlockReference) |
| 66 | Variable attributes-follow flag (optional; default = 0); if the value of attributes-follow flag is 1, a series of attribute entities is expected to follow the insert, terminated by a sevend entity |
| 2 | Block name |
| 10 | Insertion point (in OCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of insertion point (in OCS) |
| 41 | <i>X</i> scale factor (optional; default = 1) |

Insert group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 42 | Y scale factor (optional; default = 1) |
| 43 | Z scale factor (optional; default = 1) |
| 50 | Rotation angle (optional; default = 0) |
| 70 | Column count (optional; default = 1) |
| 71 | Row count (optional; default = 1) |
| 44 | Column spacing (optional; default = 0) |
| 45 | Row spacing (optional; default = 0) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

LEADER

The following group codes apply to leader entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Leader group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbLeader) |
| 3 | Dimension style name |
| 71 | Arrowhead flag: 0 = Disabled; 1 = Enabled |
| 72 | Leader path type: 0 = Straight line segments; 1 = Spline |
| 73 | Leader creation flag (default = 3): 0 = Leader created with text annotation 1 = Created with tolerance annotation 2 = Created with block reference annotation 3 = Created without any annotation |

Leader group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 74 | Hook line direction flag: 0 = Hook line (or end of tangent for a splined leader) is the opposite direction from the horizontal vector 1 = Hook line (or end of tangent for a splined leader) is the same direction as horizontal vector (see code 75) |
| 75 | Hook line flag: 0 = No hookline; 1 = Has a hookline |
| 40 | Text annotation height |
| 41 | Text annotation width |
| 76 | Number of vertices in leader (ignored for OPEN) |
| 10 | Vertex coordinates (one entry for each vertex) DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of vertex coordinates |
| 77 | Color to use if leader's DIMCLRD = BYBLOCK |
| 340 | Hard reference to associated annotation (mtext, tolerance, or insert entity) |
| 210 | Normal vector DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of normal vector |
| 211 | "Horizontal" direction for leader DXF: X value; APP: 3D vector |
| 221, 231 | DXF: Y and Z values of "horizontal" direction for leader |
| 212 | Offset of last leader vertex from block reference insertion point DXF: X value; APP: 3D vector |
| 222, 232 | DXF: Y and Z values of offset |
| 213 | Offset of last leader vertex from annotation placement point DXF: X value; APP: 3D vector |
| 223, 233 | DXF: Y and Z values of offset |

Xdata belonging to the application ID "ACAD" follows a leader entity if any dimension overrides have been applied to this entity. See ["Dimension Style Overrides" on page 76](#).

LINE

The following group codes apply to line entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Line group codes | |
|------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbLine) |
| 39 | Thickness (optional; default = 0) |
| 10 | Start point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of start point (in WCS) |
| 11 | End point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of end point (in WCS) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction (optional) |

LWPOLYLINE

The following group codes apply to lwpolyline entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Lwpolyline group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbPolyline) |
| 90 | Number of vertices |
| 70 | Polyline flag (bit-coded); default is 0: 1 = Closed; 128 = Plinegen |
| 43 | Constant width (optional; default = 0). Not used if variable width (codes 40 and/or 41) is set |
| 38 | Elevation (optional; default = 0) |
| 39 | Thickness (optional; default = 0) |
| 10 | Vertex coordinates (in OCS), multiple entries; one entry for each vertex DXF: X value; APP: 2D point |
| 20 | DXF: Y value of vertex coordinates (in OCS), multiple entries; one entry for each vertex |
| 40 | Starting width (multiple entries; one entry for each vertex) (optional; default = 0; multiple entries). Not used if constant width (code 43) is set |
| 41 | End width (multiple entries; one entry for each vertex) (optional; default = 0; multiple entries). Not used if constant width (code 43) is set |
| 42 | Bulge (multiple entries; one entry for each vertex) (optional; default = 0) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

MLINE

The following group codes apply to mline entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Mline group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbMline) |
| 2 | String of up to 32 characters. The name of the style used for this mline. An entry for this style must exist in the MLINESTYLE dictionary. NOTE Do not modify this field without also updating the associated entry in the MLINESTYLE dictionary |
| 340 | Pointer-handle/ID of MLINESTYLE object |
| 40 | Scale factor |
| 70 | Justification: 0 = Top, 1 = Zero, 2 = Bottom |
| 71 | Flags (bit-coded values): 1 = Has at least one vertex (code 72 is greater than 0); 2 = Closed; 4 = Suppress start caps; 8 = Suppress end caps |
| 72 | Number of vertices |
| 73 | Number of elements in MLINESTYLE definition |
| 10 | Start point (in WCS) DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of start point (in WCS) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |
| 11 | Vertex coordinates (multiple entries; one entry for each vertex) DXF: X value; APP: 3D point |
| 21, 31 | DXF: Y and Z values of vertex coordinates |
| 12 | Direction vector of segment starting at this vertex (multiple entries; one for each vertex) DXF: X value; APP: 3D vector |
| 22, 32 | DXF: Y and Z values of direction vector of segment starting at this vertex |
| 13 | Direction vector of miter at this vertex (multiple entries; one for each vertex) DXF: X value; APP: 3D vector |

Mline group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 23, 33 | DXF: Y and Z values of direction vector of miter |
| 74 | Number of parameters for this element (repeats for each element in segment) |
| 41 | Element parameters (repeats based on previous code 74) |
| 75 | Number of area fill parameters for this element (repeats for each element in segment) |
| 42 | Area fill parameters (repeats based on previous code 75) |

The group code 41 parameterization is a list of real values, one real per group code 41. The list may contain zero or more items. The first group code 41 value is the distance from the segment vertex along the miter vector to the point where the line element's path intersects the miter vector. The next group code 41 value is the distance along the line element's path from the point defined by the first group 41 to the actual start of the line element. The next is the distance from the start of the line element to the first break (or cut) in the line element. The successive group code 41 values continue to list the start and stop points of the line element in this segment of the mline. Linetypes do not affect group 41 lists.

The group code 42 parameterization is also a list of real values. Similar to the 41 parameterization, it describes the parameterization of the fill area for this mline segment. The values are interpreted identically to the 41 parameters and when taken as a whole for all line elements in the mline segment, they define the boundary of the fill area for the mline segment.

A common example of the use of the group code 42 mechanism is when an unfilled mline crosses over a filled mline and mledit is used to cause the filled mline to appear unfilled in the crossing area. This would result in two group 42s for each line element in the affected mline segment, one for the fill stop and one for the fill start.

The 2 group codes in mline entities and mlinestyle objects are redundant fields. These groups should not be modified under any circumstances, although it is safe to read them and use their values. The correct fields to modify are as follows:

| | |
|-------|---|
| Mline | The 340 group in the same object, which indicates the proper MLINestyle object. |
|-------|---|

Mlinestyle

The 3 group value in the MLINESTYLE dictionary which precedes the 350 group that has the handle or entity name of the current mlinestyle.

MTEXT

The following group codes apply to mtext entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Mtext group codes | |
|-------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbMText) |
| 10 | Insertion point DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of insertion point |
| 40 | Nominal (initial) text height |
| 41 | Reference rectangle width |
| 71 | Attachment point: 1 = Top left; 2 = Top center; 3 = Top right; 4 = Middle left; 5 = Middle center; 6 = Middle right; 7 = Bottom left; 8 = Bottom center; 9 = Bottom right |
| 72 | Drawing direction: 1 = Left to right; 3 = Top to bottom; 5 = By style (the flow direction is inherited from the associated text style) |
| 1 | Text string. If the text string is less than 250 characters, all characters appear in group 1. If the text string is greater than 250 characters, the string is divided into 250 character chunks, which appear in one or more group 3 codes. If group 3 codes are used, the last group is a group 1 and has fewer than 250 characters |
| 3 | Additional text (always in 250 character chunks) (optional) |
| 7 | Text style name (STANDARD if not provided) (optional) |

Mtext group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction (optional) |
| 11 | <i>X</i> -axis direction vector (in WCS) DXF: <i>X</i> value; APP: 3D vector NOTE A group code 50 (rotation angle in radians) passed as DXF input is converted to the equivalent direction vector (if both a code 50 and codes 11, 21, 31 are passed, the last one wins). This is provided as a convenience for conversions from text objects |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of <i>X</i> -axis direction vector (in WCS) |
| 42 | Horizontal width of the characters that make up the mtext entity. This value will always be equal to or less than the value of group code 41 (read-only, ignored if supplied) |
| 43 | Vertical height of the mtext entity (read-only, ignored if supplied) |
| 50 | Rotation angle in radians |
| 73 | Mtext line spacing style (optional): 1 = At least (taller characters will override) 2 = Exact (taller characters will not override) |
| 44 | Mtext line spacing factor (optional): Percentage of default (3-on-5) line spacing to be applied. Valid values range from 0.25 to 4.00 |

Xdata with the "DC015" application ID may follow an mtext entity. This contains information related to the dbConnect feature.

OLEFRAME

The following group codes apply to oleframe entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Oleframe group codes | |
|----------------------|------------------------------------|
| Group codes | Description |
| 100 | Subclass marker (AcDbOleFrame) |
| 70 | OLE version number |
| 90 | Length of binary data |
| 310 | Binary data (multiple lines) |
| 1 | End of OLE data (the string "OLE") |

OLE2FRAME

The following group codes apply to ole2frame entities. This information is read-only. During OPEN, the values are ignored because they are part of the OLE binary object, and are obtained via access functions. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Ole2frame group codes | |
|-----------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbOle2Frame) |
| 70 | OLE version number |
| 3 | Length of binary data |
| 10 | Upper left corner (WCS) DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of upper left corner (in WCS) |
| 11 | Lower right corner (WCS) DXF: X value; APP: 3D point |
| 21, 31 | DXF: Y and Z values of lower right corner (in WCS) |
| 71 | OLE object type, 1 = Link, 2 = Embedded, 3 = Static |

Ole2frame group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 72 | Tile mode descriptor: 0 = Object resides in model space 1 = Object resides in paper space |
| 90 | Length of binary data |
| 310 | Binary data (multiple lines) |
| 1 | End of OLE data (the string "OLE") |

Sample DXF output:

```
OLE2FRAME
5
2D
100
AcDbEntity
67
1
8
0
100
AcDbOle2Frame
70
2
3
Paintbrush Picture
10
4. 43116
20
5. 665992
30
0. 0
11
6. 4188
21
4. 244939
31
0. 0
71
2
72
1
90
23680
310
0155764BD60082B91140114B08C8F9A9164000000000000000506DC0D0D9AC
310
```

```

1940114B08C8F9A916400000000000000000506DC0D0D9AC194002303E5CD1FA
310
104000000000000000000000764BD60082B9114002303E5CD1FA10400000000000000
...
...

```

AutoLISP entnext function sample output:

```

Command: (setq e (entget e3))
((-1 . <Entity name: 7d50428>) (0 . "OLE2FRAME") (5 . "2D")
(100 . "AcDbEntity") (67 . 1) (8 . "0") (100 . "AcDbObjectFrame")
(70 . 2) (3 "Paintbrush Picture") (10 4.43116 5.66599 0.0)
(11 6.4188 4.24494 0.0) (71 . 2) (72 . 1))

```

POINT

The following group codes apply to point entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Point group codes | |
|-------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbPoint) |
| 10 | Point location (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of point location (in WCS) |
| 39 | Thickness (optional; default = 0) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction (optional) |
| 50 | Angle of the <i>X</i> axis for the UCS in effect when the point was drawn (optional, default = 0); used when PDMODE is nonzero |

POLYLINE

The following group codes apply to polyline entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Polyline group codes | |
|----------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDb2dPolyline or AcDb3dPolyline) |
| 66 | Obsolete; formerly an “entities follow flag” (optional; ignore if present) |
| 10 | DXF: always 0 APP: a “dummy” point; the X and Y values are always 0, and the Z value is the polyline’s elevation (in OCS when 2D, WCS when 3D) |
| 20 | DXF: always 0 |
| 30 | DXF: polyline’s elevation (in OCS when 2D, WCS when 3D) |
| 39 | Thickness (optional; default = 0) |
| 70 | Polyline flag (bit-coded); default is 0: 1 = This is a closed polyline (or a polygon mesh closed in the M direction) 2 = Curve-fit vertices have been added 4 = Spline-fit vertices have been added 8 = This is a 3D polyline 16 = This is a 3D polygon mesh 32 = The polygon mesh is closed in the N direction 64 = The polyline is a polyface mesh 128 = The linetype pattern is generated continuously around the vertices of this polyline |
| 40 | Default start width (optional; default = 0) |
| 41 | Default end width (optional; default = 0) |
| 71 | Polygon mesh M vertex count (optional; default = 0) |
| 72 | Polygon mesh N vertex count (optional; default = 0) |
| 73 | Smooth surface M density (optional; default = 0) |
| 74 | Smooth surface N density (optional; default = 0) |

Polyline group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 75 | Curves and smooth surface type (optional; default = 0); integer codes, not bit-coded: 0 = No smooth surface fitted 5 = Quadratic B-spline surface 6 = Cubic B-spline surface 8 = Bezier surface |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

Xdata with the "AUTOCAD_POSTSCRIPT_FIGURE" application ID may follow a polyline entity. This contains information related to PostScript images and PostScript fill information.

Polyface Meshes

A polyface mesh is represented in DXF as a variant of a polyline entity. The polyline header is identified as introducing a polyface mesh by the presence of the 64 bit in the polyline flags (70) group. The 71 group specifies the number of vertices in the mesh, and the 72 group specifies the number of faces. Although these counts are correct for all meshes created with the PFACE command, applications are not required to place correct values in these fields. Following the polyline header is a sequence of vertex entities that specify the vertex coordinates, then followed by faces that compose the mesh.

The AutoCAD entity structure imposes a limit on the number of vertices that a given face entity can specify. You can represent more complex polygons by decomposing them into triangular wedges. Their edges should be made invisible to prevent visible artifacts of this subdivision from being drawn. The PFACE command performs this subdivision automatically, but when applications generate polyface meshes directly, the applications must do this themselves. The number of vertices per face is the key parameter in this subdivision process. The PFACEVMAX system variable provides an application with the number of vertices per face entity. This value is read-only and is set to 4.

Polyface meshes created with the PFACE command are always generated with all the vertex coordinate entities first, followed by the face definition entities. The code within AutoCAD that processes polyface meshes requires this

ordering. Programs that generate polyface meshes in DXF should generate all the vertices then all the faces. However, programs that read polyface meshes from DXF should be tolerant of odd vertex and face ordering.

RAY

The following group codes apply to ray entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Ray group codes | |
|-----------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbRay) |
| 10 | Start point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of start point (in WCS) |
| 11 | Unit direction vector (in WCS) DXF: <i>X</i> value; APP: 3D vector |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of unit direction vector (in WCS) |

REGION

The following group codes apply to region entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Region group codes | |
|--------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbModelerGeometry) |
| 70 | Modeler format version number (currently = 1) |

Region group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 1 | Proprietary data (multiple lines < 255 characters each) |
| 3 | Additional lines of proprietary data (if previous group 1 string is greater than 255 characters) (optional) |

SEQEND

The following group codes apply to seqend entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Seqend group codes

| Group codes | Description |
|-------------|--|
| –2 | APP: name of entity that began the sequence. This entity marks the end of vertex (vertex type name) for a polyline, or the end of attribute entities (attrib type name) for an insert entity that has attributes (indicated) by 66 group present and nonzero in insert entity). This code is not saved in a DXF file |

SHAPE

The following group codes apply to shape entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Shape group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbShape) |
| 39 | Thickness (optional; default = 0) |
| 10 | Insertion point (in WCS) DXF: X value; APP: 3D point |

Shape group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 20, 30 | DXF: Y and Z values of insertion point (in WCS) |
| 40 | Size |
| 2 | Shape name |
| 50 | Rotation angle (optional; default = 0) |
| 41 | Relative X scale factor (optional; default = 1) |
| 51 | Oblique angle (optional; default = 0) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

SOLID

The following group codes apply to solid entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Solid group codes

| Group codes | Description |
|-------------|--|
| 100 | Subclass marker (AcDbTrace) |
| 10 | First corner DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of first corner |
| 11 | Second corner DXF: X value; APP: 3D point |
| 21, 31 | DXF: Y and Z values of second corner |
| 12 | Third corner XF: X value; APP: 3D point |

Solid group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 22, 32 | DXF: Y and Z values of third corner |
| 13 | Fourth corner. If only three corners are entered to define the SOLID, then the fourth corner coordinate is the same as the third. DXF: X value; APP: 3D point |
| 23, 33 | DXF: Y and Z values of fourth corner |
| 39 | Thickness (optional; default = 0) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

SPLINE

The following group codes apply to spline entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Spline group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbSpline) |
| 210 | Normal vector (omitted if the spline is nonplanar) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of normal vector (optional) |
| 70 | Spline flag (bit coded): 1 = Closed spline 2 = Periodic spline 4 = Rational spline 8 = Planar 16 = Linear (planar bit is also set) |
| 71 | Degree of the spline curve |

Spline group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 72 | Number of knots |
| 73 | Number of control points |
| 74 | Number of fit points (if any) |
| 42 | Knot tolerance (default = 0.0000001) |
| 43 | Control-point tolerance (default = 0.0000001) |
| 44 | Fit tolerance (default = 0.0000000001) |
| 12 | Start tangent—may be omitted (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 22, 32 | DXF: <i>Y</i> and <i>Z</i> values of start tangent—may be omitted (in WCS) |
| 13 | End tangent—may be omitted (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 23, 33 | DXF: <i>Y</i> and <i>Z</i> values of end tangent—may be omitted (in WCS) |
| 40 | Knot value (one entry per knot) |
| 41 | Weight (if not 1); with multiple group pairs, are present if all are not 1 |
| 10 | Control points (in WCS), one entry per control point DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of control points (in WCS), one entry per control point |
| 11 | Fit points (in WCS), one entry per fit point DXF: <i>X</i> value; APP: 3D point |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of fit points (in WCS), one entry per fit point |

TEXT

The following group codes apply to text entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#).

For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Text group codes | |
|------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbText) |
| 39 | Thickness (optional; default = 0) |
| 10 | First alignment point (in OCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of first alignment point (in OCS) |
| 40 | Text height |
| 1 | Default value (the string itself) |
| 50 | Text rotation (optional; default = 0) |
| 41 | Relative <i>X</i> scale factor—width (optional; default = 1) This value is also adjusted when fit-type text is used |
| 51 | Oblique angle (optional; default = 0) |
| 7 | Text style name (optional, default = STANDARD) |
| 71 | Text generation flags (optional, default = 0): 2 = Text is backward (mirrored in <i>X</i>) 4 = Text is upside down (mirrored in <i>Y</i>) |
| 72 | Horizontal text justification type (optional, default = 0) integer codes (not bit-coded) 0 = Left; 1 = Center; 2 = Right 3 = Aligned (if vertical alignment = 0) 4 = Middle (if vertical alignment = 0) 5 = Fit (if vertical alignment = 0) See the Group 72 and 73 integer codes table for clarification |
| 11 | Second alignment point (in OCS) (optional) DXF: <i>X</i> value; APP: 3D point This value is meaningful only if the value of a 72 or 73 group is nonzero (if the justification is anything other than baseline/left) |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of second alignment point (in OCS) (optional) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |

Text group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |
| 100 | Subclass marker (AcDbText) |
| 73 | Vertical text justification type (optional, default = 0): integer codes (not bit-coded): 0 = Baseline; 1 = Bottom; 2 = Middle; 3 = Top See the Group 72 and 73 integer codes table for clarification |

The following table describes the group codes 72 (horizontal alignment) and 73 (vertical alignment) in greater detail.

Group 72 and 73 integer codes

| Group 73 | Group 72 | | | | | |
|--------------|----------|---------|--------|---------|--------|-----|
| | 0 | 1 | 2 | 3 | 4 | 5 |
| 3 (top) | TLeft | TCenter | TRight | | | |
| 2 (middle) | MLeft | MCenter | MRight | | | |
| 1 (bottom) | BLeft | BCenter | BRight | | | |
| 0 (baseline) | Left | Center | Right | Aligned | Middle | Fit |

If group 72 and/or 73 values are nonzero then the first alignment point values are ignored and AutoCAD calculates new values based on the second alignment point and the length and height of the text string itself (after applying the text style). If the 72 and 73 values are zero or missing, then the second alignment point is meaningless.

TOLERANCE

The following group codes apply to tolerance entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Tolerance group codes | |
|-----------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbFcf) |
| 3 | Dimension style name |
| 10 | Insertion point (in WCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of insertion point (in WCS) |
| 1 | String representing the visual representation of the tolerance |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction (optional) |
| 11 | X-axis direction vector (in WCS) DXF: <i>X</i> value; APP: 3D vector |
| 21, 31 | DXF: <i>Y</i> and <i>Z</i> values of X-axis direction vector (in WCS) |

TRACE

The following group codes apply to trace entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Trace group codes | |
|-------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbTrace) |
| 10 | First corner (in OCS) DXF: <i>X</i> value; APP: 3D point |
| 20, 30 | DXF: <i>Y</i> and <i>Z</i> values of first corner (in OCS) |
| 11 | Second corner (in OCS) DXF: <i>X</i> value; APP: 3D point |

Trace group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 21, 31 | DXF: Y and Z values of second corner (in OCS) |
| 12 | Third corner (in OCS) DXF: X value; APP: 3D point |
| 22, 32 | DXF: Y and Z values of third corner (in OCS) |
| 13 | Fourth corner (in OCS) DXF: X value; APP: 3D point |
| 23, 33 | DXF: Y and Z values of fourth corner (in OCS) |
| 39 | Thickness (optional; default = 0) |
| 210 | Extrusion direction (optional; default = 0, 0, 1) DXF: X value; APP: 3D vector |
| 220, 230 | DXF: Y and Z values of extrusion direction (optional) |

VERTEX

The following group codes apply to vertex entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Vertex group codes

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (AcDbVertex) |
| 100 | Subclass marker (AcDb2dVertex or AcDb3dPolylineVertex) |
| 10 | Location point (in OCS when 2D, and WCS when 3D) DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of location point (in OCS when 2D, and WCS when 3D) |
| 40 | Starting width (optional; default is 0) |

Vertex group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 41 | Ending width (optional; default is 0) |
| 42 | Bulge (optional; default is 0). The bulge is the tangent of one fourth the included angle for an arc segment, made negative if the arc goes clockwise from the start point to the endpoint. A bulge of 0 indicates a straight segment, and a bulge of 1 is a semicircle |
| 70 | Vertex flags: 1 = Extra vertex created by curve-fitting 2 = Curve-fit tangent defined for this vertex. A curve-fit tangent direction of 0 may be omitted from DXF output but is significant if this bit is set 4 = Not used 8 = Spline vertex created by spline-fitting 16 = Spline frame control point 32 = 3D polyline vertex 64 = 3D polygon mesh 128 = Polyface mesh vertex |
| 50 | Curve fit tangent direction |
| 71 | Polyface mesh vertex index. Optional. Present only if nonzero |
| 72 | Polyface mesh vertex index. Optional. Present only if nonzero |
| 73 | Polyface mesh vertex index. Optional. Present only if nonzero |
| 74 | Polyface mesh vertex index. Optional. Present only if nonzero |

Every vertex that is part of a polyface mesh has its vertex flag 128 bit set. If the entity supplies the coordinate of a vertex of the mesh, its 64 bit is set as well, and the 10, 20, 30 groups give the vertex coordinate. The vertex index values are determined by the order in which the vertex entities appear within the polyline, with the first being numbered 1.

If the vertex defines a face of the mesh, its vertex flags group has the 128 bit set but not the 64 bit. In this case, the 10, 20, 30 (location) groups of the face entity are irrelevant and are always written as 0 in a DXF file. The vertex indexes that define the mesh are given by 71, 72, 73, and 74 group codes, the values of which specify one of the previously defined vertexes by index. If the

index is negative, the edge that begins with that vertex is invisible. The first 0 vertex marks the end of the vertices of the face.

VIEWPORT

The following group codes apply to viewport entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Viewport group codes | |
|----------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbViewport) |
| 10 | Center point (in WCS) DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of center point (in WCS) |
| 40 | Width in paper space units |
| 41 | Height in paper space units |
| 68 | Viewport status field: -1 = On, but is fully off screen, or is one of the viewports that is not active because the \$MAXACTVP count is currently being exceeded. 0 = Off <positive value > = On and active. The value indicates the order of stacking for the viewports, where 1 is the active viewport, 2 is the next, and so forth |
| 69 | Viewport ID |
| 12 | View center point (in DCS) DXF: X value; APP: 2D point |
| 22 | DXF: View center point Y value (in DCS) |

Viewport group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 13 | Snap base point DXF: <i>X</i> value; APP: 2D point |
| 23 | DXF: Snap base point <i>Y</i> value |
| 14 | Snap spacing DXF: <i>X</i> value; APP: 2D point |
| 24 | DXF: Snap spacing <i>Y</i> value |
| 15 | Grid spacing DXF: <i>X</i> value; APP: 2D point |
| 25 | DXF: Grid spacing <i>Y</i> value |
| 16 | View direction vector (in WCS) DXF: <i>X</i> value; APP: 3D vector |
| 26, 36 | DXF: <i>Y</i> and <i>Z</i> values of view direction vector (in WCS) |
| 17 | View target point (in WCS) DXF: <i>X</i> value; APP: 3D vector |
| 27, 37 | DXF: <i>Y</i> and <i>Z</i> values of view target point (in WCS) |
| 42 | Perspective lens length |
| 43 | Front clip plane <i>Z</i> value |
| 44 | Back clip plane <i>Z</i> value |
| 45 | View height (in model space units) |
| 50 | Snap angle |
| 51 | View twist angle |
| 72 | Circle zoom percent |
| 341 | Frozen layer object ID/handle (multiple entries may exist) (optional) |

Viewport group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 90 | <p>Viewport status bit coded flags:</p> <ul style="list-style-type: none"> 1 (0x1) = Enables perspective mode 2 (0x2) = Enables front clipping 4 (0x4) = Enables back clipping 8 (0x8) = Enables UCS follow 16 (0x10) = Enables front clip not at eye 32 (0x20) = Enables UCS icon visibility 64 (0x40) = Enables UCS icon at origin 128 (0x80) = Enables fast zoom 256 (0x100) = Enables snap mode 512 (0x200) = Enables grid mode 1024 (0x400) = Enables isometric snap style 2048 (0x800) = Enables hide plot mode 4096 (0x1000) = kIsoPairTop. If set and kIsoPairRight is not set, then isopair top is enabled. If both kIsoPairTop and kIsoPairRight are set, then isopair left is enabled 8192 (0x2000) = kIsoPairRight. If set and kIsoPairTop is not set, then isopair right is enabled 16384 (0x4000) = Enables viewport zoom locking 32768 (0x8000) = Currently always enabled 65536 (0x10000) = Enables non-rectangular clipping 131072 (0x20000) = Turns the viewport off |
| 340 | Hard-pointer ID/handle to entity that serves as the viewport's clipping boundary (only present if viewport is non-rectangular) |
| 1 | Plot style sheet name assigned to this viewport |
| 281 | <p>Render mode:</p> <ul style="list-style-type: none"> 0 = 2D Optimized (classic 2D) 1 = Wireframe 2 = Hidden line 3 = Flat shaded 4 = Gouraud shaded 5 = Flat shaded with wireframe 6 = Gouraud shaded with wireframe <p>All rendering modes other than 2D Optimized engage the new 3D graphics pipeline. These values directly correspond to the SHADEMODE command and the <code>AcDbAbstractViewTableRecord::RenderMode</code> enum</p> |
| 71 | <p>UCS per viewport flag:</p> <ul style="list-style-type: none"> 0 = The UCS will not change when this viewport becomes active. 1 = This viewport stores its own UCS which will become the current UCS whenever the viewport is activated |

Viewport group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 74 | Display UCS icon at UCS origin flag: Controls whether UCS icon represents viewport UCS or current UCS (these will be different if UCSVP is 1 and viewport is not active). However, this field is currently being ignored and the icon always represents the viewport UCS |
| 110 | UCS origin DXF: <i>X</i> value; APP: 3D point |
| 120, 130 | DXF: <i>Y</i> and <i>Z</i> values of UCS origin |
| 111 | UCS <i>X</i> -axis DXF: <i>X</i> value; APP: 3D vector |
| 121, 131 | DXF: <i>Y</i> and <i>Z</i> values of UCS <i>X</i> -axis |
| 112 | UCS <i>Y</i> -axis DXF: <i>X</i> value; APP: 3D vector |
| 122, 132 | DXF: <i>Y</i> and <i>Z</i> values of UCS <i>Y</i> -axis |
| 345 | ID/handle of AcDbUCSTableRecord if UCS is a named UCS. If not present, then UCS is unnamed |
| 346 | ID/handle of AcDbUCSTableRecord of base UCS if UCS is orthographic (79 code is non-zero). If not present and 79 code is non-zero, then base UCS is taken to be WORLD |
| 79 | Orthographic type of UCS 0 = UCS is not orthographic; 1 = Top; 2 = Bottom; 3 = Front; 4 = Back; 5 = Left; 6 = Right |
| 146 | Elevation |

NOTE The ZOOM XP factor is calculated with the following formula:
group_41 / group_45 (or pspace_height / mspace_height).

XLINE

The following group codes apply to xline entities. In addition to the group codes described here, see [“Common Group Codes for Entities” on page 60](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Xline group codes | |
|-------------------|--|
| Group codes | Description |
| 100 | Subclass marker (AcDbXline) |
| 10 | First point (in WCS) DXF: X value; APP: 3D point |
| 20, 30 | DXF: Y and Z values of first point (in WCS) |
| 11 | Unit direction vector (in WCS) DXF: X value; APP: 3D vector |
| 21, 31 | DXF: Y and Z values of unit direction vector (in WCS) |

OBJECTS Section

7

This chapter presents the group codes that apply to non-graphical objects. These codes are found in the OBJECTS section of a DXF™ file and are used by AutoLISP® and ObjectARX™ applications in entity definition lists.

In this chapter

- OBJECT Section Group Codes
- Common Group Codes for Objects
- ACAD_PROXY_OBJECT
- ACDBDICTIONARYWDFLT
- ACDBPLACEHOLDER
- DICTIONARY
- DICTIONARYVAR
- DIMASSOC
- GROUP
- IDBUFFER
- IMAGEDEF
- IMAGEDEF_REACTOR
- LAYER_INDEX
- LAYER_FILTER
- LAYOUT
- MLINestyle
- OBJECT_PTR
- PLOTSETTINGS
- RASTERVARIABLES
- SPATIAL_INDEX
- SPATIAL_FILTER
- SORTENTSTABLE
- VLA_PROJECT
- XRECORD

OBJECT Section Group Codes

Objects are similar to entities, except that they have no graphical or geometric meaning. All objects that are not entities or symbol table records or symbol tables are stored in this section. This section represents a homogeneous heap of objects with topological ordering of objects by ownership, such that the owners always appear before the objects they own.

Object Ownership

The root owner of most objects appearing in the OBJECTS section is the named object dictionary, which is, therefore, always the first object that appears in this section. Objects that are not owned by the named object dictionary are owned by other entities, objects, or symbol table entries. Objects in this section may be defined by AutoCAD® or by applications with access to ObjectARX™ API. The DXF names of application-defined object types should always be associated with a class name in the CLASS section of the DXF file, or else the object record cannot be bound to the application that will interpret it.

As with other dictionaries, the named-object dictionary record consists solely of associated pairs of entry names and hard ownership pointer references to the associated object.

To avoid name collision between objects, developers should always use their registered developer prefix for their entries.

Common Group Codes for Objects

The following table shows group codes that apply to virtually all nongraphical objects. When you refer to a table of group codes by object type, a list of codes associated a *specific* object, keep in mind that the codes shown here can also be present. Some of the group codes are included with an object only if the object has nondefault values for those group code properties. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| Common object group codes | |
|----------------------------------|--|
| Group codes | Description |
| 0 | Object type |
| 5 | Handle |
| 102 | Start of application defined group “{ <i>application_name</i> ” (optional) |
| <i>application-defined codes</i> | Codes and values within the 102 groups are application-defined (optional) |
| 102 | End of group, “}” (optional) |
| 102 | “{ACAD_REACTORS” indicates the start of the AutoCAD® persistent reactors group. This group exists only if persistent reactors have been attached to this object (optional) |
| 330 | Soft pointer ID/handle to owner dictionary (optional) |
| 102 | End of group, “}” (optional) |
| 102 | “{ACAD_XDICTIONARY” indicates the start of an extension dictionary group. This group exists only if persistent reactors have been attached to this object (optional) |
| 360 | Hard owner ID/handle to owner dictionary (optional) |
| 102 | End of group, “}” (optional) |
| 330 | Soft-pointer ID/handle to owner object |

ACAD_PROXY_OBJECT

The following group codes apply to ACAD_PROXY_OBJECT objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

ACAD_PROXY_OBJECT group codes

| Group codes | Description |
|--------------------------|--|
| 100 | DXF™: Subclass marker (AcDbProxyObject) |
| 90 | DXF: Proxy object class ID (always 499) |
| 91 | DXF: Application object's class ID. Class IDs are based on the order of the class in the CLASSES section. The first class is given the ID of 500, the next is 501, and so on |
| 93 | DXF: Size of object data in bits |
| 310 | DXF: Binary object data (multiple entries can appear) (optional) |
| 330 or 340 or 350 or 360 | DXF: An object ID (multiple entries can appear) (optional) |
| 94 | DXF: 0 (indicates end of object ID section) |
| 95 | DXF: Object drawing format when it becomes a proxy (a 32-bit unsigned integer): Low word is AcDbDwgVersion High word is MaintenanceReleaseVersion |
| 70 | DXF: Original custom object data format: 0 = DWG format 1 = DXF format |

The 92 field is not used for AcDbProxyObject. Objects of this class never have graphics.

ACDBDICTIONARYWDFLT

The following group codes are used by ACDBDICTIONARYWDFLT objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

ACDBDICTIONARYWDFLT group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (ACDBDICTIONARYWDFLT) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always "}" |
| 330 | Soft-owner ID/handle to owner object |
| 100 | Subclass marker (AcDbDictionary) |
| 281 | Duplicate record cloning flag (determines how to merge duplicate entries): 0 = Not applicable 1 = Keep existing 2 = Use clone 3 = <xref>\$0\$<name> 4 = \$0\$<name> 5 = Unmangle name |
| 3 | Entry name (one for each entry) |
| 350 | Soft-owner ID/handle to entry object (one for each entry) |
| 100 | Subclass marker (AcDbDictionaryWithDefault) |
| 340 | Hard pointer to default object ID/handle (currently only used for plot style dictionary's default entry, named "Normal") |

ACDBPLACEHOLDER

The following group codes are used by the ACDBPLACEHOLDER objects. In addition to the group codes described here, see “[Common Group Codes for Objects](#)” on page 116. For information about abbreviations and formatting used in this table, see “[Formatting Conventions in This Reference](#)” on page 6.

ACDBPLACEHOLDER group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (ACDBPLACEHOLDER) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always "}" |
| 330 | Soft-pointer ID/handle to owner object |

DICTIONARY

The following group codes are used by DICTIONARY objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

DICTIONARY group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (DICTIONARY) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always "}" |
| 330 | Soft-pointer ID/handle to owner object |
| 100 | Subclass marker (AcDbDictionary) |
| 280 | Hard owner flag. If set to 1, indicates that elements of the dictionary are to be treated as hard owned |

DICTIONARY group codes (continued)

| Group codes | Description |
|-------------|---|
| 281 | Duplicate record cloning flag (determines how to merge duplicate entries): 0 = Not applicable 1 = Keep existing 2 = Use clone 3 = <xref>\$0\$<name> 4 = \$0\$<name> 5 = Unmangle name |
| 3 | Entry name (one for each entry) (optional) |
| 350 | Soft-owner ID/handle to entry object (one for each entry) (optional) |

AutoCAD® maintains items such as mline styles and group definitions as objects in dictionaries. The following sections describe the AutoCAD object group codes maintained in dictionaries; however, other applications are free to create and use their own dictionaries as they see fit. The prefix "ACAD_" is reserved for use by AutoCAD applications.

DICTIONARYVAR

The following group codes are used by DICTIONARYVAR objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

DICTIONARYVAR group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (DICTIONARYVAR) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary (ACDBVARIABLEDICTIONARY) |
| 102 | End of persistent reactors group, always "}" |

DICTIONARYVAR group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 100 | Subclass marker (DictionaryVariables) |
| 280 | Object schema number (currently set to 0) |
| 1 | Value of variable |

DICTIONARYVAR objects are used by AutoCAD as a means to store named values in the database for setvar/getvar purposes without the need to add entries to the DXF™ HEADER section. Currently, the system variables that are stored as DICTIONARYVAR objects are: DIMADEC, DIMDSEP, INDEXCTL, PROJECTNAME, and XCLIPFRAME.

DIMASSOC

The following group codes are used by DIMASSOC objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

DIMASSOC group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (DIMASSOC) |
| 5 | Handle |
| 102 | Persistent reactors group; always “{ACAD_REACTORS}” |
| 330 | Soft-pointer ID |
| 100 | Subclass marker (AcDbDimAssoc) |
| 330 | ID of dimension object |

DIMASSOC group codes (continued)

| Group codes | Description |
|-------------|--|
| 90 | Associativity flag 1 = First point reference 2 = Second point reference 4 = Third point reference 8 = Fourth point reference |
| 70 | Trans-space flag (true/false) |
| 71 | Rotated Dimension type (parallel, perpendicular) |
| 1 | Class name (AcDbOsnapPointRef) |
| 72 | Object Osnap type (Start, End, Mid, Cen, etc.) |
| 331 | ID of main object (geometry) |
| 73 | SubentType of main object (edge, face) |
| 91 | GsMarker of main object (index) |
| 301 | Handle (string) of Xref object |
| 40 | Geometry parameter for Near Osnap |
| 10 | Osnap point in WCS; X value |
| 20 | Osnap point in WCS; Y value |
| 30 | Osnap point in WCS; Z value |
| 332 | ID of intersection object (geometry) |
| 74 | SubentType of intersection object (edge/face) |
| 92 | GsMarker of intersection object (index) |
| 302 | Handle (string) of intersection Xref object |
| 75 | hasLastPointRef flag (true/false) |

DIMASSOC objects implement associative dimensions by specifying an association between a dimension object and drawing geometry objects. An

associative dimension is a dimension that will automatically update when the associated geometry is modified.

GROUP

The following group codes are used by GROUP objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| GROUP group codes | |
|-------------------|--|
| Group codes | Description |
| 0 | Object name (GROUP) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” (persistent reactors group appears in all dictionaries except the main dictionary) |
| 330 | Soft-pointer ID/handle to owner dictionary. For GROUP objects this is always the ACAD_GROUP entry of the named object dictionary |
| 102 | End of persistent reactors group, always “}” |
| 330 | Soft-pointer ID/handle to owner object |
| 100 | Subclass marker (AcDbGroup) |
| 300 | Group description |
| 70 | “Unnamed” flag: 1 = Unnamed; 0 = Named |
| 71 | Selectability flag: 1 = Selectable; 0 = Not selectable |
| 340 | Hard-pointer handle to entity in group (one entry per object) |

IDBUFFER

The following group codes are used by IDBUFFER objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| IDBUFFER group codes | |
|----------------------|---|
| Group codes | Description |
| 100 | Subclass marker (AcDbIdBuffer) |
| 330 | Soft pointer reference to entity (multiple entries may exist) |

The IDBUFFER object is a utility object that is just a list of references to objects.

IMAGEDEF

The following group codes are used by IMAGEDEF objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

IMAGEDEF group codes

| Group codes | Description |
|-------------|--|
| 0 | Object name (IMAGEDEF) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to the ACAD_IMAGE_DICT dictionary |
| 330 | Soft-pointer ID/handle to IMAGEDEF_REACTOR object (multiple entries; one for each instance) |
| 102 | End of persistent reactors group, always "}" |
| 100 | Subclass marker (AcDbRasterImageDef) |
| 90 | Class version. 0 = R14 version |
| 1 | File name of image |
| 10 | Image size in pixels DXF: <i>U</i> value; APP: 2D point (<i>U</i> and <i>V</i> values) |
| 20 | DXF: <i>V</i> value of image size in pixels |
| 11 | Default size of one pixel in AutoCAD units DXF: <i>U</i> value; APP: 2D point (<i>U</i> and <i>V</i> values) |
| 12 | DXF: <i>V</i> value of pixel size |
| 280 | Image-is-loaded flag. 0 = Unloaded; 1 = Loaded |
| 281 | Resolution units. 0 = No units; 2 = Centimeters; 5 = Inch |

IMAGEDEF_REACTOR

The following group codes are used by IMAGEDEF_REACTOR objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

IMAGEDEF_REACTOR group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (IMAGEDEF_REACTOR) |
| 5 | Handle |
| 100 | Subclass marker (AcDbRasterImageDefReactor) |
| 90 | Class version. 2 = R14 version |
| 330 | Object ID for associated image object |

LAYER_INDEX

The following group codes are used by LAYER_INDEX objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

LAYER_INDEX group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (LAYER_INDEX) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always “}” |
| 100 | Subclass marker (AcDbIndex) |
| 40 | Time stamp (Julian date) |
| 100 | Subclass marker (AcDbLayerIndex) |
| 8 | Layer name (multiple entries may exist) |
| 360 | Hard owner reference to IDBUFFER (multiple entries may exist) |
| 90 | Number of entries in the IDBUFFER list (multiple entries may exist) |

LAYER_FILTER

The following group codes are used by LAYER_FILTER objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

LAYER_FILTER group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (LAYER_FILTER) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always “}” |
| 100 | Subclass marker (AcDbFilter) |
| 100 | Subclass marker (AcDbLayerFilter) |
| 8 | Layer name (multiple entries may exist) |

LAYOUT

The following group codes are used by LAYOUT objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

LAYOUT group codes

| Group codes | Description |
|-------------|----------------------|
| 0 | Object name (LAYOUT) |
| 5 | Handle |

LAYOUT group codes (*continued*)

| Group codes | Description |
|--|---|
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always "}" |
| 330 | Soft-pointer ID/handle to owner object |
| 100 | Subclass marker (AcDbPlotSettings) |
| <i>plotsettings object group codes</i> | For group codes and descriptions following the AcDbPlotSettings marker, see "PLOTSETTINGS" on page 133 |
| 100 | Subclass marker (AcDbLayout) |
| 1 | Layout name |
| 70 | Flag (bit-coded) to control the following: 1 = Indicates the PSLTSCALE value for this layout when this layout is current 2 = Indicates the LIMCHECK value for this layout when this layout is current |
| 71 | Tab order. This number is an ordinal indicating this layout's ordering in the tab control that is attached to the AutoCAD drawing frame window. Note that the "Model" tab always appears as the first tab regardless of its tab order |
| 10 | Minimum limits for this layout (defined by LIMMIN while this layout is current) DXF: X value; APP: 2D point |
| 20 | DXF: Y value of minimum limits |
| 11 | Maximum limits for this layout (defined by LIMMAX while this layout is current): DXF: X value; APP: 2D point |
| 21 | DXF: Y value of maximum limits |
| 12 | Insertion base point for this layout (defined by INSBASE while this layout is current): DXF: X value; APP: 3D point |
| 22, 32 | DXF: Y and Z values of the insertion base point |

LAYOUT group codes (continued)

| Group codes | Description |
|-------------|--|
| 14 | Minimum extents for this layout (defined by EXTMIN while this layout is current): DXF: <i>X</i> value; APP: 3D point |
| 24, 34 | DXF: <i>Y</i> and <i>Z</i> values of the minimum extents |
| 15 | Maximum extents for this layout (defined by EXTMAX while this layout is current): DXF: <i>X</i> value; APP: 3D point |
| 25, 35 | DXF: <i>Y</i> and <i>Z</i> values of the maximum extents |
| 146 | Elevation |
| 13 | UCS origin DXF: <i>X</i> value; APP: 3D point |
| 23, 33 | DXF: <i>Y</i> and <i>Z</i> values of UCS origin |
| 16 | UCS <i>X</i> -axis DXF: <i>X</i> value; APP: 3D vector |
| 26, 36 | DXF: <i>Y</i> and <i>Z</i> values of UCS <i>X</i> -axis |
| 17 | UCS <i>Y</i> -axis DXF: <i>X</i> value; APP: 3D vector |
| 27, 37 | DXF: <i>Y</i> and <i>Z</i> values of UCS <i>Y</i> -axis |
| 76 | Orthographic type of UCS 0 = UCS is not orthographic; 1 = Top; 2 = Bottom; 3 = Front; 4 = Back; 5 = Left; 6 = Right |
| 330 | ID/handle to this layout's associated paper space block table record |
| 331 | ID/handle to the viewport that was last active in this layout when the layout was current |
| 345 | ID/handle of AcDbUCSTableRecord if UCS is a named UCS. If not present, then UCS is unnamed |
| 346 | ID/handle of AcDbUCSTableRecord of base UCS if UCS is orthographic (76 code is non-zero). If not present and 76 code is non-zero, then base UCS is taken to be WORLD |

MLINESTYLE

The following group codes are used by MLINESTYLE objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| MLINESTYLE group codes | |
|------------------------|---|
| Group codes | Description |
| 0 | Object name (MLINESTYLE) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” (persistent reactors group appears in all dictionaries except the main dictionary) |
| 330 | Soft-pointer ID/handle to owner dictionary. For MLINESTYLE objects this is always the ACAD_MLINESTYLE entry of the named object dictionary |
| 102 | End of persistent reactors group; always “}” |
| 100 | Subclass marker (AcDbMlineStyle) |
| 2 | Mline style name |
| 70 | Flags (bit-coded): 1 = Fill on 2 = Display miters 16 = Start square end (line) cap 32 = Start inner arcs cap 64 = Start round (outer arcs) cap 256 = End square (line) cap 512 = End inner arcs 1024 = End round (outer arcs) cap |
| 3 | Style description (string, 255 characters maximum) |
| 62 | Fill color (integer, default = 256) |
| 51 | Start angle (real, default is 90 degrees) |
| 52 | End angle (real, default is 90 degrees) |
| 71 | Number of elements |

MLINESTYLE group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 49 | Element offset (real, no default). Multiple entries can exist; one entry for each element |
| 62 | Element color (integer, default = 0). Multiple entries can exist; one entry for each element |
| 6 | Element linetype (string, default = BYLAYER). Multiple entries can exist; one entry for each element |

The 2 group codes in mline entities and MLINESTYLE objects are redundant fields. These groups should not be modified under any circumstances, although it is safe to read them and use their values. The correct fields to modify are:

| | |
|------------|--|
| Mline | The 340 group in the same object, which indicates the proper MLINESTYLE object. |
| Mlinestyle | The 3 group value in the MLINESTYLE dictionary, which precedes the 350 group that has the handle or entity name of the current mlinestyle. |

OBJECT_PTR

The following group codes are used by OBJECT_PTR objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

OBJECT_PTR group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (OBJECT_PTR) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always “}” |

OBJECT_PTR group codes (*continued*)

| Group codes | Description |
|-------------|-------------------------|
| 1001 | Begin ASE xdata (DC015) |

PLOTSETTINGS

The following group codes are used by PLOTSETTINGS objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

PLOTSETTINGS group codes

| Group codes | Description |
|-------------|--|
| 0 | Object name (PLOTSETTINGS) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always “}” |
| 330 | Soft-pointer ID/handle to owner object |
| 100 | Subclass marker (AcDbPlotSettings) |
| 1 | Page Setup name |
| 2 | Name of system printer or plot configuration file |
| 4 | Paper size |
| 6 | Plot view name |
| 40 | Size, in millimeters, of unprintable margin on the left side of the paper |
| 41 | Size, in millimeters, of unprintable margin on the bottom of the paper |
| 42 | Size, in millimeters, of unprintable margin on the right side of the paper |
| 43 | Size, in millimeters, of unprintable margin on the top of the paper |

PLOTSETTINGS group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 44 | Plot paper size: physical paper width in millimeters |
| 45 | Plot paper size: physical paper height in millimeters |
| 46 | Plot origin: <i>X</i> value of origin offset in millimeters |
| 47 | Plot origin: <i>Y</i> value of origin offset in millimeters |
| 48 | Plot window area: <i>X</i> value of lower left window corner |
| 49 | Plot window area: <i>Y</i> value of upper right window corner |
| 140 | Plot window area: <i>X</i> value of lower left window corner |
| 141 | Plot window area: <i>Y</i> value of upper right window corner |
| 142 | Numerator of custom print scale: real world (paper) units |
| 143 | Denominator of custom print scale: drawing units |
| 70 | Plot layout flag: 1 = PlotViewportBorders 2 = ShowPlotStyles 4 = PlotCentered 8 = PlotHidden 16 = UseStandardScale 32 = PlotPlotStyles 64 = ScaleLineweights 128 = PrintLineweights 512 = DrawViewportsFirst 1024 = ModelType 2048 = UpdatePaper 4096 = ZoomToPaperOnUpdate 8192 = Initializing 16384 = PrevPlotInit |
| 72 | Plot paper units: 0 = Plot in inches 1 = Plot in millimeters 2 = Plot in pixels |
| 73 | Plot rotation: 0 = No rotation 1 = 90 degrees counterclockwise 2 = Upside down 3 = 90 degrees clockwise |

PLOTSETTINGS group codes (continued)

| Group codes | Description |
|-------------|---|
| 74 | Plot type (portion of paperspace to output to the media): 0 = Last screen display 1 = Drawing extents 2 = Drawing limits 3 = View specified by code 6 4 = Window specified by codes 48, 49, 140, and 141 5 = Layout information |
| 7 | Current style sheet |
| 75 | Standard scale type: 0 = Scaled to Fit 1 = 1/128"=1'; 2 = 1/64"=1'; 3 = 1/32"=1' 4 = 1/16"=1'; 5 = 3/32"=1'; 6 = 1/8"=1' 7 = 3/16"=1'; 8 = 1/4"=1'; 9 = 3/8"=1' 10 = 1/2"=1'; 11 = 3/4"=1'; 12 = 1"=1' 13 = 3"=1'; 14 = 6"=1'; 15 = 1'=1' 16 = 1:1; 17 = 1:2; 18 = 1:4; 19 = 1:8; 20 = 1:10; 21 = 1:16 22 = 1:20; 23 = 1:30; 24 = 1:40; 25 = 1:50; 26 = 1:100 27 = 2:1; 28 = 4:1; 29 = 8:1; 30 = 10:1; 31 = 100:1; 32 = 1000:1 |
| 147 | A floating point scale factor that represents the standard scale value specified in code 75 |
| 148 | Paper image origin: X value |
| 149 | Paper image origin: Y value |

RASTERVARIABLES

The following group codes are used by RASTERVARIABLES objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

RASTERVARIABLES group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (RASTERVARIABLES) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” |

RASTERVARIABLES group codes (*continued*)

| Group codes | Description |
|-------------|--|
| 330 | Soft-pointer ID/handle to owner dictionary. For a RASTERVARIABLES object this is always the ACAD_IMAGE_VARS entry of the named object dictionary |
| 102 | End of persistent reactors group, always "}" |
| 100 | Subclass marker (AcDbRasterVariables) |
| 90 | Class version. 0 = R14 version |
| 70 | Display-image-frame flag. 0 = No frame; 1 = Display frame |
| 71 | Image display quality (screen only). 0 = Draft; 1 = High |
| 72 | AutoCAD units for inserting images. This is what one AutoCAD unit is equal to for the purpose of inserting and scaling images with an associated resolution: 0 = None; 1 = Millimeter; 2 = Centimeter; 3 = Meter; 4 = Kilometer; 5 = Inch; 6 = Foot; 7 = Yard; 8 = Mile |

SPATIAL_INDEX

The following group codes are used by SPATIAL_INDEX objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

SPATIAL_INDEX group codes

| Group codes | Description |
|-------------|---|
| 0 | Object name (SPATIAL_INDEX) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always "}" |
| 100 | Subclass marker (AcDbIndex) |

SPATIAL_INDEX group codes (continued)

| Group codes | Description |
|-------------|------------------------------------|
| 40 | Timestamp (Julian date) |
| 100 | Subclass marker (AcDbSpatialIndex) |

The SPATIAL_INDEX is always written out empty to a DXF file. This object can be ignored.

SPATIAL_FILTER

The following group codes are used by SPATIAL_FILTER objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

SPATIAL_FILTER group codes

| Group codes | Description |
|-------------|--|
| 0 | Object name (SPATIAL_FILTER) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always “{ACAD_REACTORS” |
| 330 | Soft-pointer ID/handle to owner dictionary (SPATIAL) |
| 102 | End of persistent reactors group, always “}” |
| 100 | Subclass marker (AcDbFilter) |
| 100 | Subclass marker (AcDbSpatialFilter) |
| 70 | Number of points on the clip boundary 2 = Rectangular clip boundary (lower-left and upper-right) greater than 2 = Polyline clip boundary |
| 10 | Clip boundary definition point (in OCS) (always 2 or more) based on an xref scale of 1 DXF: X value; APP: 2D point |
| 20 | DXF: Y value of boundary definition point (always 2 or more) |

SPATIAL_FILTER group codes (*continued*)

| Group codes | Description |
|-------------|---|
| 210 | Normal to the plane containing the clip boundary DXF: <i>X</i> value; APP: 3D vector |
| 220, 230 | DXF: <i>Y</i> and <i>Z</i> values of extrusion direction |
| 11 | Origin used to define the local coordinate system of the clip boundary DXF: <i>X</i> value; APP: 3D point |
| 21, 31 | Origin used to define the local coordinate system of the clip boundary DXF: <i>Y</i> and <i>Z</i> values |
| 71 | Clip boundary display enabled flag 0 = Disabled; 1 = Enabled |
| 72 | Front clipping plane flag; 0 = No; 1 = Yes |
| 40 | Front clipping plane distance (if code 72 = 1) |
| 73 | Back clipping plane flag; 0 = No; 1 = Yes |
| 41 | Back clipping plane distance (if code 73 = 1) |
| 40 | 4x3 transformation matrix written out in column major order. This matrix is the inverse of the original block reference (insert entity) transformation. The original block reference transformation is the one that is applied to all entities in the block when the block reference is regenerated (always 12 entries) |
| 40 | 4x3 transformation matrix written out in column major order. This matrix transforms points into the coordinate system of the clip boundary (12 entries) |

SORTENTSTABLE

The following group codes are used by SORTENTSTABLE objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

SORTENTSTABLE group codes

| Group codes | Description |
|-------------|--|
| 0 | Object name (SORTENTSTABLE) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary (ACAD_SORTENTS) |
| 102 | End of persistent reactors group, always "}" |
| 100 | Subclass marker (AcDbSortentsTable) |
| 330 | Soft pointer ID/handle to owner (currently only the *MODEL_SPACE or *PAPER_SPACE blocks) |
| 331 | Soft pointer ID/handle to an entity (zero or more entries may exist) |
| 5 | Sort handle (zero or more entries may exist) |

If the SORTENTS Regen flag (bit-code value 16) is set, AutoCAD regenerates entities in ascending handle order. When the DRAWORDER command is used, a SORTENTSTABLE object is attached to the *Model_Space or *Paper_Space block's extension dictionary under the name ACAD_SORTENTS. The SORTENTSTABLE object related to this dictionary associates a different handle with each entity which redefines the order that the entities are regenerated.

VBA_PROJECT

The following group codes are used by VBA_PROJECT objects. For information about abbreviations and formatting used in this table, see ["Formatting Conventions in This Reference" on page 6](#).

| VBA_PROJECT group codes | |
|-------------------------|--|
| Group codes | Description |
| 0 | Object name (VBA_PROJECT) |
| 5 | Handle |
| 102 | Start of persistent reactors group; always "{ACAD_REACTORS" |
| 330 | Soft-pointer ID/handle to owner dictionary |
| 102 | End of persistent reactors group, always "}" |
| 330 | Soft-owner ID/handle to owner object |
| 100 | Subclass marker (AcDbVbaProject) |
| 90 | Number of bytes of binary chunk data (contained in the group code 310 records that follow) |
| 310 | DXF™: Binary object data (multiple entries containing VBA project data) |

XRECORD

The following group codes are common to all xrecord objects. In addition to the group codes described here, see [“Common Group Codes for Objects” on page 116](#). For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

Xrecord group codes

| Group codes | Description |
|--------------------------|---|
| 100 | Subclass marker (AcDbXrecord) |
| 280 | Duplicate record cloning flag (determines how to merge duplicate entries): 0 = Not applicable 1 = Keep existing 2 = Use clone 3 = <xref>\$0\$<name> 4 = \$0\$<name> 5 = Unmangle name |
| 1–369 (except 5 and 105) | These values can be used by an application in any way |

Xrecord objects are used to store and manage arbitrary data. They are composed of DXF group codes with “normal object” groups, (that is, non-xdata group codes) ranging from 1 through 369 for supported ranges. This object is similar in concept to xdata but is not limited by size or order.

Xrecord objects are designed to work in such a way as to not offend releases R13c0 through R13c3. However, if read into a pre-R13c4 level of AutoCAD®, xrecord objects disappear.

THUMBNAILIMAGE Section

This chapter presents the group codes that are found in the THUMBNAILIMAGE section of a DXF™ file. This section exists only if a preview image has been saved with the DXF file.

8

In this chapter


- THUMBNAILIMAGE Section Group Codes

THUMBNAILIMAGE Section Group Codes

The following group codes are found in the THUMBNAILIMAGE section. For information about abbreviations and formatting used in this table, see [“Formatting Conventions in This Reference” on page 6](#).

| THUMBNAILIMAGE group codes | |
|----------------------------|--|
| Group codes | Description |
| 90 | The number of bytes in the image (and subsequent binary chunk records) |
| 310 | Preview image data (multiple lines; 256 characters maximum per line) |

Drawing Interchange File Formats



This appendix describes the various file formats AutoCAD® uses to interchange drawing data with other applications. The formats presented are Drawing Interchange File (DXF™), binary DXF, Slide (SLD), and the Slide Library (SLB) file formats.

DXF files can be either ASCII or binary formats. Because ASCII DXF files are more common than the binary format, the term *DXF file* is used to refer to ASCII DXF files and the term *binary DXF file* is used for the binary format.

In this chapter

- ASCII DXF Files
- Binary DXF Files
- Slide Files
- Slide Library Files

ASCII DXF Files

This section describes the format of ASCII DXF files. It contains information that is needed only if you write your own programs to process DXF files or work with entity information obtained by AutoLISP[®] and ObjectARX[™] applications.

General DXF File Structure

Essentially a DXF file is composed of pairs of codes and associated values. The codes, known as *group codes*, indicate the type of value that follows. Using these group code and value pairs, a DXF file is organized into sections, composed of records, which are composed of a group code and a data item. Each group code and value is on its own line in the DXF file.

Each section starts with a group code 0 followed by the string, SECTION. This is followed by a group code 2 and a string indicating the name of the section (for example, HEADER). Each section is composed of group codes and values that define its elements. A section ends with a 0 followed by the string ENDSEC.

It may be helpful to produce a DXF file from a small drawing, print it out, and refer to it while reading the information presented in this section.

The overall organization of a DXF file is as follows:

- **HEADER section.** Contains general information about the drawing. It consists of an AutoCAD database version number and a number of system variables. Each parameter contains a variable name and its associated value.
- **CLASSES section.** Holds the information for application-defined classes, whose instances appear in the BLOCKS, ENTITIES, and OBJECTS sections of the database. A class definition is permanently fixed in class hierarchy.
- **TABLES section.** Contains definitions for the following symbol tables.
 - APPID (application identification table)
 - BLOCK_RECORD (block reference table)
 - DIMSTYLE (dimension style table)
 - LAYER (layer table)
 - LTYPE (linetype table)
 - STYLE (text style table)
 - UCS (User Coordinate System table)

VIEW (view table)

VPORT (viewport configuration table)

- **BLOCKS section.** Contains block definition and drawing entities that make up each block reference in the drawing.
- **ENTITIES section.** Contains the graphical objects (entities) in the drawing, including block references (insert entities).
- **OBJECTS section.** Contains the nongraphical objects in the drawing. All objects that are not entities or symbol table records or symbol tables are stored in this section. Examples of entries in the OBJECTS section are dictionaries that contain mline styles and groups.
- **THUMBNAILIMAGE section.** Contains the preview image data for of the drawing. This section is optional.

If you use the Select Objects option of the SAVE and SAVEAS commands, the resulting DXF file contains only the ENTITIES section and the EOF marker. The ENTITIES section contains only the objects you select for output. If you select an insert entity, the corresponding block definition is not included in the output file.

Group Codes in DXF Files

Group codes and the associated values define a specific aspect of an object or entity. The line immediately following the group code is the associated value. This value can be a string, an integer, or a floating-point value, such as the *X* coordinate of a point. The lines following the second line of the group, if any, are determined by the group definition and the data associated with the group.

Special group codes are used as file separators, such as markers for the beginning and end of sections, tables, and the end of the file itself.

Entities, objects, classes, tables and table entries, and file separators are introduced with a 0 group code that is followed by a name describing the group.

The maximum DXF file string length is 256 characters. If your AutoCAD drawing contains strings that exceed this number, those strings are truncated during SAVE, SAVEAS, and WBLOCK. OPEN and INSERT fail if your DXF file contains strings that exceed this number.

ASCII Control Characters in DXF Files

SAVEAS handles ASCII control characters in text strings by expanding the character into a caret (^) followed by the appropriate letter. For example, an ASCII Control-G (BEL, decimal code 7) is written as ^G. If the text itself

contains a caret character, it is expanded to caret, space (^). OPEN and INSERT perform the complementary conversion.

Header Group Codes in DXF Files

Applications can retrieve the values of these variables with the AutoLISP `getvar` function.

The following is an example of the HEADER section of a DXF™ file:

| | |
|--------------|---|
| 0 | <i>Beginning of HEADER section</i> |
| SECTION | |
| 2 | |
| HEADER | |
| 9 | <i>Repeats for each header variable</i> |
| \$<variable> | |
| <group code> | |
| <value> | |
| 0 | <i>End of HEADER section</i> |
| ENDSEC | |

Class Group Codes in DXF Files

The following is an example of the CLASSES section of a DXF file:

| | |
|--------------------|-------------------------------------|
| 0 | <i>Beginning of CLASSES section</i> |
| SECTION | |
| 2 | |
| CLASSES | |
| 0 | <i>Repeats for each entry</i> |
| CLASS | |
| 1 | |
| <class dxf record> | |
| 2 | |
| <class name> | |
| 3 | |
| <app name> | |
| 90 | |
| <flag> | |
| 280 | |
| <flag> | |
| 281 | |
| <flag> | |
| 0 | <i>End of CLASSES section</i> |
| ENDSEC | |

Symbol Table Group Codes in DXF Files

The following is an example of the TABLES section of a DXF file.

| | |
|------------------------|---|
| 0 | <i>Beginning of TABLES section</i> |
| SECTION | |
| 2 | |
| TABLES | |
| 0 | <i>Common table group codes, repeats for each entry</i> |
| TABLE | |
| 2 | |
| <table type> | |
| 5 | |
| <handle> | |
| 100 | |
| AcDbSymbol Table | |
| 70 | |
| <max. entries> | |
| 0 | <i>Table entry data, repeats, for each table record</i> |
| <table type> | |
| 5 | |
| <handle> | |
| 100 | |
| AcDbSymbol TableRecord | |
| . | |
| . <data> | |
| . | |
| 0 | <i>End of table</i> |
| ENDTAB | |
| 0 | <i>End of TABLES section</i> |
| ENDSEC | |

Symbol Table Example

This DXF sequence represents three full objects: the symbol table itself plus two entries.

| | |
|-------|--|
| 0 | |
| TABLE | <i>Indicates a symbol table entry</i> |
| 2 | |
| STYLE | <i>Text style symbol table entry. Exception to rule that code 0 fully defines type</i> |

| | |
|--------------|---|
| 5 | |
| 1C | <i>STYLE table handle; same as for entities and other objects</i> |
| 70 | |
| 3 | <i>Maximum number of STYLE table records to follow (pre-Release 13 field)</i> |
| 1001 | |
| APP_X | <i>APP_X has put xdata on a symbol table</i> |
| 1040 | |
| 42. 0 | <i>Just a single floating-point number</i> |
| 0 | |
| STYLE | <i>Beginning of first element in the STYLE symbol table</i> |
| 5 | |
| 3A | <i>The first entry's handle (DIMSTYLE entries will have 105 here)</i> |
| 2 | |
| ENTRY_1 | <i>The first entry's text name</i> |
| 70 | |
| 64 | <i>Standard flag values</i> |
| 40 | |
| . 4 | <i>Text height</i> |
| 41 | |
| 1. 0 | <i>Width scale factor</i> |
| 50 | |
| 0. 0 | <i>Oblique angle</i> |
| 71 | |
| 0 | <i>Text generation flags</i> |
| 42 | |
| 0. 4 | <i>Last height used</i> |
| 3 | |
| BUFONTS. TXT | <i>Primary font file name</i> |

| | |
|----------------|--|
| 0 | |
| STYLE | <i>Second entry begins. No xdata or persistent reactors on first entry</i> |
| 5 | |
| C2 | <i>Second entry handle</i> |
| 2 | |
| ENTRY_2 | <i>Second entry text name</i> |
| ... | |
| ... | <i>Other fields down to group code 3</i> |
| 3 | |
| BUFONTS. TXT | <i>Primary font file name and last object type—specific group</i> |
| 102 | |
| {ACAD_REACTORS | <i>This entry has two persistent reactors</i> |
| 330 | |
| 3C2 | <i>Soft ID to first reactor object</i> |
| 330 | |
| 41B | <i>Soft ID to first reactor object</i> |
| 102 | |
| } | <i>Indicates the end of the reactor set</i> |
| 1001 | |
| APP_1 | <i>Xdata attached to this entry</i> |
| 1070 | |
| 45 | |
| 1001 | |
| APP_2 | |
| 1004 | |
| 18A5B3EF2C199A | |
| 0 | |
| UCS | <i>Start of UCS table (and end of previous record and table)</i> |

Blocks Group Codes in DXF Files

The following is an example of the BLOCKS section of a DXF file:

| | |
|----------------|--|
| 0 | <i>Beginning of BLOCKS section</i> |
| SECTION | |
| 2 | |
| BLOCKS | |
| 0 | <i>Begins each block entry (a block entity definition)</i> |
| BLOCK | |
| 5 | |
| <handle> | |
| 100 | |
| AcDbEntity | |
| 8 | |
| <layer> | |
| 100 | |
| AcDbBlockBegin | |
| 2 | |
| <block name> | |
| 70 | |
| <flag> | |
| 10 | |
| <X value> | |
| 20 | |
| <Y value> | |
| 30 | |
| <Z value> | |
| 3 | |
| <block name> | |
| 1 | |
| <xref path> | |
| 0 | <i>One entry for each entity definition within the block</i> |
| <entity type> | |
| . | |
| . <data> | |
| . | |
| 0 | <i>End of each block entry (an endblock entity definition)</i> |
| ENDBLK | |
| 5 | |
| <handle> | |
| 100 | |
| AcDbBlockEnd | |
| 0 | <i>End of BLOCKS section</i> |
| ENDSEC | |

Entity Group Codes in DXF Files

The following is an example of the ENTITIES section of a DXF file:

```
0                               Beginning of ENTITIES section
SECTION
2
ENTITIES

0                               One entry for each entity definition
<entity type>
5
<handle>
330
<pointer to owner>
100
AcDbEntity
8
<layer>
100
AcDb<classname>
.
. <data>
.

0                               End of ENTITIES section
ENDSEC
```

Object Group Codes in DXF Files

The following is an example of the OBJECTS section of a DXF file:

```
0                               Beginning of OBJECTS section
SECTION
2
OBJECTS

0                               Beginning of named object dictionary
DICTIONARY                     (root dictionary object)
5
<handle>
100
AcDbDictionary

3                               Repeats for each entry
<dictionary name>
350
<handle of child>
```

| | |
|---------------|-------------------------------|
| 0 | <i>Groups of object data</i> |
| <object type> | |
| . | |
| . <data> | |
| . | |
| 0 | <i>End of OBJECTS section</i> |
| ENDSEC | |

Writing a DXF Interface Program

Writing a program that communicates with AutoCAD by means of the DXF file appears more difficult than it actually is. The DXF format makes it easy to ignore information you don't need, while reading the information you do need.

Reading a DXF File

The following example is a simple Visual Basic program that reads a DXF file and extracts specific codes and values from a given object in a given section.


```

' ReadDXF extracts specified code/value pairs from a DXF file.
' This function requires four string parameters, a valid DXF
' file name, a DXF section name, the name of an object in that
' section, and a comma delimited list of codes.

```

```

Function ReadDXF( _
    ByVal dxffile As String, ByVal strSection As String, _
    ByVal strObject As String, ByVal strCodeList As String)
    Dim tmpCode, lastObj As String
    Open dxffile For Input As #1
    ' Get the first code/value pair
    codes = ReadCodes
    ' Loop through the whole file until the "EOF" line
    While codes(1) <> "EOF"
        ' If the group code is '0' and the value is 'SECTION' ..
        If codes(0) = "0" And codes(1) = "SECTION" Then
            ' This must be a new section, so get the next
            ' code/value pair.
            codes = ReadCodes()
            ' If this section is the right one ..
            If codes(1) = strSection Then
                ' Get the next code/value pair and ..
                codes = ReadCodes
                ' Loop through this section until the 'ENDSEC'
                While codes(1) <> "ENDSEC"
                    ' While in a section, all '0' codes indicate
                    ' an object. If you find a '0' store the
                    ' object name for future use.
                    If codes(0) = "0" Then lastObj = codes(1)
                    ' If this object is one you're interested in
                    If lastObj = strObject Then
                        ' Surround the code with commas
                        tmpCode = "," & codes(0) & ","
                        ' If this code is in the list of codes ..
                        If InStr(strCodeList, tmpCode) Then
                            ' Append the return value.
                            ReadDXF = ReadDXF & _
                                codes(0) & "=" & codes(1) & vbCrLf
                        End If
                    End If
                    ' Read another code/value pair
                    codes = ReadCodes
                Wend
            End If
        Else
            codes = ReadCodes
        End If
    Wend
    Close #1
End Function

```

```

' ReadCodes reads two lines from an open file and returns a two item
' array, a group code and its value. As long as a DXF file is read
' two lines at a time, all should be fine. However, to make your
' code more reliable, you should add some additional error and
' sanity checking.

```

```

Function ReadCodes() As Variant
    Dim codeStr, valStr As String
    Line Input #1, codeStr
    Line Input #1, valStr
    ' Trim the leading and trailing space from the code
    ReadCodes = Array(Trim(codeStr), valStr)
End Function

```

Writing a DXF File

Writing a program that creates a DXF file can be more difficult than one that reads a DXF file, because you must maintain consistency within the drawing in order for AutoCAD to find the file acceptable. AutoCAD lets you omit many items in a DXF file and still obtain a usable drawing.

- The entire HEADER section can be omitted if you don't set header variables.
- Any of the tables in the TABLES section can be omitted if you don't need to make entries, and the entire TABLES section can be dropped if nothing in it is required.
- If you define any linetypes in the LTYPE table, this table must appear before the LAYER table.
- If no block definitions are used in the drawing, the BLOCKS section can be omitted.
- If present, the BLOCKS section must appear before the ENTITIES section.
- Within the ENTITIES section, you can reference layer names even though you haven't defined them in the LAYER table. Such layers are automatically created with color 7 and the CONTINUOUS linetype.
- The EOF item must be present at the end of file.

The following Visual Basic subroutine constructs a DXF file representing a polygon.

```
' WriteDXFPolygon creates a minimal DXF file that only contains
' the ENTITIES section. This subroutine requires five parameters,
' the DXF file name, the number of sides for the polygon, the X
' and Y coordinates for the bottom end of the right-most side
' (it starts in a vertical direction), and the length for each
' side. Note that because this only requests 2D points, it does
' not include the Z coordinates (codes 30 and 31). The lines are
' placed on the layer "Polygon."
Sub WriteDXFPolygon( _
    dxfFile As String, iSides As Integer, _
    dblX As Double, dblY As Double, dblLen As Double)
    Dim i As Integer
    Dim dblA1, dblA, dblPI, dblNX, dblNY As Double
    Open dxfFile For Output As #1
    Print #1, 0
    Print #1, "SECTION"
    Print #1, 2
    Print #1, "ENTITIES"
    dblPI = Atn(1) * 4
    dblA1 = (2 * dblPI) / iSides
    dblA = dblPI / 2
    For i = 1 To iSides
        Print #1, 0
        Print #1, "LINE"
        Print #1, 8
        Print #1, "Polygon"
        Print #1, 10
        Print #1, dblX
        Print #1, 20
        Print #1, dblY
        dblNX = dblLen * Cos(dblA) + dblX
        dblNY = dblLen * Sin(dblA) + dblY
        Print #1, 11
        Print #1, dblNX
        Print #1, 21
        Print #1, dblNY
        dblX = dblNX
        dblY = dblNY
        dblA = dblA + dblA1
    Next i
    Print #1, 0
    Print #1, "ENDSEC"
    Print #1, 0
    Print #1, "EOF"
    Close #1
End Sub
```

As long as a properly formatted item appears on the line on which the data is expected, DXFIN accepts it. (Of course, string items should not have leading spaces unless these are intended to be part of the string.) This BASIC program

takes advantage of this flexibility in input format and does not generate a file exactly like one generated by AutoCAD.

In the case of an error in using DXFIN to load, AutoCAD reports the error with a message indicating the nature of the error and the last line processed in the DXF file before the error was detected. This may not be the line on which the error occurred, especially in the case of errors such as the omission of required groups.

Binary DXF Files

The ASCII DXF file format is a complete representation of an AutoCAD drawing in an ASCII text form, and is easily processed by other programs. In addition, AutoCAD can produce or read a binary form of the full DXF file and accept limited input in another binary file format.

The SAVE and SAVEAS commands provide a Binary option that writes binary DXF files. Such a file contains all of the information present in an ASCII DXF file but in a more compact form that takes, typically, 25 percent less file space. It can be read and written more quickly (typically, five times faster) by AutoCAD. Unlike ASCII DXF files, which entail a trade-off between size and floating-point accuracy, binary DXF files preserve all of the accuracy in the drawing database. (AutoCAD Release 10 was the first version to support this form of DXF file; it cannot be read by older versions.)

A binary DXF file begins with a 22-byte sentinel consisting of the following:

AutoCAD Bi nary DXF<CR><LF><SUB><NULL>

Following the sentinel are pairs (group, value) as in an ASCII DXF file but represented in binary form. The group code is a 2-byte binary value (1-byte in DXF files prior to AutoCAD Release 14), and the value that follows is one of the following:

- A 2-byte integer with the least significant byte first and the most significant byte last
- An 8-byte IEEE double-precision floating-point number stored with the least significant byte first and the most significant byte last
- An ASCII string terminated by a 0 (NULL) byte

The type of data following a group is determined from the group code by the same rules used in decoding ASCII DXF files. Translation of angles to degrees and dates to fractional Julian date representation is performed for binary files, as well as for ASCII DXF files. The comment group, 999, is not used in binary DXF files.

Extended data group codes are represented in binary DXF as a single byte with the value 255, followed by a 2-byte integer value containing the actual group code, followed by the actual value.

Extended data long (group code 1071) values occupy 4 bytes of data.

Extended data binary chunks (group code 1004) are represented as a single-byte, unsigned integer length, followed by the specified number of bytes of chunk data. For example, to transfer an extended data long group, the following values would appear, occupying 1, 2, and 4 bytes respectively.

| | |
|--------|--------------------------------------|
| 255 | <i>Escape group code</i> |
| 1071 | <i>True group code</i> |
| 999999 | <i>Value for the 1071 group code</i> |

SAVEAS writes binary DXF files with the same file type (*.dxf*) as for ASCII DXF files. The OPEN and INSERT commands automatically recognizes a binary file by means of its sentinel string. You need not identify it as a binary file.

If the OPEN and INSERT commands encounter an error in a binary DXF file, AutoCAD reports the byte address within the file where the error was detected.

Slide Files

NOTE This information is for experienced programmers, and is subject to change without notice.

AutoCAD slide files are screen images written by the MSLIDE command and read by the VSLIDE command. This section describes the format of slide files for the benefit of developers who wish to incorporate support for slides into their programs.

A slide file consists of a header portion (31 bytes) and one or more data records of variable length. All coordinates and sizes written to the slide file reflect the drawing area of the display device from which the slide was created with point (0,0) located at the lower-left corner of the drawing area. For

AutoCAD Release 9 and later, the slide file header consists of the following fields:

| Slide file header | | |
|-------------------|-------|--|
| Field | Bytes | Description |
| ID string | 17 | "AutoCAD Slide" CR LF ^Z NUL |
| Type indicator | 1 | Currently set to 56 (decimal) |
| Level indicator | 1 | Currently set to 2 |
| High X dot | 2 | Width of the graphics area: 1, in pixels |
| High Y dot | 2 | Height of the graphics area: 1, in pixels |
| Aspect ratio | 4 | Drawing area aspect ratio (horizontal size/vertical size in inches), scaled by 10,000,000. This value is always written with the least significant byte first |
| Hardware fill | 2 | Either 0 or 2 (value is unimportant) |
| Test number | 2 | A number (1234 hex) used to determine whether all 2-byte values in the slide were written with the high-order byte first (Intel 8086-family CPUs) or the low-order byte first (Motorola 68000-family CPUs) |

Data records follow the header. Each data record begins with a 2-byte field whose high-order byte is the record type. The remainder of the record may be composed of 1-byte or 2-byte fields as described in the following table. To determine whether the 2-byte fields are written with the high-order byte first or the low-order byte first, examine the Test number field of the header that is described in the previous table.

| Slide file data records | | | |
|-------------------------|-------|-----------|---|
| Record type (hex) | Bytes | Meaning | Description |
| 00-7F | 8 | Vector | The from-X coordinate for an ordinary vector. From-Y, to-X, and to-Y follow in that order as 2-byte values. The from point is saved as the last point |
| 80-FA | — | Undefined | Reserved for future use |

Slide file data records (*continued*)

| Record type (hex) | Bytes | Meaning | Description |
|-------------------|-------|------------------------|---|
| FB | 5 | Offset vector | The low-order byte and the following three bytes specify the endpoints (from-X, from-Y, to-X, to-Y) of a vector, in terms of offsets (-128 to +127) from the saved last point. The adjusted from point is saved as the last point for use by subsequent vectors |
| FC | 2 | End of file | The low-order byte is 00 |
| FD | 6 | Solid fill | The low-order byte is always zero. The following two 2-byte values specify the X and Y coordinates of one vertex of a polygon to be solid filled. Three to ten such records occur in sequence. A Solid fill record with a negative Y coordinate indicates the start or end of such a flood sequence. In the start record, the X coordinate indicates the number of vertex records to follow |
| FE | 3 | Common endpoint vector | This is a vector starting at the last point. The low-order byte and the following byte specify to-X and to-Y in terms of offsets (-128 to +127) from the saved last point. The adjusted to point is saved as the last point for use by subsequent vectors |
| FF | 2 | New color | Subsequent vectors are to be drawn using the color number indicated by the low-order byte |

If a slide contains any vectors at all, a New color record will be the first data record. The order of the vectors in a slide, and the order of the endpoints of those vectors, may vary.

For example, the following is an annotated hex dump of a simple slide file created on an IBM PC/AT with an IBM Enhanced Graphics Adapter. The slide consists of a white diagonal line from the lower-left corner to the upper-right corner of the drawing area, a green vertical line near the lower-left corner, and a small red rectangle at the lower-left corner.

41 75 74 6F 43 41
 44 20 53 6C 69 64
 65 0D 0A 1A 00

56
 02
 3C 02
 24 01
 0B 80 DF 00
 02 00
 34 12
 07 FF
 3C 02 24 01 00 00 00 00
 3 FF
 0F 00 32 00 0F 00 13 00

01 FF
 12 FB E7 12 CE

DF FE 00

00 FE E7

21 FE 00

00 FC

ID string ("AutoCAD Slide" CR LF ^Z NUL)

Type indicator (56)

Level indicator (2)

High X dot (572)

High Y dot (292)

Aspect ratio (14,647,307 / 10,000,000 = 1.46)

Hardware fill (2)

Test number (1234 hex)

New color (7 = white)

Vector from 572,292 to 0,0. 572,292 becomes "last" point

New color (3 = green)

Vector from 15,50 to 15,19. \x1115,50 becomes "last" point

New color (1 = red)

Offset vector from 15+18,50-25 (33,25) to 15+18, 50-50 (33,0). 33,25 becomes "last" point

Common-endpoint vector from 33,25 to 33-33,25+0 (0,25). 0,25 becomes "last" point

Common-endpoint vector from (0,25) to 0+0,25-25 (0,0). 0,0 becomes "last" point

Common-endpoint vector from (0,0) to 0+33,0+0 (33,0). 33,0 becomes "last" point

End of file

Old Slide Header

The slide format described in the previous section is produced by AutoCAD Release 9 and later, and is portable among all computers running AutoCAD Release 9 or later. Previous versions of AutoCAD (as well as AutoShade® 1.0 and AutoSketch® 1.02) produce slides with a somewhat different header, as shown in the following table.

| Old slide file header | | |
|-----------------------|-------|---|
| Field | Bytes | Description |
| ID string | 17 | "AutoCAD Slide" CR LF ^Z NUL |
| Type indicator | 1 | 56 (decimal) |
| Level indicator | 1 | 1 (old format) |
| High X dot | 2 | Width of the drawing area: 1, in pixels |
| High Y dot | 2 | Height of the drawing area: 1, in pixels |
| Aspect ratio | 8 | Drawing area aspect ratio (horizontal size/vertical size in inches), written as a floating-point number |

Old slide file header (*continued*)

| Field | Bytes | Description |
|---------------|-------|--------------------------------------|
| Hardware fill | 2 | Either 0 or 2 (value is unimportant) |
| Filler byte | 1 | Unused |

Note that the old-format header does not contain a test number field. The floating-point aspect ratio value and all 2-byte integers are written in the native format of the CPU that was used to create the file (for 8086-family CPUs, IEEE double-precision, and low-order byte first). Old-format slide files are not portable across machine types, but they can be read by any version of AutoCAD running on the same CPU type as the CPU with which the slide was created.

Slide Library Files

This section describes the format of AutoCAD slide libraries (Release 9 and later) for the benefit of developers who wish to incorporate support for slide libraries into their programs.

The general format of a slide library is as follows:

"AutoCAD Slide Library 1.0" CR LF ^Z NUL NUL NUL NUL *Header (32 bytes)*
One or more slide directory entries (36 bytes each)
One or more slides (variable length)

Slide directory entries have the following format:

Slide name (NUL terminated) (32 bytes)
Address of slide within library file (4 bytes)

The slide address is always written with the low-order byte first. Each slide to which the directory points is a complete slide file as described in the previous section. The end of the slide directory is signified by an entry with a null slide name (first byte is NUL). A slide library can contain a mixture of old-format and new-format slides.

Advanced DXF Issues

B

This appendix discusses the advanced concepts related to DXF™ group codes.

In this chapter

- Database Objects
- Persistent Inter-Object Reference Handles
- Subclass Markers
- Extension Dictionary and Persistent Reactors
- Extended Data
- Object Coordinate Systems (OCS)
- Arbitrary Axis Algorithm

Database Objects

AutoCAD® drawings consist largely of structured containers for database objects. Database objects each have the following:

- Handle whose value is unique to the drawing/DXF file, and is constant for the lifetime of the drawing. This format has existed since AutoCAD Release 10, but as of AutoCAD Release 13, handles are always enabled.
- Optional xdata table, just as entities have had since AutoCAD Release 11.
- Optional persistent reactor table.
- Optional ownership pointer to an extension dictionary, which in turn owns subobjects placed in it by an application.

Symbol tables and symbol table records are database objects and, thus, have a handle. They can also have xdata and persistent reactors in their DXF records.

Persistent Inter-Object Reference Handles

A set of group code ranges permit objects to directly specify references to other objects within the same drawing/DXF file. Four ranges are provided for the four types of reference handles that you can specify:

- Soft-pointer handle
- Hard-pointer handle
- Soft-owner handle
- Hard-owner handle

These handle types are manifested as entity names in AutoLISP®, as `ads_name` values in ObjectARX™ and as like-named classes derived from ObjectARX. These values are always maintained in insert, xref, and wblock operations such that references between objects in a set being copied are updated to point to the copied objects, while references to other objects remain unchanged.

Also, a group code range for “arbitrary” handles is defined to allow convenient storage of handle values that are not converted to entity names and then translated in insert, xref, or wblock.

NOTE If you use 1005 xdata group codes to store handles, they are treated as soft-pointer handles, which means that when groups of objects are copied or inserted into another drawing, references between the involved objects are translated. Although 1005 xdata items are always returned as handles in AutoLISP and ObjectARX, all of the reference handle group code ranges are represented as “entity names” in AutoLISP and as `ads_name` structures in ObjectARX.

Pointer and Ownership References

A pointer is a reference that indicates usage but not possession or responsibility for another object. Pointer references mean that the object uses the other object in some way, and shares access to it.

An ownership reference means that an owner object is responsible for the objects for which it has an owner handle. Ownership references direct the writing of the entire DWG and DXF files in a generic manner, such as beginning from a few key root objects.

An object can have any number of pointer references associated with it, but it can have only one owner.

Hard and Soft References

Hard references, whether they are pointer or owner, protect an object from being purged. Soft references do not.

In AutoCAD, block definitions and complex entities are hard owners of their elements. A symbol table and dictionaries are soft owners of their elements. Polyline entities are hard owners of their vertex and seqend entities. Insert entities are hard owners of their attrib and seqend entities.

When establishing a reference to another object, it is recommended that you think about whether the reference should protect an object from the PURGE command.

Arbitrary Handles

Arbitrary handles are distinct in that they are not translated to session persistent identifiers internally, to entity names in AutoLISP, and so on. They are stored as handles. When translation of handle values are translated in drawing-merge operations, arbitrary handles are ignored.

In all environments, arbitrary handles can be exchanged for entity names of the current drawing by means of the `handent` functions. A common usage of arbitrary handles is to refer to objects in external DXF and DWG files.

1005 Group Codes

1005 xdata group codes have the same behavior and semantics as soft pointers, which means that they are translated whenever the host object is merged into a different drawing. However, 1005 items are not translated to session-persistent identifiers, internally entity names in AutoLISP and ObjectARX. They are stored as handles.

Subclass Markers

When filing a stream of group data, a single object may be composed of several filer members, one for each level of inheritance where filing is done. Since derived classes and levels of inheritance can evolve separately, the data of each class filer member must be segregated from other members. This is achieved using subclass markers.

All class filer members are expected to precede their class-specific portion of instance data with a “subclass” marker—a 100 group code followed by a string with the actual name of the class. This does not affect the state needed to define the object’s state, but it provides a means for the DXF file parsers to direct the group codes to the corresponding application software.

For example, an object that has data from different derived classes would be represented as follows:

```

999
FOOGRANDCHILD, defined by class AcDbSonOfSonOfFoo, which
999
    is derived from AcDbSonOfFoo
    0
FOOGRANDCHILD
    5
C2
100
AcDbFoo
999
Uses 10/20/30 group codes
    10
    1. 1
    20
    2. 3
    30
    7. 3
    100
AcDbSonOfFoo
999
Also uses 10/20/30 group codes, for a different purpose
    10
    1. 1
    20
    2. 3
    30
    7. 3
    100
AcDbSonOfSonOfFoo
999
Also uses 10/20/30 group codes, for yet another purpose
    10
    13. 2
    20
    23. 1
    30
    31. 2
    999
Now for the Xdata
    1001
APP_1
    1070
    45
    1001
APP_2
    1004
    18A5B3EF2C199A

```

Extension Dictionary and Persistent Reactors

The extension dictionary is an optional sequence that stores the handle of a dictionary object that belongs to the current object, which in turn may contain entries. This facility allows attachment of arbitrary database objects to any database object. Any object or entity may have this section.

Persistent reactors are an optional sequence that stores object handles of objects registering themselves as reactors on the current object. Any object or entity may have this section.

Extended Data

Extended data (xdata) is created by AutoLISP or ObjectARX applications. If an entity contains extended data, it follows the entity's normal definition data. The group codes 1000 through 1071 describe extended data. The following is an example of an entity containing extended data in DXF format.

Normal entity definition data:

```
0
INSERT
5
F11
100
AcDbEntity
8
TOP
100
AcDbBlockReference
2
BLOCK_A
10
0.0
20
0.0
30
0.0
```

Extended entity definition data:


```

1001
AME_SOL
1002
{
1070
0
1071
1. 95059E+06
1070
519
1010
2. 54717
1020
2. 122642
1030
2. 049201
1005
ECD
1005
EE9
1005
0
1040
0. 0
1040
1. 0
1000
MI LD_STEEL

```

The group code 1001 indicates the beginning of extended data. In contrast to normal entity data, with extended data the same group code can appear *multiple times*, and *order* is important.

Extended data are grouped by registered application name. Each registered application's group begins with a 1001 group code with the application name as the string value. Registered application names correspond to APPID symbol table entries.

An application can use as many APPID names as needed. APPID names are permanent, although they can be purged if they aren't currently used in the drawing. Each APPID name can have no more than one data group attached to each entity. Within an application's group, the sequence of extended data groups and their meaning is defined by the application.

The extended data group codes are listed in the following table.

Extended data group codes and descriptions

| Entity name | Group code | Description |
|-------------|------------|--|
| String | 1000 | Strings in extended data can be up to 255 bytes long (with the 256th byte reserved for the null character) |

Extended data group codes and descriptions (*continued*)

| Entity name | Group code | Description |
|--------------------------|-----------------------------|---|
| Application name | 1001 also a string value | Application names can be up to 31 bytes long (the 32nd byte is reserved for the null character). NOTE Do not add a 1001 group into your extended data because AutoCAD assumes it is the beginning of a new application extended data group |
| Control string | 1002 | An extended data control string can be either "{" or "}". These braces enable applications to organize their data by subdividing the data into lists. The left brace begins a list, and the right brace terminates the most recent list. Lists can be nested. When AutoCAD reads the extended data for a particular application, it checks to ensure that braces are balanced |
| Layer name | 1003 | Name of the layer associated with the extended data |
| Binary data | 1004 | Binary data is organized into variable-length <i>chunks</i> . The maximum length of each chunk is 127 bytes. In ASCII DXF files, binary data is represented as a string of hexadecimal digits, two per binary byte |
| Database handle | 1005 | Handles of entities in the drawing database NOTE When a drawing with handles and extended data handles is imported into another drawing using INSERT, INSERT *, XREF Bind, XBIND, or partial OPEN, the extended data handles are translated in the same manner as their corresponding entity handles, thus maintaining their binding. This is also done in the EXPLODE block operation or for any other AutoCAD operation. When AUDIT detects an extended data handle that doesn't match the handle of an entity in the drawing file, it is considered an error. If AUDIT is fixing entities, it sets the handle to 0 |
| 3 reals | 1010, 1020, 1030 | Three real values, in the order X, Y, Z. They can be used as a point or vector record. AutoCAD never alters their value |
| World space position | 1011, 1021, 1031 | Unlike a simple 3D point, the world space coordinates are moved, scaled, rotated, and mirrored along with the parent entity to which the extended data belongs. The world space position is also stretched when the STRETCH command is applied to the parent entity and this point lies within the select window |
| World space displacement | 1012, 1022, 1032 | Also a 3D point that is scaled, rotated, and mirrored along with the parent (but is not moved or stretched) |
| World direction | 1013, 1023, 1033 | Also a 3D point that is rotated and mirrored along with the parent (but is not moved, scaled, or stretched) |
| Real | 1040 | A real value |
| Distance | 1041 | A real value that is scaled along with the parent entity |

Extended data group codes and descriptions (*continued*)

| Entity name | Group code | Description |
|--------------|------------|---|
| Scale factor | 1042 | Also a real value that is scaled along with the parent. The difference between a distance and a scale factor is application-defined |
| Integer | 1070 | A 16-bit integer (signed or unsigned) |
| Long | 1071 | A 32-bit signed (long) integer |

Object Coordinate Systems (OCS)

To save space in the drawing database (and in the DXF file), the points associated with each entity are expressed in terms of the entity's own object coordinate system (OCS). The OCS was referred to as ECS in previous releases of AutoCAD. With OCS, the only additional information needed to describe the entity's position in 3D space is the 3D vector describing the *Z* axis of the OCS, and the elevation value.

For a given *Z* axis (or extrusion) direction, there are an infinite number of coordinate systems, defined by translating the origin in 3D space and by rotating the *X* and *Y* axes around the *Z* axis. However, for the same *Z* axis direction, there is only one OCS. It has the following properties:

- Its origin coincides with the WCS origin.
- The orientation of the *X* and *Y* axes within the *XY* plane are calculated in an arbitrary but consistent manner. AutoCAD performs this calculation using the arbitrary axis algorithm (see [“Arbitrary Axis Algorithm” on page 175](#)).

For some entities, the OCS is equivalent to the WCS and all points (DXF groups 10–37) are expressed in world coordinates. See the following table.

Coordinate systems associated with an entity type

| Entities | Notes |
|--|---|
| 3D entities such as line, point, 3dface, 3D polyline, 3D vertex, 3D mesh, 3D mesh vertex | These entities do not lie in a particular plane. All points are expressed in world coordinates. Of these entities, only lines and points can be extruded. Their extrusion direction can differ from the world <i>Z</i> axis |

Coordinate systems associated with an entity type (*continued*)

| Entities | Notes |
|--|--|
| 2D entities such as circle, arc, solid, trace, text, attrib, attdef, shape, insert, 2D polyline, 2D vertex, lwpolyline, hatch, image | These entities are planar in nature. All points are expressed in object coordinates. All of these entities can be extruded. Their extrusion direction can differ from the world Z axis |
| Dimension | Some of a dimension's points are expressed in WCS and some in OCS |
| Viewport | Expressed in world coordinates |

Once AutoCAD has established the OCS for a given entity, the OCS works as follows: The elevation value stored with an entity indicates how far to shift the *XY* plane along the *Z* axis (from the WCS origin) to make it coincide with the plane that contains the entity. How much of this is the user-defined elevation is unimportant.

Any 2D points entered through the UCS are transformed into the corresponding 2D points in the OCS, which is shifted and rotated with respect to the UCS.

These are a few ramifications of this process:

- You cannot reliably find out what UCS was in effect when an entity was acquired.
- When you enter the *XY* coordinates of an entity in a given UCS and then do a SAVEAS, you probably won't recognize those *XY* coordinates in the DXF file. You must know the method by which AutoCAD calculates the *X* and *Y* axes in order to work with these values.
- The elevation value stored with an entity and output in DXF files is a sum of the *Z*-coordinate difference between the UCS *XY* plane and the OCS *XY* plane, and the elevation value that the user specified at the time the entity was drawn.

Arbitrary Axis Algorithm

The arbitrary axis algorithm is used by AutoCAD internally to implement the arbitrary but consistent generation of object coordinate systems for all entities which use object coordinates.

Given a unit-length vector to be used as the Z axis of a coordinate system, the arbitrary axis algorithm generates a corresponding X axis for the coordinate system. The Y axis follows by application of the right-hand rule.

The method is to examine the given Z axis (also called the *normal vector*) and see if it is close to the positive or negative world Z axis. If it is, cross the world Y axis with the given Z axis to arrive at the arbitrary X axis. If not, cross the world Z axis with the given Z axis to arrive at the arbitrary X axis. The boundary at which the decision is made was chosen to be both inexpensive to calculate and completely portable across machines. This is achieved by having a sort of “square” polar cap, the bounds of which is $1/64$, which is precisely specifiable in six decimal-fraction digits and in six binary-fraction bits.

The algorithm does the following. (All vectors are assumed to be in 3D space and specified in the world coordinate system.)

Let the given normal vector be called N .

Let the world Y axis be called Wy , which is always $(0, 1, 0)$.

Let the world Z axis be called Wz , which is always $(0, 0, 1)$.

Here we are looking for the arbitrary X and Y axes to go with the normal N . They will be called Ax and Ay . N could also be called Az (the arbitrary Z axis) as follows:

If $(\text{abs}(Nx) < 1/64)$ and $(\text{abs}(Ny) < 1/64)$ then

$Ax = Wy \times N$ (where “ \times ” is the cross-product operator).

Otherwise,

$Ax = Wz \times N$.

Scale Ax to unit length.

The method of getting the Ay vector is:

$Ay = N \times Ax$. Scale Ay to unit length.

Index

- *Model_Space block definition, 57
- *Paper_Space block definition, 57
- 2D entities, coordinate systems associated with, 174
- 3D entities, coordinate systems associated with, 173
- 3dface group codes, 62
- 3dsolid group codes, 63

A

- acad_proxy_entity group codes, 63
- ACAD_PROXY_OBJECT group codes, 117
- ACADMAINTVR DXF system variable, 16
- ACADVER DXF system variable, 16
- ACDBDICTIONARYWDFLT group codes, 118
- ACDBPLACEHOLDER group codes, 119
- aligned dimension group codes, 71
- ANGBASE DXF system variable, 16
- ANGDIR DXF system variable, 16
- angular dimension group codes, 74
- anonymous blocks, 56
- APPID group codes, 38
 - xdata groupings and, 171
- application-defined object types, 116
- arbitrary axis algorithm, 175
- arbitrary handles, 166
- arc edge data for hatch entities, 81
- arc group codes, 64
- ASCII control characters in DXF files, 147
- ASCII DXF files
 - about, 145
 - vs. binary DXF files, 158
 - BLOCKS section (example), 152
 - CLASSES section (example), 148

- control character handling, 147
- ENTITIES section (example), 153
- HEADER section (example), 148
- maximum file string length, 147
- OBJECTS section (example), 153
- reading (example), 154
- sections of, 146
- structure of, 146
- TABLES section (example), 149
- writing (example), 156

- attdef group codes, 65
- ATTMODE DXF system variable, 16
- attrib group codes, 66
- AUNITS DXF system variable, 16
- AUPREC DXF system variable, 16
- AutoLISP
 - arbitrary handles and, 167
 - entnext function output for ole2frame entity (example), 96
 - group code 1005 xdata items and, 168
 - handent function, 168
 - reference handles and, 166, 167

B

- binary DXF files, 145, 158
- block definitions
 - about, 56
 - Model_Space and Paper_Space, 57
 - UCS/WCS and, 57
- block group codes, 56
- block reference (insert) group codes, 85
- block table handles, 56
- BLOCK_RECORD group codes, 39
- BLOCKS section

- about, 55, 147
- example of, 152
- group codes in, 56
- and writing a DXF file, 156

blocks, anonymous, 56

body group codes, 68

boundary path data for hatch entities, 80

C

C++ class names, default class values, 33

CECOLOR DXF system variable, 16

CELTSCALE DXF system variable, 16

CELTYPE DXF system variable, 16

CELWEIGHT DXF system variable, 16

CEPSNTYPE DXF system variable, 16

CHAMFERA DXF system variable, 16

CHAMFERB DXF system variable, 16

CHAMFERC DXF system variable, 17

CHAMFERD DXF system variable, 17

circle group codes, 69

CLASSES section

- about, 31, 146
- default class values by DXF record name and C++ class name, 33
- group codes in, 32

CLAYER DXF system variable, 17

CMLJUST DXF system variable, 17

CMLSCALE DXF system variable, 17

CMLSTYLE DXF system variable, 17

common entity group codes, 60

control character handling, 147

conventions used in this reference, 6

coordinate systems associated with entity types, 173

CPSNID DXF system variable, 16

D

database objects, 166

default class values by DXF record name and C++ class name, 33

deleted items in symbol tables, 36

diameter dimension group codes, 73

dictionaries, named object, 116

DICTIONARY group codes, 120

DICTIONARYVAR group codes, 121, 122

DIMADEC DXF system variable, 17

DIMALT DXF system variable, 17

DIMALTD DXF system variable, 17

DIMALTF DXF system variable, 17

DIMALTRND DXF system variable, 17

DIMALTTD DXF system variable, 17

DIMALTTZ DXF system variable, 17

DIMALTU DXF system variable, 17

DIMALTZ DXF system variable, 17

DIMAPOST DXF system variable, 17

DIMASO DXF system variable, 18

DIMASZ DXF system variable, 18

DIMATFIT DXF system variable, 18

DIMAUNIT DXF system variable, 18

DIMAZIN DXF system variable, 18

DIMBLK DXF system variable, 18

DIMBLK1 DXF system variable, 18

DIMBLK2 DXF system variable, 18

DIMCEN DXF system variable, 18

DIMCLRD DXF system variable, 18

DIMCLRE DXF system variable, 18

DIMCLRT DXF system variable, 18

DIMDEC DXF system variable, 18

DIMDLE DXF system variable, 18

DIMDLI DXF system variable, 18

DIMDSEP DXF system variable, 19

dimension entities, coordinate systems associated with, 174

dimension group codes, 69

- aligned, 71
- angular, 74
- common, 69
- diameter, 73
- linear, 72
- ordinate, 75
- radial, 73
- rotated, 72

dimension style overrides, 76

DIMEXE DXF system variable, 19

DIMEXO DXF system variable, 19

DIMFRAC DXF system variable, 19

DIMGAP DXF system variable, 19

DIMJUST DXF system variable, 19

DIMLDRBLK DXF system variable, 19

DIMLFAC DXF system variable, 19

DIMLIM DXF system variable, 19

DIMLUNIT DXF system variable, 19

DIMLWD DXF system variable, 19

DIMLWE DXF system variable, 19

DIMPOST DXF system variable, 19

DIMRND DXF system variable, 19

DIMSAH DXF system variable, 19

DIMSCALE DXF system variable, 20

DIMSD1 DXF system variable, 20

DIMSD2 DXF system variable, 20

DIMSE1 DXF system variable, 20

DIMSE2 DXF system variable, 20

DIMSHO DXF system variable, 20

DIMSOXD DXF system variable, 20

DIMSTYLE

- table handle code, 36

DIMSTYLE DXF system variable, 20

DIMSTYLE group codes, 40

DIMSTYLE table handle code, 36

DIMTAD DXF system variable, 20

DIMTDEC DXF system variable, 20

DIMTFAC DXF system variable, 20

- DIMTIH DXF system variable, 20
- DIMTIX DXF system variable, 20
- DIMTM DXF system variable, 20
- DIMTMOVE DXF system variable, 20
- DIMTOFL DXF system variable, 20
- DIMTOH DXF system variable, 20
- DIMTOL DXF system variable, 20
- DIMTOLJ DXF system variable, 20
- DIMTP DXF system variable, 21
- DIMTSZ DXF system variable, 21
- DIMTVP DXF system variable, 21
- DIMTXSTY DXF system variable, 21
- DIMTXT DXF system variable, 21
- DIMTZIN DXF system variable, 21
- DIMUPT DXF system variable, 21
- DIMZIN DXF system variable, 21
- DISPSILH DXF system variable, 21
- drawing interchange file formats
 - ASCII DXF, 145, 146
 - binary DXF, 145, 158
 - Slide (SLD), 159
 - Slide Library (SLB), 163
- DWGCODEPAGE DXF system variable, 21
- DXF
 - conventions
 - group code ranges, 7
 - group codes in numerical order, 9
 - file parsers, subclass markers and, 168
 - files. *See* ASCII DXF files; binary DXF files
 - format
 - about, 5
 - interface programs, writing (example), 154
 - record names, default class values, 33
 - system variables, 16
- DXFIN considerations for writing DXF files, 157

E

- ECS. *See* object coordinate system
- ELEVATION DXF system variable, 21
- elevation value for entity positioning, 173
- ellipse edge data for hatch entities, 82
- ellipse group codes, 76
- elliptical arc definition, 77
- endblk group codes, 58
- ENDCAPS DXF system variable, 21
- entities
 - block, 56
 - coordinate systems associated with, 173
 - endblk, 56
 - entity group codes vs. object codes, 6
 - group codes listed in numerical order, 9
- ENTITIES section
 - about, 59, 147
 - and writing a DXF file, 156
- extension dictionary, 170
- EXTMAX DXF system variable, 21

- EXTMIN DXF system variable, 21
- EXTNAMES DXF system variable, 22
- extrusion direction, OCS properties for, 173

F

- FASTZ revised VPORT header variable, 28
- filing a stream of group data, subclass markers and, 168
- FILLETRAD DXF system variable, 22
- FILLMODE DXF system variable, 22
- FINGERPRINTGUID DXF system variable, 22

G

- getvar AutoLISP function, 148
- graphical object group codes. *See names of specific objects*
- GRIDMODE revised VPORT header variable, 28
- GRIDUNIT revised VPORT header variable, 28
- group codes
 - about, 146
 - arbitrary handle range, 166
 - ASCII DXF files and, 147
 - binary DXF files and, 158
 - for entities (graphical objects), 60
 - examples of, 148
 - formatting conventions for, 6
 - in numerical order, 9
 - objects/entities and, 6
 - ranges of, 7
 - reference handle ranges, 166
 - for xdata, 171
- group data, subclass markers and, 168
- GROUP group codes, 124

H

- handent functions (AutoLISP), 168
- handles
 - about, 166
 - arbitrary, 166
 - of dictionary objects, 170
 - reference, 166
- HANDSEED DXF system variable, 22
- hard references vs. soft references, 167
- hard-owner handles, 166
- hard-pointer handles, 166
- hatch group codes, 78
- hatch pattern data, 83
- HEADER section
 - about, 15, 146
 - example of, 148
 - group codes for revised VPORT variables, 27
 - group codes for saved DXF system variables, 16

time/date variables, handling of, 28
and writing a DXF file, 156
HYPERLINKBASE DXF system variable, 22

I

IDBUFFER group codes, 125
image group codes, 83
IMAGEDEF group codes, 125
IMAGEDEF_REACTOR group codes, 126
inheritance levels for filer members, subclass
 markers and, 168
INSBASE DXF system variable, 22
INSERT command
 ASCII control character handling and, 147
 binary DXF files and, 159
insert group codes, 85
INSUNITS DXF system variable, 22

J

JOINSTYLE DXF system variable, 22

L

LAYER group codes, 44
LAYER_FILTER group codes, 128
LAYER_INDEX group codes, 127
LAYOUT group codes, 128
leader group codes, 86
LIMCHECK DXF system variable, 22
LIMMAX DXF system variable, 22
LIMMIN DXF system variable, 22
line edge data for hatch entities, 81
line group codes, 88
linear dimension group codes, 72
LTSCALE DXF system variable, 22
LTYPE group codes, 45
LUNITS DXF system variable, 22
LUPREC DXF system variable, 22
LWDISPLAY DXF system variable, 23
lwppolyline group codes, 88

M

MAXACTVP DXF system variable, 23
MEASUREMENT DXF system variable, 23
MENU DXF system variable, 23
MIRRTXT DXF system variable, 23
mline group codes, 89
MLINESTYLE group codes, 131
Model_Space block definition, 57
MSLIDE/VSLIDE commands, 159
mtext group codes, 92

N

named object dictionary, 116
nongraphical object group codes. *See names of specific objects*
normal vector, arbitrary axis algorithm and, 175
numerical order group codes, 9

O

object coordinate system (OCS), 173
 arbitrary axis algorithm and, 175
OBJECT_PTR group codes, 132
ObjectARX
 group code 1005 xdata items and, 168
 reference handles and, 166, 167
ObjectARX, reference handles and, 166
objects
 object group codes vs. entity codes, 6
 ownership of, 116
OBJECTS section
 about, 115, 147
 common group codes, 116
ole2frame entities, AutoLISP entnext function
 output (example), 96
ole2frame group codes, 94
 DXF output (example), 95
oleframe group codes, 93
OPEN command
 ASCII control character handling and, 147
 binary DXF files and, 159
ordinate dimension group codes, 75
ORTHOMODE DXF system variable, 23
ownership pointers to extension dictionaries,
 166
ownership references vs. pointer references, 167

P

Paper_Space block definition, 57
pattern data for hatch entities, 83
PDMODE DXF system variable, 23
PDSIZE DXF system variable, 23
PELEVATION DXF system variable, 23
persistent inter-object reference handles, 166
persistent reactor tables, 166, 170
PEXTMAX DXF system variable, 23
PEXTMIN DXF system variable, 23
PFACE command considerations, 98
PINSBASE DXF system variable, 23
PLIMCHECK DXF system variable, 23
PLIMMAX DXF system variable, 23
PLIMMIN DXF system variable, 23
PLINEGEN DXF system variable, 23
PLINEWID DXF system variable, 23, 24
PLOTSETTINGS group codes, 133
point group codes, 96

- pointer references vs. ownership references, 167
- polyface meshes in DXF, 98
- polyline boundary data for hatch entities, 81
- polyline group codes, 97
 - polyface meshes and, 98
- PROXYGRAPHICS DXF system variable, 23
- PSLTSCALE DXF system variable, 23
- PSVPSCALE DXF system variable, 24
- PUCSBASE DXF system variable, 24
- PUCSNAME DXF system variable, 24
- PUCSORG DXF system variable, 24
- PUCSORGBACK DXF system variable, 24
- PUCSORGBOTTOM DXF system variable, 24
- PUCSORGFRONT DXF system variable, 24
- PUCSORGGLEFT DXF system variable, 24
- PUCSORGRIGHT DXF system variable, 24
- PUCSORGTOP DXF system variable, 24
- PUCSORTHOREF DXF system variable, 24
- PUCSORTHVIEW DXF system variable, 24
- PUCSXDIRE DXF system variable, 24
- PUCSYDIRE DXF system variable, 24

Q

- QTEXTMODE DXF system variable, 25

R

- radial dimension group codes, 73
- ranges of group codes, 7
- RASTERVARIABLES group codes, 135
- ray group codes, 99
- reading a DXF file (example), 154
- reference handles
 - hard vs. soft, 167
 - pointer vs. ownership, 167
 - types of, 166
- REGENMODE DXF system variable, 25
- region group codes, 99
- rotated dimension group codes, 72

S

- SAVE command
 - Binary option, 158
 - Select Objects option, 147
- SAVEAS command
 - ASCII control character handling and, 147
 - binary DXF files and, 159
 - Binary option, 158
 - Select Objects option, 147
- sequend group codes, 100
- SHADEDGE DXF system variable, 25
- SHADEDIF DXF system variable, 25
- shape group codes, 100
- SKETCHINC DXF system variable, 25

- SKPOLY DXF system variable, 25
- slide (SLD) files
 - about, 159
 - data record types, 160
 - header format, 159
 - hex dump of (example), 161
 - old-format header, 162
 - vectors and, 160
- slide library (SLB) file format, 163
- SNAPANG revised VPORT header variable, 28
- SNAPBASE revised VPORT header variable, 28
- SNAPISOPAIR revised VPORT header variable, 28
- SNAPMODE revised VPORT header variable, 28
- SNAPSTYLE revised VPORT header variable, 28
- SNAPUNIT revised VPORT header variable, 28
- soft references vs. hard references, 167
- soft-owner handles, 166
- soft-pointer handles, 166, 167
- solid group codes, 101
- SORTENTSTABLE group codes, 138
- SPATIAL_FILTER group codes, 137
- SPATIAL_INDEX group codes, 136
- SPLFRAME DXF system variable, 25
- spline edge data for hatch entities, 82
- spline group codes, 102
- SPLINESEGS DXF system variable, 25
- SPLINETYPE DXF system variable, 25
- STYLE group codes, 46
- subclass markers, 168
- SURFTAB1 DXF system variable, 25
- SURFTAB2 DXF system variable, 25
- SURFTYPE DXF system variable, 25
- SURFU DXF system variable, 25
- SURFV DXF system variable, 25
- symbol table entries
 - common group codes, 37
 - structure of, 36
- symbol tables
 - common group codes, 36
 - deleted items and, 36
 - DIMSTYLE handle, 36
 - handles and, 166
 - identifying, 36
 - structure of, 36
- system variables, saved in DXF files, 16

T

- TABLES section
 - about, 35, 146
 - example of, 149
 - symbol table common group codes, 36
 - symbol table structure, 36
 - and writing a DXF file, 156
- tagged data, 5
- TDCREATE DXF system variable, 25
- TDINDWG DXF system variable, 25

- TDUCREATE DXF system variable, 25
- TDUPDATE DXF system variable, 25
- TDUSRTIMER DXF system variable, 25
- TDUUPDATE DXF system variable, 26
- text group codes, 103
- TEXTSIZE DXF system variable, 26
- TEXTSTYLE DXF system variable, 26
- THICKNESS DXF system variable, 26
- THUMBNAIL section
 - about, 147
- THUMBNAILIMAGE
 - group codes, 144
- THUMBNAILIMAGE section
 - about, 143
- TILEMODE DXF system variable, 26
- time/date variables, handling of, 28
- tolerance group codes, 105
- TRACE DXF system variable, 26
- trace group codes, 106
- TREEDEPTH DXF system variable, 26

U

- UCS group codes, 47
- UCSBASE DXF system variable, 26
- UCSNAME DXF system variable, 26
- UCSORG DXF system variable, 26
- UCSORGBACK DXF system variable, 26
- UCSORGBOTTOM DXF system variable, 26
- UCSORGFRONT DXF system variable, 26
- UCSORGGLEFT DXF system variable, 26
- UCSORGRIGHT DXF system variable, 26
- UCSORGTOP DXF system variable, 26
- UCSORTHOREF DXF system variable, 26
- UCSORTHOVIEW DXF system variable, 27
- UCSXDIR DXF system variable, 27
- UCSYDIR DXF system variable, 27
- UNITMODE DXF system variable, 27
- user coordinate system (UCS), 174
- USERI1-5 DXF system variable, 27
- USERR1-5 DXF system variable, 27
- USRTIMER DXF system variable, 27

V

- VBA_PROJECT group codes, 139
- vectors, in slide files, 160
- VERSIONGUID DXF system variable, 27

- vertex group codes, 107
- VIEW group codes, 49
- VIEWCTR revised VPORT header variable, 28
- VIEWDIR revised VPORT header variable, 28
- viewport entities
 - coordinate systems associated with, 174
- viewport group codes, 109
- VIEWSIZE revised VPORT header variable, 28
- VISRETAIN DXF system variable, 27
- Visual Basic programs (examples)
 - for reading a DXF file, 154
 - for writing a DXF file, 157
- VPORT group codes, 51
- VPORT header variables, revised, 27
- VSLIDE/MSLIDE commands, 159

W

- world coordinate system (WCS), 173
- WORLDVIEW DXF system variable, 27
- writing a DXF file (example), 156

X

- X and Y axes orientation calculations, 173, 174, 175
- X axis, arbitrary axis algorithm and, 175
- xdata
 - and dimension entities, 76
 - sample entity containing (DXF format), 170
- xdata group codes, 171
 - binary DXF group codes, 158
- XEDIT DXF system variable, 27
- xline group codes, 113
- XRECORD group codes, 140
- XY coordinates, working with, 174

Y

- Y axis, arbitrary axis algorithm and, 175

Z

- Z axis
 - arbitrary axis algorithm and, 175
 - OCS properties for, 173